

Mr.Go CQ-C102

Mr.Go 10-inch Rechargeable LED Cube Light User Manual

Model: CQ-C102

1. PRODUCT OVERVIEW

The Mr.Go 10-inch Rechargeable LED Cube Light is a versatile and durable lighting solution designed for both indoor and outdoor use. It features a robust PE shell, multi-colored LED lighting with 16 RGB color tones, and 4 dynamic lighting modes. The built-in rechargeable battery ensures cordless operation, making it ideal for various decorative and ambient lighting needs.

Key Features:

- **Waterproof Design:** Durable PE shell with IP68 waterproof rating, suitable for outdoor environments.
- **16 RGB Colors & Dimmable:** Offers a wide spectrum of colors and adjustable brightness levels.
- **4 Lighting Modes:** Includes Flash, Strobe, Fade, and Smooth modes for dynamic lighting effects.
- **Remote Control:** All functions are easily controlled via an infrared (IR) remote control.
- **Rechargeable & Cordless:** Built-in lithium polymer battery provides 8-48 hours of operation on a 2-hour charge.
- **Shatter-Resistant:** Constructed from sturdy polyethylene material.




Image: The Mr.Go 10-inch LED Cube Light illuminated with a purple glow, showcasing its ambient lighting capability.

2. PACKING LIST

Please ensure all items are present in the package:

- 1x Mr.Go 10-inch LED Cube Light
- 1x IR Remote Control
- 1x Charger Adapter with 4 ft cord (US Style)
- 1x User Manual (this document)

Packing List

1x Rechargeable LED Cube Light 1x User Manual
1x 24-key Remote Control 1x US Charger with USB Cord



* Single remote can control multiple lamps.
Remote control working range: 16 to 26 feet.

Remove the clear plastic piece before using.

Image: A visual representation of the Mr.Go 10-inch LED Cube Light, its remote control, and charger adapter, as typically found in the product packaging.

3. SETUP

3.1 Initial Charging

1. Locate the charging port on the bottom of the LED Cube Light.
2. Connect the provided charger adapter to the charging port.
3. Plug the charger into a standard electrical outlet.
4. Allow the unit to charge for approximately 2 hours for a full charge. The charging indicator will typically change color or turn off when fully charged.

Note: The unit can be used while charging, but it may need to be placed on its side if the charging port is on the bottom.



Image: The Mr.Go LED Cube Light connected to a wall charger, illustrating its rechargeable and cordless feature.

3.2 Remote Control Preparation

- Remove the clear plastic piece from the battery compartment of the IR remote control before first use.

4. OPERATING INSTRUCTIONS

The LED Cube Light can be controlled using the included IR remote control or the button located on the bottom of the unit.

4.1 Using the Remote Control

Point the remote directly at the LED Cube Light for optimal responsiveness. The remote control has a working range of 16 to 26 feet.

Button	Function
Power ON/OFF	Turns the light on or off.
Brightness +/-	Adjusts the brightness level (8 levels available).
Color Buttons (R, G, B, W, etc.)	Selects one of the 16 preset static colors.
FLASH	Cycles through colors with a rapid flash effect.
STROBE	Flashes white light on and off.
FADE	Smoothly transitions between colors.
SMOOTH	Gradually cycles through RGB colors.
Dynamic Speed +/-	Adjusts the speed of dynamic modes (Flash, Strobe, Fade, Smooth).



Image: The remote control for the Mr.Go LED Cube Light, displaying buttons for power, brightness, 16 static colors, and 4 dynamic lighting modes.

4.2 Using the Bottom Button

A button on the bottom of the cube allows for basic control:

- Press once to turn on/off.
- Press repeatedly to cycle through different colors and modes.

5. MAINTENANCE

5.1 Cleaning

To clean the LED Cube Light, wipe it with a damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the PE shell.

5.2 Storage

When not in use for extended periods, ensure the unit is fully charged and stored in a cool, dry place away from direct sunlight.



Image: The Mr.Go LED Cube Light being sprayed with water, highlighting its waterproof design for outdoor use.

6. TROUBLESHOOTING

Problem	Possible Solution
Light does not turn on.	Ensure the unit is charged. Check if the remote control's plastic tab has been removed. Try pressing the power button on the remote or the bottom button multiple times.
Remote control is unresponsive.	Ensure the remote is pointed directly at the cube. Check the remote control battery. Replace if necessary. Remove any obstructions between the remote and the cube.
Light does not hold a charge.	Ensure the charger is properly connected and the power outlet is functional. The battery may need to be replaced if it's old or damaged.
Colors are not changing correctly.	Ensure the remote control is functioning correctly. Try resetting the unit by turning it off and on.

7. SPECIFICATIONS

Feature	Detail
Model Name	CQ-C102
Product Dimensions	10"D x 10"W x 10"H
Item Weight	3.3 Pounds
Material	Polyethylene (PE)
Light Source Type	LED
Light Color	16 RGB Colors
Power Source	Battery Powered (1 Lithium Polymer battery included)
Battery Life	8 - 48 Hours (depending on brightness settings)
Charging Time	Approx. 2 hours
Wattage	1.5 watts

Feature	Detail
Voltage	5 Volts
Water Resistance Level	Waterproof (IP68)
Control Method	Remote (IR) / Push button
Certification	CE Certified, UL Listed

8. WARRANTY INFORMATION

Mr.Go products are designed for quality and durability. For specific warranty details regarding your LED Cube Light, please refer to the warranty card included with your purchase or contact Mr.Go customer support directly. Keep your purchase receipt as proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

If you encounter any issues or have questions about your Mr.Go 10-inch Rechargeable LED Cube Light that are not covered in this manual, please contact Mr.Go customer support for assistance. You can typically find contact information on the product packaging or the official Mr.Go website.
For more information, visit the [Mr.Go Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question