Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duravit 2169090092

Instruction Manual

ME by Starck One-Piece Elongated Toilet

Model: 2169090092 | Brand: Duravit

Introduction

This instruction manual provides essential information for the installation, operation, maintenance, and troubleshooting of your Duravit ME by Starck 0.8/1.28 GPF Dual Flush Floor Mounted One Piece Elongated Toilet, Model 2169090092. This toilet is designed for durability and seamless integration into modern bathrooms. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of your product. Note: This manual pertains to the toilet unit itself; the toilet seat is sold separately.

Product Overview



Image 1: Front view of the Duravit ME by Starck One-Piece Elongated Toilet. This image shows the sleek, minimalist design of the white ceramic toilet, highlighting its one-piece construction and the integrated tank. The top of the toilet, where a seat would typically rest, is visible, along with the smooth, floor-mounted base.

The Duravit ME by Starck toilet is a floor-mounted, one-piece unit featuring a dual-flush system operated by a wall-mounted actuator plate (sold separately). Its elongated bowl provides enhanced comfort, and the ceramic construction ensures hygiene and ease of cleaning. The one-piece design simplifies installation and offers a streamlined aesthetic.

Setup and Installation

Before beginning installation, ensure you have all necessary tools and components. It is recommended that installation be performed by a qualified professional.

Included Components:

- Duravit ME by Starck One-Piece Elongated Toilet Unit
- Mounting Hardware

Required Tools (Not Included):

- Adjustable Wrench
- Screwdriver (Phillips and Flathead)

- Level
- Sealant (Wax Ring or Wax-Free Seal)
- Measuring Tape
- Drill (if needed for floor mounting)

Installation Steps:

1. **Preparation:** Turn off the water supply to the toilet area. Remove any existing toilet and clean the flange area thoroughly. Ensure the floor is level and clean.
2. **Seal Installation:** Install the wax ring or wax-free seal onto the toilet's waste outlet or directly onto the floor flange, following the sealant manufacturer's instructions.
3. **Positioning the Toilet:** Carefully lift and position the one-piece toilet unit over the floor bolts, aligning the waste outlet with the flange. Gently press down and rock the toilet slightly to ensure a good seal.
4. **Securing the Toilet:** Install the washers and nuts onto the floor bolts. Tighten the nuts evenly, alternating between sides, until the toilet is secure and stable. Do not overtighten, as this can crack the ceramic. Use a level to ensure the toilet is perfectly horizontal.
5. **Water Supply Connection:** Connect the water supply line to the toilet's fill valve. Ensure all connections are tight to prevent leaks.
6. **Wall Actuator Plate Installation:** Install the wall-mounted actuator plate according to its specific instructions. This plate controls the dual flush mechanism.
7. **Testing:** Turn on the water supply slowly and check for leaks. Flush the toilet several times using both flush options to ensure proper operation and water flow.

Operating Instructions

Your Duravit ME by Starck toilet features a dual-flush system designed for water efficiency. The flush mechanism is activated via a wall-mounted actuator plate (not included with the toilet unit).

Dual Flush Operation:

- **Partial Flush (0.8 GPF):** For liquid waste, press the smaller button or section on your wall-mounted actuator plate. This uses less water (0.8 Gallons Per Flush) for efficient waste removal.
- **Full Flush (1.28 GPF):** For solid waste, press the larger button or section on your wall-mounted actuator plate. This uses the full water volume (1.28 Gallons Per Flush) to ensure complete waste removal.

Always ensure the actuator plate is properly installed and calibrated for optimal flush performance.

Maintenance and Care

Regular cleaning and proper maintenance will ensure the longevity and pristine appearance of your Duravit toilet.

Cleaning the Ceramic Surface:

- Use a soft cloth or sponge with mild, non-abrasive bathroom cleaners.
- Avoid using abrasive powders, scouring pads, or harsh chemical cleaners (e.g., bleach, acid-based cleaners) as these can damage the ceramic glaze.
- Rinse thoroughly with clean water after cleaning and wipe dry to prevent water spots.

Internal Components:

- Periodically inspect the fill valve and flush valve for any signs of wear or mineral buildup.

- If you notice a continuous running water sound, it may indicate an issue with the fill valve or flush valve seal. Consult a plumber if necessary.

General Tips:

- Do not use in-tank drop-in cleaners as they can damage internal components and void warranties.
- Ensure proper ventilation in the bathroom to prevent mold and mildew buildup.

Troubleshooting

This section addresses common issues you might encounter with your toilet. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Toilet runs continuously	Flapper/flush valve not sealing; fill valve malfunction; water level too high.	Check flapper for debris or wear; adjust water level in tank; inspect/replace fill valve.
Weak flush	Low water level; clogged rim jets or siphon jet; partial clog in drain.	Adjust water level; clean rim jets; clear any clogs in the drain line.
Toilet leaks at base	Loose floor bolts; faulty wax ring/seal; cracked toilet base.	Tighten floor bolts (do not overtighten); replace wax ring/seal; if cracked, toilet replacement may be necessary.
Toilet does not flush	Actuator plate issue; disconnected flush chain/cable; no water supply.	Check actuator plate connection; ensure water supply is on; inspect internal flush mechanism.

Specifications

Feature	Detail
Brand	Duravit
Model Number	2169090092
Color	White
Product Dimensions (D x W x H)	15.75"D x 14.63"W x 15.75"H
Material	Ceramic
Item Weight	69.4 Pounds
Installation Type	Floor Mounted
Flush Type	Dual Flush (0.8 GPF / 1.28 GPF)
Bowl Shape	Elongated
Included Components	Toilet Unit, Hardware
Seat Included	No (Sold Separately)

Warranty and Support

For specific warranty details regarding your Duravit product, please refer to the warranty documentation provided at the time of purchase or visit the official Duravit website. Duravit offers high-quality products designed for long-term durability.

Protection plans may be available for purchase separately to extend coverage beyond the manufacturer's warranty. For customer support, technical assistance, or to inquire about replacement parts, please contact Duravit customer service through their official channels. Refer to your purchase documentation or the Duravit website for contact information.

© 2024 Duravit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01E7IEMB8

More documents and user manuals: **https://manuals.plus/**