

[Manuals.plus](#) /

› [TACWISE](#) /

› Tacwise 1219 Z2-M Manual Hand Stapler Kit User Manual

TACWISE 1219

Tacwise 1219 Z2-M Manual Hand Stapler Kit User Manual

Model: 1219 Z2-M | Brand: TACWISE

INTRODUCTION

This manual provides instructions for the safe and effective use of your Tacwise 1219 Z2-M Manual Hand Stapler Kit. This kit includes the Z2-M hand stapler, a staple remover, and a pack of 53/8mm staples, designed for various stapling tasks. Please read these instructions carefully before initial use and retain them for future reference.



Figure 1: Tacwise 1219 Z2-M Manual Hand Stapler Kit contents.

SAFETY INFORMATION

Always observe basic safety precautions when using hand tools to reduce the risk of injury.

- Wear appropriate personal protective equipment, such as safety glasses, to protect against flying debris.

- Keep hands and fingers clear of the stapling mechanism and staple exit area.
- Ensure the stapler is pointed away from yourself and others when not in use or when loading/unloading staples.
- Do not attempt to staple materials that are too hard or thick for the tool, as this can cause staples to jam or ricochet.
- Store the tool in a safe place, out of reach of children.
- Do not modify the tool or use it for purposes other than its intended design.

PACKAGE CONTENTS

The Tacwise 1219 Z2-M Manual Hand Stapler Kit typically includes the following items:

- Tacwise Z2-M Manual Hand Stapler
- Staple Remover
- 5000 x 53/8mm Staples
- Storage Case (Orange)

SETUP

1. Loading Staples

1. **Unlock the Handle:** If the handle is locked down for storage, press the handle release button or mechanism to allow the handle to spring up.
2. **Open the Magazine:** Locate the staple magazine release at the rear or bottom of the stapler. Push or pull this mechanism to open the staple magazine. The magazine will slide out.
3. **Insert Staples:** Place a strip of Tacwise 53/8mm staples into the magazine with the staple legs pointing downwards. Ensure the staples are correctly oriented and fit snugly.
4. **Close the Magazine:** Slide the magazine back into the stapler until it clicks securely into place. Ensure it is fully closed to prevent staples from falling out during use.



Figure 2: Loading staples into the Z2-M stapler magazine.



Figure 3: Operating the staple magazine release mechanism.

2. Adjusting the Margin Adjuster (if applicable)

The Z2-M stapler features an adjustable margin adjuster. This allows you to set a consistent distance from the edge of your material for precise stapling. Slide the adjuster to the desired measurement before stapling.

OPERATING INSTRUCTIONS

1. Using the Hand Stapler

1. **Position the Stapler:** Place the stapler firmly against the material you wish to staple, ensuring the nose of the stapler is flat against the surface.
2. **Apply Pressure and Staple:** Squeeze the handle firmly and completely until a staple is driven into the material. Release the handle to prepare for the next staple.
3. **Check Staple Depth:** Inspect the stapled material to ensure the staple is fully embedded. If not, adjust your technique by applying more consistent pressure or checking the material suitability.



Figure 4: Tacwise Z2-M stapler ready for operation.

2. Using the Staple Remover

The included staple remover is designed to safely and easily remove staples without damaging the material.

1. **Position the Remover:** Slide the pointed end of the staple remover underneath the crown of the staple.
2. **Leverage and Lift:** Gently press down on the handle of the remover, using it as a lever to lift the staple out of the material.
3. **Dispose of Staples:** Safely dispose of removed staples to prevent injury.

MAINTENANCE

- **Cleaning:** Keep the stapler clean and free from dust and debris. Use a dry cloth to wipe down the exterior. Do not use harsh chemicals or solvents.
- **Lubrication:** No regular lubrication is required for manual staplers.
- **Storage:** When not in use, lock the handle down (if applicable) and store the stapler and accessories in the provided case in a dry, cool place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Staples not firing or jamming	◦ Empty magazine ◦ Incorrect staple size/type ◦ Staples jammed in the mechanism ◦ Magazine not fully closed	◦ Reload staples ◦ Ensure using 53/8mm staples ◦ Open magazine, remove jammed staples carefully ◦ Push magazine until it clicks securely
Staples not fully penetrating material	◦ Insufficient pressure applied ◦ Material too hard/dense ◦ Worn stapler mechanism	◦ Apply more firm and consistent pressure ◦ Use a different fastening method for harder materials ◦ Consider replacing the stapler if consistently underperforming
Staples bending or buckling	◦ Stapler not held flat against surface ◦ Material too soft or too hard	◦ Ensure stapler nose is flush with the surface ◦ Verify material suitability for stapling

SPECIFICATIONS

Feature	Detail
Brand	TACWISE
Model Number	1219 (Z2-M)
Product Dimensions (L x W x H)	15.7 x 2.8 x 8.2 cm
Item Weight	1 Kilogram
Color	Orange
Material Type	Metal
Staple Type	Type 53 (8mm)
Operation Mode	Manual
Included Staples	5000
Special Features	Lockable handle, adjustable margin adjuster, customization window

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Manufacturer: Tacwise

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question