

[Manuals.plus](#) /

› [Lavazza](#) /

› Lavazza Deséa LM950 Coffee Machine User Manual

Lavazza LM950

Lavazza Deséa LM950 Coffee Machine User Manual

Model: LM950

INTRODUCTION

Welcome to the world of Lavazza Deséa. This manual provides detailed instructions for the safe and efficient operation, setup, and maintenance of your new Lavazza Deséa LM950 Coffee Machine. Designed for ease of use and exceptional coffee quality, the Deséa LM950 allows you to enjoy a variety of coffee and milk-based beverages with an intuitive touch interface.



Figure 1: Lavazza Deséa LM950 Coffee Machine, showcasing its sleek black design and integrated milk frother.

SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- Always connect the machine to a grounded power outlet.
- Do not immerse the machine, power cord, or plug in water or other liquids.
- Keep hands and cords away from hot surfaces and steam.
- Unplug the machine before cleaning and when not in use for extended periods.
- This appliance is for household use only.

- Do not operate the machine if it has a damaged cord or plug, or if it malfunctions or has been damaged in any way.

PACKAGE CONTENTS

Ensure all items are present in the box before discarding packaging materials.

- Lavazza Deséa LM950 Coffee Machine
- Removable Water Tank
- Milk Frother Jug with whisk
- Drip Tray and Grid
- Instruction Manual (this document)
- Starter pack of Lavazza A Modo Mio capsules (may vary by region)



Figure 2: The retail packaging for the Lavazza Deséa LM950, indicating the contents within.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Lavazza Deséa LM950.

1. **Control Panel:** Intuitive touch interface for selecting drink types and adjusting settings.
2. **Capsule Insertion Lever:** For opening and closing the capsule compartment.
3. **Capsule Compartment:** Where Lavazza A Modo Mio capsules are inserted.
4. **Used Capsule Drawer:** Collects used capsules.
5. **Water Tank:** Removable tank for fresh water.
6. **Drip Tray:** Collects excess liquid and supports cups.
7. **Milk Frother Jug:** For preparing frothed milk for cappuccinos and lattes.

8. **Power Button:** To turn the machine on or off.

SETUP

1. Unpacking and Initial Cleaning

- Remove all packaging materials from the machine.
- Wash the water tank, drip tray, and milk frother jug with warm soapy water. Rinse thoroughly and dry.
- Wipe the exterior of the machine with a damp cloth.

2. Filling the Water Tank

- Remove the water tank from the back of the machine.
- Fill the tank with fresh, potable water up to the MAX line. Do not use sparkling water or other liquids.
- Place the water tank back onto the machine, ensuring it is securely seated.

3. Power Connection

- Place the machine on a stable, flat surface.
- Plug the power cord into a suitable grounded electrical outlet.

4. First Use Cycle

- Turn on the machine using the power button. It will begin to heat up.
- Once heated, place a large container under the coffee spout.
- Press the Lungo button (or a similar large coffee button) without inserting a capsule. This will flush the internal system with hot water. Repeat this process 2-3 times.

OPERATING INSTRUCTIONS

Brewing Coffee (Espresso, Lungo)

1. Ensure the water tank is filled and the machine is powered on and heated (indicator light stable).
2. Lift the capsule insertion lever and insert one Lavazza A Modo Mio capsule into the compartment. Close the lever firmly.
3. Place your cup on the drip tray.
4. Select your desired coffee type (e.g., Espresso, Lungo) from the touch panel. The machine will begin brewing.
5. The machine will automatically stop when the selected volume is dispensed.
6. After brewing, lift the lever to eject the used capsule into the internal drawer.



Figure 3: A freshly brewed coffee beverage in a glass cup, demonstrating the quality of the output.

Preparing Milk-Based Beverages (Cappuccino, Latte Macchiato)

1. Pour cold milk into the milk frother jug, observing the MIN/MAX fill lines for your desired beverage.
2. Place the jug on the designated spot on the machine.
3. Insert a coffee capsule as described above.
4. Select your desired milk-based beverage (e.g., Cappuccino, Latte Macchiato) from the touch panel. The machine will first froth the milk, then dispense the coffee.
5. Once complete, carefully remove the jug and pour the frothed milk and coffee into your serving cup.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your machine.

Daily Cleaning

- **Drip Tray:** Empty and rinse the drip tray and grid daily.
- **Used Capsule Drawer:** Empty the used capsule drawer daily and rinse it.
- **Milk Frother Jug:** Immediately after each use, rinse the milk frother jug and whisk with warm water. For thorough cleaning, disassemble the whisk and wash all parts with warm soapy water.

- **Exterior:** Wipe the machine's exterior with a soft, damp cloth.

Descaling

The machine will indicate when descaling is required (refer to your machine's specific indicator light pattern in the full manual). Use a descaling solution recommended by Lavazza and follow the instructions provided with the descaler. Typically, the process involves:

1. Empty the water tank and fill it with the descaling solution mixed with water as per the descaler's instructions.
2. Place a large container under the coffee spout.
3. Initiate the descaling cycle (refer to your machine's specific button combination or menu option).
4. Once the descaling cycle is complete, rinse the water tank thoroughly and fill it with fresh water.
5. Run 2-3 full water cycles (without capsules) to rinse the machine.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue.	Check power cord connection; try a different outlet.
No coffee dispenses.	Water tank empty; machine not heated; capsule not inserted correctly.	Fill water tank; wait for machine to heat up; ensure capsule is properly seated.
Coffee is cold or lukewarm.	Machine not fully heated; cups not pre-warmed.	Allow machine to fully heat; pre-warm cups with hot water.
Milk not frothing properly.	Milk type (use cold, fresh, semi-skimmed milk); frother jug/whisk dirty.	Ensure milk is cold and fresh; clean frother jug and whisk thoroughly.
Machine leaks.	Water tank not seated correctly; internal issue.	Re-seat water tank; if problem persists, contact customer support.

SPECIFICATIONS

- **Brand:** Lavazza
- **Model Number:** LM950
- **Colour:** Ink Cartridge (Black)
- **Product Dimensions:** 41.7 x 14.5 x 28 cm
- **Weight:** 5 kg
- **Water Tank Capacity:** 1200 Millilitres
- **Power / Wattage:** 1500 watts
- **Voltage:** 240 Volts
- **Material:** Acrylonitrile Butadiene Styrene
- **Compatible Capsules:** Lavazza A Modo Mio
- **Coffee Maker Type:** Espresso Machine

WARRANTY AND SUPPORT

For warranty information, technical support, or service requests, please contact Lavazza customer service. Keep your proof of purchase for warranty claims.

Manufacturer: Luigi Lavazza S.p.A.



Figure 4: Lavazza customer support contact graphic, indicating availability for assistance.

You may also visit the official Lavazza website for FAQs and additional support resources.