

Hoover XP 25

Hoover XARION PRO XP 25 Bagless Multicyclonic Canister Vacuum Cleaner Instruction Manual

Model: XP 25

1. INTRODUCTION

Thank you for choosing the Hoover XARION PRO XP 25 Bagless Multicyclonic Canister Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

The Hoover XARION PRO XP 25 is designed for powerful and consistent cleaning performance across various floor types. Its advanced multicyclonic technology, combined with a HEPA filter, ensures effective dust separation and high filtration efficiency, making it suitable for allergy sufferers.

2. SAFETY INFORMATION

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the voltage indicated on the appliance corresponds to the mains voltage in your home.
- Do not use the vacuum cleaner to pick up water, liquids, hot ashes, burning cigarette ends, or sharp objects.
- Do not operate the appliance with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Always unplug the appliance before cleaning or performing maintenance.
- Do not pull the power cord to disconnect the plug from the socket. Grasp the plug itself.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Hoover XARION PRO XP 25 vacuum cleaner:

- Main Canister Unit (with dust container and filters)
- Flexible Hose
- Telescopic Tube
- All Floors Extra Nozzle
- Parquet Brush (for delicate hard floors)
- Mini Turbo Brush (for pet hair and upholstery)
- Crevice Tool
- Dusting Brush



This image displays the complete Hoover XARION PRO XP 25 vacuum cleaner system, including the main red and grey

canister unit, the flexible hose, the adjustable telescopic tube, and a selection of cleaning tools such as floor nozzles, a crevice tool, and a dusting brush.



The Hoover XARION PRO XP 25 vacuum cleaner is shown fully assembled with its flexible hose, adjustable telescopic tube, and the primary floor cleaning nozzle attached, ready for use.



The Hoover parquet brush attachment, specifically designed with soft bristles to gently clean delicate hard floors like parquet without causing scratches.



The Hoover mini turbo brush attachment, ideal for removing pet hair and deep cleaning upholstery. It features a rotating brush for effective dirt agitation.

4. SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Attaching the Hose:** Insert the flexible hose into the suction inlet on the main canister unit until it clicks securely into place.
3. **Connecting the Telescopic Tube:** Attach the handle end of the hose to the telescopic tube. Adjust the telescopic tube to a comfortable operating height by pressing the release button and extending or retracting it.
4. **Attaching a Nozzle:** Select the appropriate cleaning nozzle (e.g., All Floors Extra, Parquet Brush) and firmly attach it to the end of the telescopic tube.
5. **Power Connection:** Extend the power cord to its full length (9m operating radius) and plug it into a suitable mains power socket.

5. OPERATING INSTRUCTIONS

1. **Turning On/Off:** Press the ON/OFF pedal switch located on the main canister unit to start or stop the vacuum cleaner.

2. **Suction Power:** The Hoover XARION PRO XP 25 operates at a fixed power of 800 Watts, providing consistent suction.
3. **Using Different Nozzles:**
 - **All Floors Extra Nozzle:** Suitable for general cleaning on both carpets and hard floors.
 - **Parquet Brush:** Use this brush for delicate hard floors like wood or laminate to prevent scratches.
 - **Mini Turbo Brush:** Ideal for deep cleaning upholstery, stairs, and removing pet hair.
 - **Crevice Tool:** For narrow gaps, corners, and edges.
 - **Dusting Brush:** For cleaning delicate surfaces, curtains, and shelves.
4. **Cord Rewind:** After use, press the cord rewind button on the main unit to automatically retract the power cord.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Emptying and Cleaning the Dust Container

The 1.5-liter dust container should be emptied regularly, especially when the dust level reaches the 'MAX' indicator.

1. Ensure the vacuum cleaner is unplugged from the power supply.
2. Press the release button to detach the dust container from the main unit. The design allows for one-hand detachment in approximately two seconds.
3. Position the container over a waste bin and open the bottom flap to empty the contents.
4. Close the flap securely and reattach the dust container to the vacuum cleaner until it clicks into place.
5. The dust container is treated with silver ions to help prevent the formation of bacteria.



This image provides a view of the Hoover XARION PRO XP 25 vacuum cleaner from the side, clearly showing the transparent dust collection container, which allows users to monitor dust levels and facilitates easy emptying.

6.2 Cleaning the Filters

Your Hoover XARION PRO XP 25 is equipped with two washable EPA filters (HEPA filters) for high filtration efficiency. Clean them regularly to maintain suction power.

1. Unplug the vacuum cleaner.
2. Locate the filter compartments (refer to your product diagram for exact locations).
3. Remove the filters.
4. Tap the filters gently to remove loose dust. If heavily soiled, rinse them under lukewarm running water. Do not use detergents.
5. Allow the filters to air dry completely for at least 24 hours before reinserting them. Do not use a hairdryer or other heating devices.
6. Reinsert the dry filters into their compartments and close the covers securely.



A square-shaped HEPA filter, designed for optimal air filtration in the Hoover XARION PRO XP 25 vacuum cleaner. This filter is washable and crucial for maintaining air quality.



A rectangular HEPA filter, another component of the Hoover XARION PRO XP 25 vacuum cleaner's advanced filtration system. This filter is also washable and helps capture fine dust particles.

6.3 Cleaning Brushes and Nozzles

Periodically check all brushes and nozzles for blockages or tangled hair/fibers. Remove any obstructions to ensure effective cleaning.

7. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply.	Check if the plug is securely inserted into the socket. Check the household fuse/circuit breaker.
Reduced suction power.	Dust container full. Filters are dirty/blocked. Hose, tube, or nozzle is blocked.	Empty the dust container. Clean or wash the filters (refer to Section 6.2). Check and remove any blockages from the hose, telescopic tube, or selected nozzle.

Problem	Possible Cause	Solution
Unusual noise during operation.	Blockage in the air path. Filter incorrectly fitted.	Check for and remove any blockages. Ensure all filters are correctly seated.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Hoover
Model Number	XP 25
Color	Red/Grey
Dimensions (L x W x H)	30.5 x 30 x 42 cm
Weight	10 Kilograms
Dust Container Capacity	1.5 Litres
Power	800 Watts
Material	Plastic
Noise Level	75 dB
Energy Class	A to G
Annual Energy Consumption	27 kilowatthours per year
Filter Type	HEPA (2 washable EPA filters)
Operating Radius	9 meters
Special Features	Multicyclonic Airvolution Technology, Telescopic Tube, Parquet Brush, Carpet Optimax Brush, All Floors Extra Brush, Mini Turbo Brush with Silver Ion, 360° Swivel Front Wheel, Bagless

9. WARRANTY AND SUPPORT

Your Hoover XARION PRO XP 25 vacuum cleaner is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

For technical assistance, spare parts, or service inquiries, please contact Hoover customer support through their official website or the contact information provided in your product documentation.

© 2025 Hoover. All rights reserved.