

MoKo Smart Shell Cover Case

MoKo Smart Shell Cover Case for Samsung Galaxy Tab A 7.0 Inch Instruction Manual

Model: Smart Shell Cover Case

1. PRODUCT OVERVIEW

1.1 Product Description

The MoKo Smart Shell Cover Case is custom designed to provide protection and functionality for your Samsung Galaxy Tab A 7.0 Inch 2016 Released Tablet. It combines a slim, lightweight profile with durable materials to safeguard your device for years to come. The case features a unique New York City design, adding a touch of style.

1.2 Key Features

- **Slim & Lightweight Design:** Adds minimal bulk while providing maximum protection.
- **Durable Hardback:** Protects your device against scratches and minor impacts.
- **Premium Materials:** Constructed with a high-quality PU leather exterior and a soft microfiber interior.
- **Convenient Stand Position:** Easily folds into a stable stand for comfortable viewing or typing.
- **Magnetic Closure:** Securely keeps the case closed when not in use.
- **Precise Cutouts:** Ensures full access to all ports, buttons, and features without removing the case.
- **Full Screen Display:** No raised bezels around the screen, allowing for unobstructed gesture swipes.

1.3 Compatibility

This MoKo Smart Shell Cover Case is specifically designed for the following models:

- Samsung Galaxy Tab A 7.0 Inch Tablet 2016 Release (SM-T280)
- Samsung Galaxy Tab A 7.0 Inch Tablet 2016 Release (SM-T285)

NOTE: This case is NOT compatible with Galaxy Tab A 9.7 / 8.0 / 10.1, Galaxy Tab 3 Lite 7.0, Galaxy Tab E / Lite 7.0 / 9.6 / 8.0 / 7.0, or any other Samsung Galaxy Tablets.



Image: The MoKo Smart Shell Cover Case in New York City design, showcasing its functionality as a stand for the Samsung Galaxy Tab A 7.0 Inch tablet.

2. SETUP

2.1 Installation

Follow these steps to properly install your MoKo Smart Shell Cover Case onto your Samsung Galaxy Tab A 7.0 Inch tablet:

1. **Prepare Your Tablet:** Ensure your tablet is clean and free of dust or debris.
2. **Align the Tablet:** Gently align your Samsung Galaxy Tab A 7.0 Inch tablet with the hardback shell of the case. Ensure the camera, ports, and buttons on your tablet match the corresponding cutouts on the case.
3. **Insert the Tablet:** Carefully press the tablet into the hardback shell, starting from one corner and working your way around. Apply gentle, even pressure until the tablet is securely seated within the case.

4. **Check Fit:** Verify that all edges of the tablet are fully enclosed by the case and that all cutouts align perfectly with your tablet's features.

PROTECTIVE AND RELIABLE

Fully covers your device and protects it against scratches.

- » Durable hardback
- » Microfiber lining
- » Premium synthetic leather




Image: A close-up of the MoKo Smart Shell Cover Case securely fitted onto a tablet, demonstrating its protective design.



PRECISE CUTOUTS

Align well with your tablet's features and allow smooth operation without removing the case.



Image: Detailed view of the precise cutouts on the MoKo case, ensuring full access to all tablet functions.

3. OPERATING

3.1 Using the Stand Function

The MoKo Smart Shell Cover Case can be easily converted into a stand for comfortable viewing or typing:

- **For Viewing:** Fold the front cover back and tuck it into the designated groove on the back of the case. This creates a stable triangular stand, ideal for watching videos or browsing.
- **For Typing:** For a lower angle suitable for typing, fold the front cover into a different triangular shape, providing a comfortable incline for keyboard input.



COMFORTABLE TYPING


It turns into a stable stand, more comfortable to typing, writing e-mail, etc.



Image: The tablet case configured into a stable stand, demonstrating its utility for comfortable typing.

BEST VIEWING

It turns into a convenient stand, frees your hands and gives you a best viewing angle.



Comfortable angle eases spine pain.



Image: The case providing an optimal viewing angle, illustrated with a diagram showing ergonomic benefits.

3.2 Magnetic Closure

The case features a magnetic closure to keep the front cover securely shut when not in use. This helps protect the screen from scratches and accidental activation. Simply close the front cover over the tablet screen, and the magnets will engage to hold it in place.

4. MAINTENANCE

4.1 Cleaning Instructions

To keep your MoKo Smart Shell Cover Case in optimal condition, follow these cleaning guidelines:

- **Exterior (PU Leather):** Wipe gently with a soft, damp cloth. For stubborn stains, use a mild soap solution diluted with water, then wipe with a clean, damp cloth and dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Interior (Microfiber):** Use a dry, lint-free cloth to gently wipe away dust and smudges. If necessary, lightly dampen the cloth with water. Do not saturate the microfiber.
- **General:** Do not submerge the case in water. Allow the case to air dry completely before reinserting

your tablet.

4.2 Care Tips

- Avoid exposing the case to extreme temperatures or direct sunlight for prolonged periods, as this may affect the material's integrity and color.
- Do not bend or twist the hardback excessively, as this could cause damage.
- Keep the case away from sharp objects to prevent scratches or punctures.

5. TROUBLESHOOTING

5.1 Common Issues

Problem	Possible Cause / Solution
Case does not fit my tablet.	Ensure your tablet is a Samsung Galaxy Tab A 7.0 Inch 2016 Release (SM-T280 / SM-T285). This case is not compatible with other tablet models. Double-check the model number of your tablet.
Magnetic closure is not strong.	Ensure no foreign objects are lodged between the cover and the tablet screen. The magnetic closure is designed to be secure but not overly strong to allow easy opening.
Tablet slips out of the case.	Ensure the tablet is fully seated and snapped into all corners of the hardback shell during installation. If the issue persists, inspect the case for any damage.
Stand function is unstable.	Ensure the cover is folded correctly into the triangular stand position and placed on a flat, stable surface.

6. SPECIFICATIONS

Feature	Detail
Brand	MoKo
Compatible Devices	Samsung Galaxy Tab A 7.0 Inch (SM-T280 / SM-T285)
Material	Premium PU Leather (exterior), Microfiber (interior), Hardback Shell
Color	New York City design

Feature	Detail
Product Dimensions (L x W x H)	22.58 x 13.69 x 0.99 cm (approx. 22.6 x 13.7 x 1 cm)
Item Weight	120 Grams
Special Features	Stand Function, Magnetic Closure, Precise Cutouts, Slim & Lightweight
UPC	765857104355

7. WARRANTY AND SUPPORT

7.1 Lifetime Warranty

This MoKo Smart Shell Cover Case is backed by a Lifetime Warranty when purchased exclusively from BSCstore. This warranty covers manufacturing defects and ensures the quality of your product.

7.2 Customer Support

For any questions, concerns, or warranty claims regarding your MoKo product, please contact BSCstore customer service. You can typically find their contact information on the platform where you purchased the product or by searching for "BSCstore customer service" online.