

[Manuals.plus](#) /

› [DOOGEE](#) /

› DOOGEE Cube P1 Smart Mini DLP LED Projector User Manual

DOOGEE P1

DOOGEE Cube P1 Smart Mini DLP LED Projector User Manual

Model: P1

1. INTRODUCTION

This user manual provides detailed instructions for the operation and maintenance of your DOOGEE Cube P1 Smart Mini DLP LED Projector. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.

2. SAFETY INFORMATION

To ensure safe operation and prolong the life of your projector, please observe the following safety precautions:

- Do not block the ventilation openings. Ensure adequate airflow around the projector.
- Do not expose the projector to rain or moisture to prevent fire or electric shock.
- Avoid direct eye exposure to the projector lens when the lamp is on.
- Use only the power adapter supplied with the projector.
- Do not attempt to disassemble or repair the projector yourself. Refer all servicing to qualified personnel.
- Keep the projector away from heat sources and direct sunlight.

3. PACKAGE CONTENTS

Please check the package contents upon opening. If any items are missing or damaged, contact your retailer.

- DOOGEE Cube P1 Projector
- Power Adapter
- User Manual
- USB Cable (if applicable)
- HDMI Cable (if applicable)

4. PRODUCT OVERVIEW

Familiarize yourself with the components and ports of your DOOGEE Cube P1 projector.

4.1. Front View



Figure 4.1: Front view of the DOOGEE Cube P1 projector. This image displays the projector's unique cube design with red, yellow, blue, and white sections, highlighting the projection lens on the red section. The DOOGEE logo is visible on the white section, and "Smart Cube P1" is on the blue section.

4.2. Side View



Figure 4.2: Side view of the DOOGEE Cube P1 projector. This image shows the side of the projector, emphasizing the ventilation grilles on the red and white sections, and a power button or switch located on the red section. The projector's light is visible from the lens.

4.3. Top View



Figure 4.3: Top view of the DOOGEE Cube P1 projector. This image provides an aerial perspective of the projector, showcasing its complete cube form and the distinct color blocks (red, yellow, blue, white) that make up its design. The projection light is visible from the lens.

4.4. Ports and Controls

- **Power Button:** Turns the projector on/off.
- **USB Port:** For connecting USB devices (e.g., flash drives) or charging.
- **HDMI Port:** For connecting external video sources.
- **Focus Ring:** Adjusts image clarity (if applicable, not explicitly mentioned but common for projectors).
- **Ventilation Grilles:** Ensure proper heat dissipation.

5. SETUP

5.1. Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a wall outlet.
3. The projector has a built-in 4800mAh battery, allowing for portable use without constant power connection once charged.

5.2. Placement

Place the projector on a stable, flat surface. Ensure there are no obstructions around the ventilation grilles. For optimal viewing, position the projector directly in front of the projection surface (wall or screen).

- **Projection Distance:** The optimal projection distance for a 100-inch screen is approximately 3.3 meters. Adjust distance to achieve desired screen size.

5.3. Connecting External Devices

- **HDMI:** Connect an HDMI cable from your source device (e.g., laptop, game console) to the HDMI port on the projector.
- **USB:** Insert a USB flash drive into the USB port to play media files directly.
- **Wireless Connection:** The projector supports 2.4GHz WiFi for wireless connectivity. Refer to the "Operating Instructions" section for details on setting up wireless connections.

6. OPERATING INSTRUCTIONS

6.1. Powering On/Off

- **Power On:** Press and hold the Power button for a few seconds until the indicator light turns on and the projector starts up.
- **Power Off:** Press and hold the Power button again until the projector shuts down.

6.2. Initial Setup (Android 4.4)

Upon first power-on, you may be guided through an initial setup process for the Android 4.4 operating system. Follow the on-screen prompts to configure language, time zone, and network settings.

6.3. Focus Adjustment

Rotate the focus ring (if present, typically near the lens) until the projected image appears clear and sharp.

6.4. Input Source Selection

Navigate the projector's menu to select the desired input source (e.g., HDMI, USB, or internal Android system for streaming/apps).

6.5. Wireless Connectivity (Wi-Fi)

1. From the Android home screen, navigate to *Settings*.
2. Select *Wi-Fi* and turn it on.
3. Choose your desired network from the list and enter the password if prompted.
4. Once connected, you can access online content, stream, or mirror compatible devices.

6.6. Media Playback

- **USB Playback:** Insert a USB drive. The projector's file manager should automatically open or be accessible from the main menu. Select your desired video (MP4), audio (MP3), or picture (JPEG) files.

- **Screen Mirroring:** The projector supports mirroring your phone's display. Consult your phone's manual for screen mirroring instructions (e.g., Miracast, AirPlay, or similar features).

7. MAINTENANCE

7.1. Cleaning the Projector

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners or excessive force.
- **Casing:** Wipe the exterior with a soft, dry cloth. For stubborn marks, dampen the cloth slightly with water, then wipe dry. Avoid harsh chemicals.
- **Ventilation:** Periodically check and gently clean the ventilation grilles to prevent dust buildup, which can affect performance and lifespan. Use a soft brush or compressed air.

7.2. Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to use the original packaging for storage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image projected	Power not connected; Projector off; Incorrect input source; Lens cap on.	Ensure power is connected and unit is on. Select correct input source. Remove lens cap.
Image is blurry	Focus not adjusted; Projector too far/close.	Adjust the focus ring. Adjust projection distance.
No sound	Volume too low; External device volume low; Audio format not supported.	Increase projector volume. Increase source device volume. Ensure audio format is MP3.
Cannot connect to Wi-Fi	Incorrect password; Out of range; Network issue.	Verify password. Move closer to router. Restart router and projector.

9. SPECIFICATIONS

Feature	Detail
Brand	DOOGEE
Model	P1
Projection Technology	DLP
Native Resolution	FWVGA (854x480)
Supported Resolution	720P (1280x720)

Feature	Detail
Operating System	Android 4.4
Brightness	70 Lumens
Aspect Ratio	16:9
Contrast Ratio	800:1
Projection Screen Size	Up to 100 inches
Projection Distance	Approx. 3.3 meters for 100 inches
Lamp Type	LED
Lamp Life	30,000 Hours
Connectivity	USB, HDMI, 2.4GHz WiFi
Built-in Battery	4800mAh
Power Consumption	10W
Net Weight	0.29 kg
Dimensions	34.01 x 26.01 x 11.99 cm

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official DOOGEE website. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: LightInTheBox

Model Number: 3633581

© 2024 DOOGEE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01EJ9RZ64>

More documents and user manuals: <https://manuals.plus/>