



[Manuals.plus](#) /

› [XP METAL DETECTORS](#) /

› XP Metal Detectors Silicone Protection for Deus and ORX Remote Control User Manual

XP METAL DETECTORS 3665994002385

XP Metal Detectors Silicone Protection for Deus and ORX Remote Control User Manual

Model: D08CASE2 / 3665994002385

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides essential information for the proper use and maintenance of your XP Metal Detectors Silicone Protection case, designed specifically for the Deus and ORX remote controls. This silicone case offers a protective layer against everyday wear and tear, dirt, and minor impacts, helping to preserve the longevity and appearance of your valuable metal detector remote control.



Figure 1: The XP Metal Detectors Silicone Protection case. This clear silicone cover is designed to fit snugly over the Deus and ORX remote controls, providing a protective barrier while allowing full access to controls and screen visibility.

2. SETUP AND INSTALLATION

Installing the silicone protection case is a straightforward process. Ensure your remote control is clean and free of debris before installation.

- 1. Prepare the Remote Control:** Ensure the XP Deus or ORX remote control is powered off and clean. Remove any existing dust or dirt from the surface.
- 2. Align the Case:** Carefully align the silicone case with the remote control. The case is designed to fit precisely, with cutouts for buttons, screen, and ports.
- 3. Gently Apply:** Starting from one end, gently stretch the silicone case over the remote control. Work your way around, ensuring all edges and corners are properly seated within the case. It may feel tight, which is normal for a secure fit.
- 4. Check for Proper Fit:** Once installed, ensure that all buttons are accessible and responsive, and the screen is clearly visible through the silicone. Verify that no parts of the remote control are pinched or misaligned.



Figure 2: Front view of the silicone case properly installed on an XP Deus remote control. Note the clear visibility of the screen and accessibility of the control buttons.



Figure 3: Back view of the silicone case installed on an XP Deus remote control, showing the precise cutouts for the battery compartment and other features.

3. OPERATING INSTRUCTIONS

The silicone case is designed to protect your remote control without impeding its functionality. You can operate your Deus or ORX remote control as usual with the case installed.

- **Button Access:** The case features molded button covers that allow full tactile feedback and access to all remote control functions.
- **Screen Visibility:** The clear silicone material is designed to maintain screen visibility. In some bright light conditions or with polarized sunglasses, minor glare or reduced clarity may be experienced. Adjust the screen angle or backlight settings on your remote control if needed.
- **Port Access:** All necessary ports for charging and connecting accessories remain accessible through precise cutouts in the case.

Important Note:

- This silicone case provides protection against dust, dirt, and minor splashes. It is **not** designed for underwater

use and does not make the remote control waterproof.

- Keep away from water. Do not expose to static electricity.

4. MAINTENANCE

Regular cleaning of your silicone case will help maintain its appearance and protective qualities.

- **Cleaning:** To clean the silicone case, remove it from the remote control. Wash it with mild soap and water. Rinse thoroughly and allow it to air dry completely before re-installing.
- **Dirt Adherence:** Silicone can attract dust and lint. Regular cleaning will mitigate this.
- **Storage:** When not in use, store the case in a clean, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

Issue	Possible Cause	Solution
Screen difficult to read through case.	Glare from bright light, polarized sunglasses, or slight haziness of silicone.	Adjust the angle of the remote control. Increase screen backlight on the remote. Clean the case and remote screen thoroughly.
Dirt or lint sticking to the case.	Static electricity or environmental dust.	Remove the case and wash with mild soap and water. Ensure it is completely dry before re-installing. Avoid highly dusty environments if possible.
Case feels too tight or difficult to install.	New silicone can be stiff; improper alignment.	Ensure correct alignment before applying force. Gently stretch the silicone over the remote, working from one end. The tight fit is intentional for secure protection.

6. SPECIFICATIONS

Feature	Detail
Product Name	Silicone Protection for Deus and ORX Remote Control
Brand	XP METAL DETECTORS
Model Number	D08CASE2 / 3665994002385
Material	Silicone
Color	Clear
Dimensions (L x W x H)	4.5 x 2.5 x 0.5 inches (approximate, for the case itself)
Item Weight	0.8 ounces
Compatibility	XP Deus and XP ORX Remote Controls
Protection Rating	IP44 (Protection against solid objects greater than 1mm and splashing water from any direction)

7. WARRANTY AND SUPPORT

XP Metal Detectors products are manufactured to high standards. While specific warranty details for accessories like this silicone case may vary, XP Metal Detectors generally offers a 5-year warranty on their main detector components. For any questions regarding your silicone protection case, including warranty claims or product support, please contact XP Metal Detectors customer service directly or visit their official website.

You can find contact information and further resources on the official XP Metal Detectors website:

www.xpmetaldetectors.com

© 2025 XP METAL DETECTORS. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.