

BONTEC B01ESPXJW

BONTEC Table Top Desk Pedestal TV Stand Mount User Manual

Model: B01ESPXJW

1. INTRODUCTION

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your BONTEC Table Top Desk Pedestal TV Stand Mount. Please read this manual thoroughly before installation to ensure correct setup and safe operation. Keep this manual for future reference.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 50kg (110 lbs). This stand is designed for TVs between 32 and 60 inches.
- **VESA Compatibility:** Ensure your TV's VESA mounting pattern is compatible with this stand (refer to specifications).
- **Secure Installation:** Always ensure all screws and bolts are securely tightened before placing the TV on the stand.
- **Surface Stability:** Place the stand on a stable, level, and sturdy surface that can support the combined weight of the stand and your television.
- **Children and Pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- **Professional Assistance:** If you are unsure about any part of the installation process, consult a qualified professional.

3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before assembly. If any parts are missing or damaged, contact BONTEC customer support.

- Base Plate
- Upright Support Column

- TV Mounting Brackets (2 pieces)
- Hardware Kit (various screws, washers, spacers, Allen wrench, spanner)
- Anti-slip Pads

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your TV stand.

Step 4.1: Attach Anti-slip Pads to the Base

Peel and stick the provided anti-slip pads to the bottom of the base plate. This prevents scratching your furniture and provides stability.

Step 4.2: Assemble the Upright Support Column to the Base

Secure the upright support column to the base plate using the designated screws and tools from the hardware kit. Ensure it is firmly attached and stable.

Step 4.3: Attach TV Mounting Brackets to Your TV

Identify the VESA mounting holes on the back of your television. Select the appropriate screws, washers, and spacers from the hardware kit that fit your TV's specific VESA pattern. Attach the two TV mounting brackets to the back of your TV. Ensure they are level and securely fastened.

Enhance Your Viewing Experience



Figure 4.3.1: This image illustrates the VESA compatibility (50x50mm to 800x400mm) and screen size range (22-65 inches) supported by the stand, with a maximum capacity of 50kg. It helps in selecting the correct mounting hardware for your TV.



Figure 4.3.2: This image displays two installation options for the TV mounting brackets: one for larger TVs (Max VESA: 800x400mm) and another for smaller TVs (Max VESA: 400x200mm). It also provides detailed dimensions of the stand, including height and width, to aid in proper setup.

Step 4.4: Mount the TV onto the Stand

Carefully lift your TV with the attached brackets and hook them onto the upright support column. Ensure the brackets are properly seated and secured. The stand offers multiple height adjustment levels.

Keep Your TV Securely Upright



Figure 4.4.1: This image demonstrates the three adjustable height levels of the TV stand: Maximum (700mm), Mid (640mm), and Minimum (580mm). This allows users to customize the TV's viewing height.

Various Features



Detachable



Easy Installation



Anti-slip Pads



Figure 4.4.2: This image compares the stability of the BONTEC stand, showing a TV securely upright, against another stand that appears unstable. It highlights the design's focus on keeping your TV safely in position.




Figure 4.4.3: This image details key features of the stand, including its detachable components for easier assembly, the straightforward installation process, and the inclusion of anti-slip pads on the base for enhanced stability and surface protection.

5. OPERATING INSTRUCTIONS

Once assembled, the BONTEC TV stand is designed for fixed placement. The primary operation involves adjusting the TV's height during initial setup.

5.1 Height Adjustment

The stand offers three distinct height levels. To adjust the height:

1. Carefully remove the TV from the mounting brackets.
2. Adjust the position of the mounting brackets on the upright support column to your desired height level (Max, Mid, or Min).
3. Re-mount the TV onto the adjusted brackets, ensuring it is securely locked in place.

Always ensure the TV is balanced and stable after any height adjustment.

6. MAINTENANCE

Regular maintenance ensures the longevity and safety of your TV stand.

- **Cleaning:** Wipe the stand with a soft, dry cloth. Avoid abrasive cleaners or solvents that may damage the finish.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary.
- **Inspect for Damage:** Regularly inspect the stand for any signs of wear, damage, or instability. If damage is found, discontinue use and contact customer support.

7. TROUBLESHOOTING

If you encounter issues with your TV stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
TV is unstable or wobbles	Loose screws; uneven surface; TV too heavy; incorrect assembly	Ensure all screws are tightened. Place stand on a level surface. Verify TV weight is within limits. Review assembly steps.
TV does not fit the stand	Incorrect VESA pattern; TV size outside range	Check your TV's VESA pattern against the stand's specifications. Confirm TV size is between 32-60 inches.
Missing parts	Packaging error	Contact BONTEC customer support with your purchase details.

8. SPECIFICATIONS

- **Brand:** BONTEC
- **Model:** B01ESPXJW
- **Mounting Type:** Tabletop Mount
- **Movement Type:** Fixed (Height adjustable during assembly)
- **Compatible Devices:** Television
- **Minimum Supported Screen Size:** 32 Inches
- **Maximum Supported Screen Size:** 60 Inches (Note: Some users report compatibility with up to 65 inches, but official specification is 60 inches)
- **Maximum Weight Capacity:** 50 kg (110 lbs)
- **Item Weight:** 1.9 Kilograms
- **VESA Compatibility:** 50x50mm, 75x75mm, 100x100mm, 200x100mm, 200x200mm, 300x200mm, 300x300mm, 400x200mm, 400x300mm, 400x400mm, 600x400mm, 800x400mm
- **Adjustable Height Levels:** 3 levels (Max 700mm, Mid 640mm, Min 580mm from base to top of bracket)

9. WARRANTY AND SUPPORT

BONTEC products are manufactured to high-quality standards. For warranty information, technical support, or to report missing/damaged parts, please contact BONTEC customer service through the retailer where the

product was purchased or visit the official BONTEC website. Please have your model number (B01ESPXJW) and purchase date ready.

© 2024 BONTEC. All rights reserved.