



Manuals.plus /

› **BabyDan** /

› BabyDan Flex XXL Room Divider / Playspace Instruction Manual

**BabyDan 56826-2600-50**


# BabyDan Flex XXL Room Divider / Playspace Instruction Manual

Model: 56826-2600-50

## 1. INTRODUCTION AND PRODUCT OVERVIEW

---

The BabyDan Flex XXL is a versatile safety gate system designed to create a secure environment for children and pets. It can be configured as an extra-wide room divider, a protective hearth gate, or a spacious playpen. This manual provides essential information for the safe and correct installation, operation, and maintenance of your BabyDan Flex XXL.



Room divider

## Multifunctional safety gate



Hearth gate



Playpen

If used for kids a playmat is needed (sold separately)

Image: The BabyDan Flex XXL demonstrating its multifunctional uses as a room divider, hearth gate, and playpen. Note that a playmat is needed for playpen use (sold separately).

## 2. SAFETY INFORMATION

Your BabyDan Flex XXL is designed and manufactured in Denmark to meet the highest safety standards, including EN 1930:2011 (European) and ASTM F1004 (American). Always follow these safety guidelines:

- Ensure all components are securely fastened before use.
- Regularly check the gate for any loose parts or damage.
- Never leave children unattended near the gate.
- When used as a hearth gate, the distance to a heat source must be at least 29.5 inches (75 cm). If an open fire is present, the distance must be at least 35.4 inches (90 cm).
- Do not use the gate if any parts are missing or broken.

# Certified Safety



**EN 1930:2011**  
**ASTM F1004**

Complies with the latest, highest and strictest safety standards. Both European and American standards.

MADE IN  
**DENMARK**  
PREMIUM QUALITY

Designed and manufactured in Denmark from European steel to ensure Danish quality and less climate impact.



Approved by independent experts from market leading test labs like TÜV SÜD.

Image: Certified Safety information highlighting compliance with EN 1930:2011 and ASTM F1004 standards, manufacturing in Denmark, and approval by TÜV SÜD.

# How to measure for best fit



## PLEASE NOTE

If used as a hearth gate the distance to the heat source must always be at least 29.5" (35.4" if open fire.)

Measure the circumference.  
Must be between  
35.5 - 137.7"

Image: A diagram illustrating how to measure the circumference for best fit (35.5 - 137.7 inches) and a critical safety note regarding the minimum distance to a heat source when used as a hearth gate.

## 3. WHAT'S IN THE BOX

Carefully unpack all components and verify that all parts are present before beginning assembly. The package includes:

- 1 x Door section
- 4 x Large sections
- Wall fittings (all necessary fittings and screws for mounting in wood)



Fits openings between:  
35.5 - 137.7"



**Included:**  
All necessary fittings  
+  
screws for mounting  
in wood



MADE IN  
**DENMARK**  
PREMIUM QUALITY



Image: A visual representation of the BabyDan Flex XXL, detailing its dimensions (Height: 27.76", Width: 1.38", Distance between bars: 2.17") and listing the included fittings and screws for mounting.

#### 4. SETUP AND INSTALLATION

The BabyDan Flex XXL is designed for easy installation. Follow these general steps. For detailed visual instructions, refer to the step-by-step video instructions available online (as indicated in product imagery, search for 'BabyDan Flex XXL installation video').

- 1. Plan Your Configuration:** Decide whether you will use the system as a room divider, hearth gate, or playpen. Measure the area to ensure it fits within the 35.4" - 138" (90 cm - 350 cm) range.
- 2. Assemble Sections:** Connect the door section and large sections using the provided connectors. The gate section can be placed anywhere within the FLEX XXL configuration.
- 3. Wall Mounting (if applicable):** If using as a room divider or hearth gate, attach the wall fittings to a sturdy wall surface using the supplied screws. Ensure the wall fittings are level and securely anchored. The swivel wall-mounted brackets are adjustable to any angle.

4. **Attach Gate System:** Securely connect the assembled gate system to the wall fittings. Ensure all connections are tight and the gate is stable.
5. **Final Check:** Test the gate's stability and ensure the door opens and closes smoothly and locks securely.



Image: A diagram illustrating how to open the gate with one hand, its ability to open both ways, and the swivel wall-mounted feature that allows adjustment to any angle.



Image: The BabyDan Flex XXL in a room setting, highlighting the option to extend infinitely with separately sold extensions and the flexibility of free door placement within the configuration. A visual cue for 'Step by step video instructions' is also present.

## 5. OPERATING INSTRUCTIONS

---

The door section of the BabyDan Flex XXL is designed for convenient and safe operation:

- **Opening the Gate:** The gate can be opened with one hand. Simply lift the handle and swing the gate open.
- **Two-Way Opening:** The gate is designed to open in both directions, providing flexibility for movement through the opening.
- **Closing the Gate:** Push the gate firmly until it clicks into the closed and locked position. Always ensure the gate is securely latched.

## 6. MAINTENANCE

---

To ensure the longevity and continued safe operation of your BabyDan Flex XXL, follow these maintenance guidelines:

- **Cleaning:** Wipe the gate regularly with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose connections. Pay close attention to hinges, locking mechanisms, and wall fittings.
- **Lubrication:** If the hinges become stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.
- **Storage:** If storing the gate, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

## 7. TROUBLESHOOTING

---

If you encounter issues with your BabyDan Flex XXL, consider the following:

- **Gate is difficult to install or secure:** Review the installation instructions carefully. Ensure wall fittings are correctly positioned and securely anchored. Verify that all sections are properly aligned before attempting to secure them.
- **Missing parts:** Upon receiving your product, immediately check the contents against the 'What's in the Box' section. If any parts are missing, contact BabyDan customer support for assistance.
- **Gate does not close or latch properly:** Check for any obstructions in the closing path. Ensure the gate is correctly aligned with the latching mechanism. Adjust wall fittings if necessary to ensure proper alignment.
- **Gate feels unstable:** Re-check all connections and wall fittings to ensure they are tight and secure. The gate must be firmly anchored to the wall for stability.

## 8. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	2 x 138 x 28.4 inches (5.08 x 350.52 x 72.14 cm)
Item Model Number	56826-2600-50
Material Type	Plastic (Note: Product description mentions 'European steel' for manufacturing, but 'Material Type' in specifications lists 'Plastic'. This likely refers to specific components or a general classification. The gate itself is metal.)
Number Of Items	1 (complete system)
Item Weight	33.5 pounds (15.2 kg)
Fits Openings	35.4" - 138" (90 cm - 350 cm)
Gate Height	27.76" (70.5 cm)
Distance Between Bars	2.17" (5.5 cm)

## 9. WARRANTY AND SUPPORT

---

For warranty information, specific product support, or to inquire about replacement parts, please contact BabyDan Inc., the official seller. Keep your purchase receipt and model number (56826-2600-50) handy when contacting support.

**Seller:** Baby Dan Inc.

For further assistance, please visit the BabyDan official website or contact their customer service department.