

[Manuals.plus](#) /

› [Lighting EVER](#) /

› Lighting EVER 594 LED Curtain Lights, 20 x 10 ft Plug in Hanging Fairy String Lights, Wedding Party Backdrop Lights, Window Twinkle Lights for Wall, Patio, NOT Connectable (27 Strings, 9" Apart) Warm White 19.7 ft

Lighting EVER N4300011-WW-US

Lighting EVER 594 LED Curtain Lights

Model: N4300011-WW-US

Brand: Lighting EVER

INTRODUCTION

The Lighting EVER 594 LED Curtain Lights are designed to create a warm and festive ambiance for various indoor settings. These 20 x 10 ft fairy string lights feature 27 vertical strings, each with numerous LEDs, providing extensive coverage for backdrops, walls, patios, and more. They offer multiple lighting patterns and a convenient memory function to recall your preferred setting.

SAFETY INFORMATION

- Ensure the product is used with the provided ETL Certified transformer (30 V DC, 300 mA) or an equivalent from a reputable manufacturer.
- Do not cut the curtain lights to a smaller size. If strands are too long, tie them shorter with packing ties.
- This product is designed for indoor use. While the light strings are waterproof, the power supply should be kept off the ground and in a sheltered area if used outdoors to prolong service life.
- Keep away from heat sources and open flames.
- Unplug the lights from the power source before cleaning or maintenance.

PACKAGE CONTENTS

- 1 x 20x10ft 594 LED Curtain Lights
- 1 x UL Certified Transformer with Standard US Plug
- 1 x User Manual (this document)

SETUP INSTRUCTIONS

1. **Unpacking:** Carefully remove the curtain lights from the packaging. The strands are neatly bundled to prevent tangling.

2. **Crucial Tip for Installation:** It is highly recommended to hang the main horizontal string of the lights in your desired location *before* untangling or unbundling the individual vertical strands. This will significantly reduce the risk of tangling.
3. **Hanging:** Secure the main horizontal string across your chosen area (e.g., wall, pergola, ceiling). Ensure it is evenly supported.
4. **Untangling Strands:** Once the main string is securely hung, gently unbundle and release each vertical string one by one. Allow them to hang freely. If a strand is too long, you can use the provided packing ties to shorten it by tying it up.
5. **Power Connection:** Connect the lights to the UL Certified transformer. Plug the transformer into a standard US power outlet.




Image: Curtain lights installed on a pergola, demonstrating their use in an outdoor setting.



Image: Diagram illustrating the dimensions and structure of the curtain lights, highlighting the 27 strands and 9-inch spacing.

OPERATING INSTRUCTIONS

The Lighting EVER curtain lights feature 8 different lighting patterns, controlled by a button on the adapter.

1. **Power On/Off:** Plug the adapter into a power outlet to turn the lights on. Unplug to turn them off.
2. **Changing Lighting Patterns:** Press the button located on the adapter to cycle through the 8 available lighting modes. These modes include: Steady On, In Waves, Sequential, Twinkle, Slow Fade, Slo Glo, Combination, and Flashing.
3. **Memory Function:** The lights are equipped with a convenient memory function that remembers your last selected lighting pattern. When you turn the lights back on, they will resume the previously chosen mode.



Image: Curtain lights illuminating a living room wall, showcasing their decorative effect.



Image: Curtain lights used to decorate a gazebo, suitable for parties or events.



Image: Curtain lights enhancing a bedroom's decor, providing ambient lighting.



Image: Curtain lights used for event decoration, draped across a ceiling and walls.

Close-spaced & ETL Listed

Note: DO NOT cut these curtain lights to a smaller size




Image: String lights installed on a covered patio ceiling, providing overhead illumination.

MAINTENANCE

- **Cleaning:** Disconnect from power. Gently wipe the lights with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully gather each vertical string and re-bundle them to prevent tangling. Store the lights in their original packaging or a suitable container in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the wires and LEDs for any damage. Do not use if any part is damaged.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty adapter.	Check if the adapter is securely plugged into a working outlet. Ensure all connections are firm. Try a different outlet.

Problem	Possible Cause	Solution
Some LEDs are not lit.	Individual LED failure (rare), wire damage.	These are LED lights, so individual bulb replacement is not typically possible. If a section is out, inspect the wiring for visible damage. If significant, contact support.
Lights are tangled during setup.	Vertical strands unbundled before hanging main string.	Carefully untangle each strand one by one. For future installations, always hang the main horizontal string first before releasing the vertical strands.

SPECIFICATIONS

- Model:** N4300011-WW-US
- Light Source:** LED
- Number of LEDs:** 594
- Dimensions:** 20 ft (width) x 10 ft (drop)
- Vertical Strings:** 27 strings, 9 inches apart
- Color:** Warm White
- Color Temperature:** 3000 Kelvin
- Voltage:** 29 Volts (DC)
- Wattage:** 6 watts
- Power Source:** Corded Electric
- Controller Type:** Button Control (on adapter)
- Lighting Modes:** 8 (Steady On, In Waves, Sequential, Twinkle, Slow Fade, Slo Glo, Combination, Flashing)
- Water Resistance Level:** Waterproof (lights only, adapter needs shelter)
- Indoor/Outdoor Usage:** Indoor (Power adapter requires shelter for outdoor use)
- Certification:** UL Certified Power Adapter
- Not Connectable:** These lights are not designed to be connected to other sets.

WARRANTY & SUPPORT

This Lighting EVER product comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact Lighting EVER customer service. Refer to the contact information provided on the product packaging or visit the official Lighting EVER website. You can also find additional information and support resources on the [Lighting EVER Store on Amazon](#).

A PDF User Guide is also available for download: [User Guide \(PDF\)](#)

PRODUCT VIDEOS

No official product videos from the seller are available in the provided data.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question