

ANJAYLIA 001WW

ANJAYLIA LED Fairy String Lights (Model 001WW)

Instruction Manual

INTRODUCTION

Thank you for choosing ANJAYLIA LED Fairy String Lights. This manual provides essential information for the safe and effective use of your new lights. These 10-foot (3-meter) string lights feature 30 warm white LEDs on an ultra-thin copper wire, designed for various decorative applications. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- The battery box is **not waterproof**. To prevent damage and ensure safety, keep the battery box away from water and moisture.
- Use only 3 AA batteries (not included). Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the product is not used for an extended period.
- Do not attempt to modify or repair the lights. Contact customer support if issues arise.
- Keep out of reach of small children to prevent choking hazards from small parts.

PACKAGE CONTENTS

Your package should contain the following:

- 1 x ANJAYLIA LED Fairy String Lights (10ft/3M, 30 Warm White LEDs)

Note: 3 AA batteries are required and are **not included** in the package.


SETUP

1. **Install Batteries:** Open the battery compartment on the battery box. Insert 3 new AA batteries, ensuring correct polarity (+/-). Close the battery compartment securely.

- 2. Placement:** Uncoil the string lights carefully. The ultra-thin copper wire is flexible and can be easily bent and shaped. Place the lights in your desired location, such as wrapping around plants, signs, furniture, or inside decorative items like jars and cloches.
- 3. Secure Position:** Ensure the lights are securely placed to prevent accidental dislodgement.



Image: Coiled ANJAYLIA LED Fairy String Lights. The lights are shown in a compact, coiled form, highlighting their flexible wire design.



Bendable,
Sturdy, and
Submersible.

Image: Close-up of ANJAYLIA LED Fairy String Lights. This image provides a detailed view of the small LED bulbs on the thin copper wire, demonstrating their delicate appearance.

OPERATING INSTRUCTIONS

To operate the ANJAYLIA LED Fairy String Lights:

- Locate the ON/OFF switch on the battery box.
- Slide the switch to the **ON** position to illuminate the lights.
- Slide the switch to the **OFF** position to turn off the lights.

This model does not include a remote control or timer function.

Video: ANJAYLIA Fairy String Lights Battery Operated. This video demonstrates the lights in various decorative settings, showcasing their warm glow and flexibility for different applications.

MAINTENANCE

- **Battery Replacement:** When the lights dim or stop working, replace all 3 AA batteries with new ones. Ensure correct polarity.
- **Cleaning:** Gently wipe the lights and battery box with a dry, soft cloth. Do not use liquid cleaners or

immerse any part of the product in water.

- **Storage:** When not in use, store the lights in a cool, dry place, away from direct sunlight and moisture. Remove batteries before long-term storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Lights are dim.	Batteries are low.	Replace batteries with new ones.
Lights flicker.	Loose battery connection or low battery power.	Check battery connection or replace batteries.

SPECIFICATIONS

Feature	Detail
Model Number	001WW
Brand	ANJAYLIA
Light Color	Warm White
Number of LEDs	30
String Length	10 Feet (3 Meters)
Power Source	3 x AA Batteries (not included)
Indoor/Outdoor Usage	Indoor, Outdoor (battery box not waterproof)
Special Feature	Cordless, Flexible Wire
Material	Plastic, Copper Wire
Color Temperature	3000 Kelvin
Wattage	3 watts
Item Weight	0.71 ounces (20 Grams)
Control Method	Manual Switch

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the retailer's return policy or contact the seller directly through your purchase platform. Keep your purchase receipt as proof of purchase.

