

Evolveo EP-600-XDL

Evolveo easyphone XD Mobile Phone User Manual

Model: EP-600-XDL

1. INTRODUCTION

Welcome to the user manual for your Evolveo easyphone XD. This mobile phone is designed for ease of use, particularly for seniors, featuring large keys, a clear display, and essential functions including an SOS button for emergencies. Please read this manual carefully to ensure proper operation and maintenance of your device.

2. PRODUCT OVERVIEW

The Evolveo easyphone XD is a straightforward mobile phone with a focus on accessibility. It includes a charging stand for convenient power replenishment and a dedicated SOS button for quick assistance.



Figure 2.1: Front view of the Evolveo easyphone XD in its charging dock. The phone features a color screen, large numeric keypad, and dedicated function buttons for calls, navigation, and memory presets (M1, M2, M3).



Figure 2.2: Angled view of the phone, showcasing the ergonomic design and the clear layout of the large buttons, including call, end call, and navigation keys.







Figure 2.3: Rear view of the Evolveo easyphone XD. This image displays the integrated camera lens, the loud speaker grille, and the prominent SOS button, designed for emergency use.

3. SETUP

3.1. Inserting the SIM Card and Battery

1. Carefully remove the back cover of the phone.
2. Insert your SIM card into the designated slot. Ensure the gold contacts face downwards and the card is correctly oriented.
3. Insert the battery, aligning the contacts with those in the phone.
4. Replace the back cover until it clicks securely into place.

3.2. Charging the Phone

Before first use, fully charge the phone battery.

- Connect the charging adapter to the charging stand.
- Place the phone into the charging stand, ensuring it sits correctly and the charging indicator appears on the screen.
- Alternatively, you can connect the charging cable directly to the phone's USB port.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- To power on: Press and hold the red **End Call/Power** button until the screen lights up.
- To power off: Press and hold the red **End Call/Power** button until the power off option appears, then confirm.

4.2. Making and Receiving Calls

- **To make a call:** Dial the number using the large numeric keypad and press the green **Call** button.
- **To answer a call:** Press the green **Call** button when the phone rings.
- **To end a call:** Press the red **End Call** button.

4.3. SOS Function

The SOS button is located on the back of the phone. In an emergency, press and hold this button for a few seconds. The phone will automatically dial pre-set emergency contacts and send an SOS message.

- **Setting SOS contacts:** Navigate to the SOS settings in the phone menu to add up to three emergency numbers.

4.4. Memory Keys (M1, M2, M3)

The M1, M2, and M3 buttons are speed dial keys. You can assign frequently called numbers to these

buttons.

- **To program:** Go to the phone's settings, find the 'Speed Dial' or 'Memory Keys' option, and assign contacts to M1, M2, and M3.
- **To use:** Simply press and hold the desired memory key (M1, M2, or M3) to dial the assigned number.

4.5. FM Radio

The phone includes an FM radio. To use it, ensure headphones are connected as they act as the antenna.

- Navigate to the 'FM Radio' option in the main menu.
- Use the navigation keys to scan for stations and adjust volume.

4.6. Camera

The phone features a basic camera for taking photos.

- Access the camera from the main menu.
- Use the central navigation key to take a picture.
- Photos are saved to the phone's memory or an inserted MicroSDHC card.

4.7. Bluetooth

The phone supports Bluetooth for connecting to compatible devices like headsets.

- Go to 'Settings' > 'Bluetooth'.
- Turn Bluetooth on and search for available devices.
- Select the device you wish to pair with and follow the on-screen prompts.

5. MAINTENANCE

- Keep the phone dry. Moisture can damage electronic circuits.
- Do not expose the phone to extreme temperatures.
- Clean the phone with a soft, dry cloth. Avoid using harsh chemicals.
- Handle the battery with care. Do not puncture or expose to fire.

6. TROUBLESHOOTING

Problem	Possible Solution
Phone does not power on	Ensure the battery is charged. Check if the battery is correctly inserted.
Cannot make or receive calls	Check if the SIM card is properly inserted and active. Verify network signal strength.
SOS button not working	Ensure SOS contacts are programmed in the settings. Check if the button is physically obstructed.
Poor audio quality	Check volume settings. Ensure the speaker/microphone is not blocked.

7. SPECIFICATIONS





Feature	Detail
Brand	Evolveo
Model Name	EP 600 XDL
Model Number	EP-600-XDL
Color	Blue/Silver
Product Type	Bar Phone
Operating System	EVOLVEO
Screen Size	2.3 Inches
Connectivity	Bluetooth, USB
Cellular Technology	2G
Camera Resolution	1.3 Megapixels
Special Features	3 special keys, Camera, Bluetooth, Easy to use, Large keys, MicroSDHC support, FM Radio, Charging stand, Color screen
Battery Composition	Lithium-polymer
Memory Storage Capacity	1 GB

8. WARRANTY AND SUPPORT

Your Evolveo easyphone XD is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support or service inquiries, please contact your retailer or visit the official Evolveo website for contact information.

Related Documents - EP-600-XDL

<p>MANUAL EVOLVEO MODEL VERSION / DATE EasyPhone ID III. / 30. 7. 2024</p> 	<p>EVOLVEO EasyPhone ID Felhasználói Kézikönyv</p> <p>Részletes felhasználói kézikönyv az EVOLVEO EasyPhone ID mobiltelefonhoz, amely lefedi a beállítást, funkciókat, biztonsági figyelmeztetéseket, karbantartást és garanciális információkat.</p>
<p>MANUAL EVOLVEO MODEL VERSION / DATE EasyPhone XG II. / 18. 3. 2022</p> 	<p>Manual de utilizare EVOLVEO EasyPhone XG</p> <p>Ghid complet pentru telefonul mobil EVOLVEO EasyPhone XG. Descoperiți instrucțiuni detaliate despre funcții, setări, apeluri, mesaje, multimedia, SOS și conectivitate.</p>

<div><div>MANUAL</div><div>EVOLVEO</div><div>MODEL VERSION / DATE</div><div>EasyPhone 11. / 12. 11. 2025</div></div> <div></div> <div><div>CZ</div><div>SK</div><div>EN</div><div>HU</div><div>RO</div><div>SI</div><div>BG</div></div>	<p>EVOLVEO EasyPhone Návod k použití</p> <p>Kompletní návod k použití pro mobilní telefon EVOLVEO EasyPhone, včetně informací o funkcích, nastavení a řešení problémů.</p>
<div><div>MANUAL</div><div>EVOLVEO</div><div>MODEL VERSION / DATE</div><div>ACSALMBTZ 1. / 25. 3. 2022</div></div> <div></div> <div><div>CZ</div><div>SK</div><div>EN</div><div>HU</div><div>RO</div><div>SI</div></div>	<p>EVOLVEO Alarmex Pro ACSALMBTZ Wireless SOS Button/Doorbell User Manual</p> <p>User manual for the EVOLVEO Alarmex Pro ACSALMBTZ wireless SOS button and doorbell. Features include SOS signaling, doorbell functionality, and compatibility with EVOLVEO Alarmex Pro WiFi/GSM alarms. Specifications, warranty, and disposal information included.</p>
<div><div>MANUAL</div><div>EVOLVEO</div><div>MODEL VERSION / DATE</div><div>EasyPhone XS 1. / 9. 1. 2025</div></div> <div></div> <div><div>CZ</div><div>SK</div><div>EN</div><div>HU</div><div>RO</div><div>SI</div><div>BG</div><div>GR</div></div>	<p>EVOLVEO EasyPhone XS Uživatelský manuál</p> <p>Kompletní uživatelský manuál pro mobilní telefon EVOLVEO EasyPhone XS. Obsahuje informace o bezpečnosti, obsluze, funkcích a údržbě.</p>
<div><div>MANUAL</div><div>EVOLVEO</div><div>MODEL VERSION / DATE</div><div>FX 450 / 500 / 550 / V. / 22. 8. 2025</div><div>FX 650 / 750</div></div> <div></div> <div><div>CZ</div><div>SK</div><div>EN</div></div>	<p>EVOLVEO FX Gaming Power Supply Manual</p> <p>User manual for EVOLVEO FX series gaming power supplies, covering installation, features, safety precautions, and disposal information.</p>