JBL JBLCLIP2BLKAM

JBL Clip 2 Portable Waterproof Bluetooth Speaker User Manual

Model: JBLCLIP2BLKAM

INTRODUCTION

The JBL Clip 2 is an ultra-light, ultra-rugged, and ultra-powerful portable speaker designed for on-the-go audio. Its waterproof design and integrated carabiner make it an ideal companion for various activities, whether indoors or outdoors. This manual will guide you through the setup, operation, and maintenance of your JBL Clip 2 speaker.

WHAT'S IN THE BOX

- 1 x JBL Clip 2 Speaker
- 1 x Micro USB cable for charging
- 1 x Quick start guide
- 1 x Safety sheet
- 1 x Warranty card

PRODUCT OVERVIEW

Figure 1: Front view of the JBL Clip 2 speaker, highlighting its integrated 3.5mm audio cable and carabiner clip.

Figure 2: The JBL Clip 2 speaker positioned next to a smartphone, illustrating its compact form factor and readiness for wireless connection.

Setup

1. Charging the Speaker

Before first use, fully charge your JBL Clip 2. Connect the provided Micro USB cable to the charging port on the speaker and to a USB power source. The LED indicator will show charging status. A full charge takes approximately 2.5 hours.

2. Power On/Off

Press the power button located on the side of the speaker to turn it on or off. You will hear an audible tone indicating the power status.

3. Bluetooth Pairing

1. Turn on your JBL Clip 2 speaker.
2. Press the Bluetooth button on the speaker. The LED indicator will flash blue, indicating it's in pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings and select "JBL Clip 2" from the list of available devices.
4. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation tone.

Video 1: This video demonstrates how to power on the JBL Clip 2 speaker and initiate Bluetooth pairing with a mobile device. It shows the location of the power and Bluetooth buttons and the visual cues for successful connection.

4. Wired Connection (Auxiliary Input)

The JBL Clip 2 features an integrated 3.5mm audio cable. Unwind the cable from its storage slot on the back of the speaker and plug it into the headphone jack of your audio device. The speaker will automatically switch to auxiliary input mode.

Video 2: This video provides a detailed look at the various ports and buttons on the JBL Clip 2, including the integrated 3.5mm audio cable and the charging port.

OPERATING THE SPEAKER

1. Music Playback and Volume Control

Once connected via Bluetooth or auxiliary cable, you can control music playback and volume directly from your connected device or using the dedicated buttons on the JBL Clip 2. Use the '+' button to increase volume and the '-' button to decrease volume.

2. Speakerphone Functionality

The JBL Clip 2 has a built-in microphone, allowing you to answer calls directly through the speaker. When a call comes in, press the phone icon button to answer. Press it again to end the call.

3. Daisy Chain Feature (JBL Connect)

You can wirelessly link two JBL Clip 2 speakers together to amplify your listening experience. To do this, ensure both speakers are powered on and not connected to any device. Press the JBL Connect button on both speakers simultaneously to pair them. Once connected, they will play audio in stereo.

4. Portability with Carabiner

The integrated aluminum carabiner allows you to easily clip the JBL Clip 2 to your backpack, belt loop, or any secure attachment point, making it highly portable for outdoor adventures.

Video 3: This video showcases the JBL Clip 2's portability, demonstrating how it can be easily clipped onto a backpack using its integrated carabiner, ideal for travel and outdoor use.

MAINTENANCE

1. Waterproof Care

The JBL Clip 2 is IPX7 waterproof, meaning it can be submerged in water up to 1 meter (3 feet) for up to 30 minutes. Ensure all port covers are securely closed before exposing the speaker to water. After exposure to water, dry the speaker thoroughly before charging or using the ports.

2. Cleaning

To clean the speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish or internal components.

TROUBLESHOOTING

- **No Power:** Ensure the speaker is charged. Connect it to a power source using the Micro USB cable.
- **Cannot Pair via Bluetooth:** Make sure the speaker is in pairing mode (flashing blue LED). Check your device's Bluetooth settings to ensure it's discoverable. If issues persist, try restarting both the speaker and your device.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the

correct input source (Bluetooth or Aux) is selected.

- **Poor Sound Quality:** Move the speaker closer to your Bluetooth device to reduce interference. Ensure the speaker is not obstructed.

SPECIFICATIONS

Feature	Specification
Model Name	Clip 2
Wireless Communication Technology	Bluetooth
Connectivity Technology	Auxiliary, Bluetooth
Special Feature	Waterproof
Water Resistance Level	Waterproof (IPX7)
Speaker Maximum Output Power	3 Watts
Battery Life	Up to 8 hours (as per product description)
Charging Time	2.5 Hours
Item Weight	6.5 Ounces
Product Dimensions	6"D x 6"W x 6"H
Included Components	1 x JBL Clip 2, 1 x Micro USB cable for charging, 1 x Quick start guide, 1 x Safety sheet, 1 x Warranty card

WARRANTY AND SUPPORT

Your JBL Clip 2 speaker comes with a limited warranty. Please refer to the included Warranty Card for detailed terms and conditions. For technical support, product registration, or further assistance, please visit the official JBL website or contact their customer service.