

Juwel Serie 67/6 - Keystar

Juwel Series 67/6 Keystar Safe Instruction Manual

Model: Serie 67/6 - Keystar | Brand: Juwel

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient use of your Juwel Series 67/6 Keystar reinforced cabinet safe. Please read these instructions carefully before installation and operation, and retain them for future reference.

The Juwel Series 67/6 Keystar safe is designed for secure storage of valuables, featuring a robust steel construction and an advanced key-locking mechanism. Its reinforced structure provides enhanced protection against unauthorized access.





Figure 1: Juwel Series 67/6 Keystar Safe with its door open. The image displays the robust construction, the interior shelving, and the key-operated locking mechanism with its chrome-plated bolts extended. The Juwel logo is visible at the top of the safe's frame.

2. SAFETY INFORMATION

Always follow these safety guidelines to prevent injury or damage to the safe:

- Ensure the safe is installed on a stable and level surface.
- Keep keys in a secure location, separate from the safe.
- Do not store flammable materials or explosives inside the safe.
- Avoid placing heavy objects on top of the safe.
- Children should not be allowed to play with or near the safe.

3. SETUP AND INSTALLATION

The Juwel Series 67/6 Keystar safe is designed for embedding. Proper installation is crucial for its security.

3.1 Unpacking

1. Carefully remove the safe from its packaging.
2. Inspect the safe for any signs of damage during transit. Report any damage to your supplier immediately.
3. Locate the keys, which are typically secured inside the safe or in a small package attached to the exterior.

3.2 Mounting and Fixing

The safe features 12 fixing holes on the back and base for secure installation.

1. Choose a suitable location for embedding the safe, ensuring the wall or floor structure can support its weight and provide adequate security.
2. Mark the drilling points using the safe's fixing holes as a template.
3. Drill holes of appropriate size and depth for your chosen anchors (not supplied).
4. Position the safe and secure it firmly using suitable bolts or anchors. Ensure all fixing points are tightened to prevent movement.
5. Verify that the safe door opens and closes smoothly after installation.

4. OPERATING INSTRUCTIONS

The Juwel Series 67/6 Keystar safe operates with a traditional key-locking mechanism.

4.1 Opening the Safe

1. Insert one of the provided bicifrate keys into the keyhole on the safe door.
2. Turn the key clockwise (or counter-clockwise, depending on the lock mechanism) until the locking bolts retract.
3. Pull the door open.

4.2 Closing and Locking the Safe

1. Ensure all items are properly placed inside the safe and nothing obstructs the door.
2. Gently push the door closed until it is flush with the safe body.
3. Insert the key into the keyhole.
4. Turn the key counter-clockwise (or clockwise) until the locking bolts extend fully, securing the door.
5. Remove the key and store it in a secure, separate location.

5. MAINTENANCE

Regular maintenance ensures the longevity and reliable operation of your safe.

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lock Mechanism:** Periodically apply a small amount of graphite powder or a non-greasy lubricant to the keyhole to ensure smooth operation of the lock. Do not use oil-based lubricants.
- **Hinges and Bolts:** Check the door hinges and locking bolts for any signs of wear or obstruction. Ensure they move freely.
- **Key Care:** Handle keys with care. Avoid bending or forcing them. If a key becomes damaged, contact Juwel support for assistance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Key does not turn or is stiff.	Dust or debris in the lock; worn key; incorrect key.	Apply graphite powder to the keyhole. Ensure you are using the correct key. If the key is worn, contact support.
Door does not close properly.	Obstruction inside the safe; safe not level; damaged hinges.	Check for obstructions. Verify the safe is level. Inspect hinges for damage.

Problem	Possible Cause	Solution
Locking bolts do not extend fully.	Mechanism obstruction; key not fully turned.	Ensure the key is turned completely. Check for any internal obstructions preventing bolt extension.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Juwel customer support.

7. SPECIFICATIONS





Feature	Detail
Model Number	Serie 67/6 - Keystar (Art. 6726 N. 3)
Brand	Juwel
Exterior Dimensions (H x W x D)	245 mm x 375 mm x 248 mm
Interior Dimensions (H x W x D)	235 mm x 365 mm x 184 mm
Material	Reinforced Alloy Steel
Door Thickness	8 mm (total 55 mm)
Locking System	Key Lock, 8 real anti-manipulation points, 2 bicifrate keys
Lock Certification	Certified according to European Standard EN 1300 Class B
Fixing Holes	12 holes (back and base)
Color	White

8. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. Juwel products are manufactured to high standards, and support is available for any operational issues or inquiries.

For technical assistance or to inquire about replacement parts, please contact Juwel customer service through official channels or your point of purchase. When contacting support, please have your model number (Serie 67/6 - Keystar) and purchase details ready.

Related Documents

	<p>Juwel RUNNER Electronic Digital Combination Safe Lock User Manual</p> <p>Comprehensive guide to operating and setting up the Juwel RUNNER electronic digital combination safe lock, covering different versions and features.</p>
	<p>Juwel 3-Button Combination Lock Operating Instructions</p> <p>Detailed instructions for operating, opening, closing, and changing the combination code on a Juwel 3-button combination lock. Includes guidance on understanding the set combination.</p>
	<p>How to Open and Close Your Safe: A Step-by-Step Guide</p> <p>Instructions for operating a safe with a handle to open, including steps for both opening and closing using key, mechanical combination, and electronic combination systems.</p>
	<p>JUWEL Biostar 1500 Cold Frame Assembly and Usage Guide</p> <p>Detailed assembly instructions, parts list, and usage tips for the JUWEL Biostar 1500 cold frame. Learn how to install, maintain, and optimize your cold frame for gardening success, including details on the optional automatic window opener.</p>