

[Manuals.plus](#) /

> [Pitco](#) /

> Pitco A6086803 Fryer/Feeder/Magi Top Logo Instruction Manual

Pitco A6086803

Pitco A6086803 Fryer/Feeder/Magi Top Logo Instruction Manual

Brand: Pitco | Model: A6086803

1. INTRODUCTION

This manual provides essential information for the proper handling, installation, operation, and maintenance of the Pitco A6086803 Fryer/Feeder/Magi Top Logo. This product is an original OEM replacement part designed to ensure the safety, reliability, and performance of your Pitco equipment. Please read this manual thoroughly before attempting any procedures.

For further assistance, please contact Pitco customer support.

2. IMPORTANT SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the equipment:

- Only use original OEM parts for replacement to maintain safety and performance standards.
- Ensure the equipment is disconnected from power before attempting any installation or maintenance.
- If you are unsure about any procedure, consult a qualified technician or Pitco customer support.
- Keep this manual in a safe place for future reference.

3. PRODUCT OVERVIEW

The Pitco A6086803 is an original equipment manufacturer (OEM) replacement part, specifically a top logo decal for Pitco Fryer/Feeder/Magi units. This decal features the "Superior" brand logo and is crucial for maintaining the original aesthetic and branding of your commercial kitchen equipment.



Figure 3.1: Pitco A6086803 Top Logo Decal. This image shows the black rectangular decal with the "Superior" logo and a phone number (1-800-328-9400) in white, oriented horizontally.



Figure 3.2: Pitco A6086803 Top Logo Decal. This image displays the same black decal with the "Superior" logo and phone number, but oriented vertically.



Figure 3.3: Pitco A6086803 Top Logo Decal. This image shows the decal horizontally, but with the text mirrored, possibly indicating the adhesive side or a different angle.



Figure 3.4: Pitco A6086803 Top Logo Decal. This image shows the decal vertically, with the text mirrored, similar to Figure 3.3.

4. SETUP AND INSTALLATION

This product is a replacement decal. Installation typically involves applying the decal to a clean, dry surface on the fryer/feeder/magi unit. Follow these general steps:

1. **Prepare the Surface:** Ensure the area where the decal will be applied is clean, dry, and free of grease, dust, or old adhesive residue. Use a mild cleaner if necessary, and allow the surface to dry completely.

- 2. **Position the Decal:** Carefully align the new logo decal to the desired position on the equipment. It is recommended to lightly mark the position before removing the backing.
- 3. **Apply the Decal:** Slowly peel off the backing from one edge of the decal. As you peel, press the decal firmly onto the surface, working from one side to the other to avoid air bubbles.
- 4. **Smooth Out:** Use a soft cloth or a squeegee to smooth out any air bubbles, working from the center outwards.
- 5. **Final Check:** Ensure the decal is securely adhered and properly aligned.

Note: For specific placement instructions, refer to your original Pitco equipment manual or consult a qualified service technician.

5. OPERATING INSTRUCTIONS

As the A6086803 is a cosmetic replacement part (a logo decal), it does not have operational functions. Its purpose is to restore the original appearance of your Pitco Fryer/Feeder/Magi unit. The operation of the fryer/feeder/magi itself is covered in its dedicated operational manual.

6. MAINTENANCE

To ensure the longevity and appearance of the A6086803 logo decal, follow these maintenance guidelines:

- **Cleaning:** Clean the decal surface gently with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the decal's finish.
- **Avoid Direct Heat:** While designed for commercial kitchen environments, prolonged direct exposure to extreme heat sources should be minimized if possible, to prevent adhesive degradation.
- **Inspection:** Periodically inspect the decal for signs of peeling, fading, or damage. If significant damage occurs, consider replacing the decal to maintain the professional appearance of your equipment.

7. TROUBLESHOOTING

Since the A6086803 is a non-functional cosmetic part, troubleshooting is limited to issues related to its application or appearance.

Problem	Possible Cause	Solution
Decal is peeling or not adhering properly.	Surface not clean/dry; improper application; old adhesive residue.	Ensure surface is thoroughly cleaned and dried before application. Reapply carefully, pressing firmly. If peeling persists, the decal may need replacement.
Air bubbles under the decal.	Improper application technique.	When applying, work slowly from one side to the other, smoothing as you go. For existing bubbles, gently press them towards the nearest edge to push out the air. A small pinprick might be used as a last resort for stubborn bubbles, then smooth.
Decal appears faded or damaged.	Exposure to harsh cleaning agents; prolonged direct heat; general wear and tear.	Use only mild cleaners. Avoid direct heat. If damage is significant, replace the decal.

8. SPECIFICATIONS

Key specifications for the Pitco A6086803 Top Logo replacement part:

- **Brand:** Pitco
- **Manufacturer:** Pitco
- **Model Number:** PTA6086803
- **Part Number:** A6086803
- **Unit Count:** 1
- **Battery Operated:** No
- **Product Dimensions:** Approximately 12.7 x 15.24 x 22.86 cm (5 x 6 x 9 inches)
- **Item Weight:** Approximately 45.36 g (0.1 lbs)
- **ASIN:** B01F6C9V5G
- **Available for purchase since:** May 4, 2016

9. WARRANTY AND SUPPORT

As an OEM replacement part, the Pitco A6086803 is manufactured to Pitco's high standards. For specific warranty information regarding replacement parts, please refer to the warranty policy provided with your original Pitco equipment or contact Pitco directly.

For technical support, inquiries about this part, or assistance with installation, please contact Pitco customer service. Contact details can typically be found on the official Pitco website or in your original equipment documentation.

Note: The phone number "1-800-328-9400" visible on the decal may be for "Superior" brand, which could be a component supplier or a related entity. For Pitco product support, always refer to official Pitco contact channels.

© 2023 Pitco. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01F6C9V5G>

More documents and user manuals: <https://manuals.plus/>