

IKEA VIMMERN

IKEA VIMMERN Mixer Tap with Pull-Out Spray Instruction Manual

Model: VIMMERN

INTRODUCTION

Welcome to your new IKEA VIMMERN mixer tap. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your product. Please read these instructions carefully before installation and use, and retain them for future reference.

PRODUCT FEATURES

- **Height:** 47 cm
- **Material:** Durable brass construction with a zirconium surface finish.
- **Water and Energy Saving:** Equipped with a flow regulator (8 L/min) to reduce water consumption while maintaining adequate pressure.
- **Ceramic Disc Cartridge:** Features a ceramic disc cartridge designed for high friction resistance during temperature adjustments, ensuring smooth operation.
- **Dual-Function Pull-Out Spray:** The pull-out spray offers two distinct water patterns: a concentrated jet and a wider spray, selectable by pressing a button on the spray head.
- **Magnetic Holder (IPS11):** The spray head is secured by a magnetic holder, allowing for easy and precise re-docking with one hand.
- **Safety Valve:** Includes a safety valve to prevent unwanted backflow into the water supply.
- **Certified Quality:** Tested and approved according to European mechanical, quality, and safety regulations (KIWA).
- **Connection Hoses:** Supplied with 3/8" connection hoses, 35 cm in length.
- **Temperature and Pressure:** Maximum hot water temperature of 80 °C (176 °F). Suitable for pressure systems, tested up to 16 bar (1000 kPa). Recommended working pressure is 1.0–5.0 bar (100 kPa – 500 kPa).

- **360° Swivel Spout:** The tap features a full 360-degree swivel range for enhanced flexibility.

SETUP AND INSTALLATION

Important: Installation must be carried out by a qualified professional and in accordance with all local building and plumbing regulations. If you have any questions or concerns, please seek technical advice.

Pre-installation Requirements

- A minimum clearance of 60 cm is required between the countertop and any wall cabinet above to allow for full use of the pull-out spray.
- A 35 mm diameter drill hole is required for mounting the tap.
- The tap is designed for installation on countertops or sinks with a maximum thickness of 50 mm.

Installation Steps (General)

The mixer tap is designed for single-hole installation. An installation tool is included in the packaging to facilitate assembly.

1. Ensure the water supply is turned off at the main valve.
2. Insert the tap into the prepared 35 mm hole in your countertop or sink.
3. From underneath the countertop, secure the tap using the provided washers and nuts. Tighten firmly but do not overtighten.
4. Connect the 3/8" connection hoses to your hot and cold water supply lines. Ensure all connections are sealed properly to prevent leaks.
5. Connect the pull-out spray hose to the tap body and attach any counterweights as per the detailed diagram in the product packaging.
6. Once all connections are made, slowly turn on the main water supply and check for any leaks.



Image: The IKEA VIMMERN mixer tap, showcasing its brushed steel finish and pull-out spray design. This image illustrates the complete product before installation.

OPERATING INSTRUCTIONS

Water Flow and Temperature Control

The single lever handle on the side of the tap controls both water flow and temperature. Move the handle to the left for hot water, to the right for cold water, and up or down to adjust the water flow intensity.

Using the Pull-Out Spray

To use the pull-out spray, simply pull the spray head away from the main spout. The flexible hose allows for extended reach. The spray head features a button to switch between a concentrated jet and a wider spray pattern, suitable for various tasks like rinsing dishes or washing vegetables.

After use, the magnetic holder (IPS11) ensures the spray head easily and securely returns to its original position within the main spout.



Image: A hand demonstrating the use of the pull-out spray on the IKEA VIMMERN mixer tap. The user is pressing a button on the spray head to change the water flow pattern, with water flowing into a sink.



Image: The IKEA VIMMERN mixer tap's pull-out spray being used to rinse fruit in a sink. This illustrates the flexibility and reach of the spray function for various kitchen tasks.

MAINTENANCE

Care and Cleaning Instructions

Proper care will help maintain the appearance and functionality of your IKEA VIMMERN mixer tap.

- **Regular Cleaning:** Clean the tap regularly with a soft, damp cloth. Use only water and a mild dishwashing detergent or soft soap.
- **Drying:** After cleaning, wipe the tap dry with a clean, soft cloth to prevent water spots and mineral buildup.
- **Avoid Harsh Cleaners:** Do not use scouring pads, steel wool, or abrasive cleaners. Avoid cleaning agents that contain descaling agents, acids, alcohol, or abrasives, as these can damage the tap's surface finish.

TROUBLESHOOTING

This section addresses common issues you might encounter with your mixer tap. For complex problems, it is recommended to contact a qualified plumber.

Low Water Pressure

- **Check Water Supply:** Ensure that the hot and cold water supply valves under the sink are fully open.
- **Inspect Aerator:** The aerator at the tip of the spray head can become clogged with debris or mineral deposits. Unscrew the aerator and clean it thoroughly. Replace if damaged.
- **Flow Regulator:** Verify that the internal flow regulator is not obstructed.

Leaks

- **Connection Points:** Check all hose connections under the sink to ensure they are tightened properly. Do not overtighten.

- **O-Rings and Gaskets:** Inspect the condition of O-rings and gaskets at connection points. Replace any that appear worn or damaged.
- **Spout Leaks:** If water leaks from the spout when the tap is off, the ceramic disc cartridge may require inspection or replacement by a qualified professional.

Difficulty Adjusting Temperature

- **Water Supply:** Ensure both hot and cold water supplies are connected and functioning correctly.
- **Cartridge Issue:** Inconsistent temperature mixing may indicate an issue with the ceramic disc cartridge, which might require servicing or replacement.

For issues not listed here or if problems persist after attempting these solutions, please contact IKEA customer support or a qualified plumber.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	IKEA
Model Name	VIMMERN
Model Number	VIMMERN
Height	47 cm
Material	Brass, Alloy Steel, Zirconium surface
Finish	Brushed
Color	Silver-colored
Weight	2.69 kg
Installation Method	Single-hole (Monotrou)
Number of Holes Required	1
Number of Handles	1
Handle Material	Brass
Spout Swivel	360°
Max Hot Water Temperature	80 °C (176 °F)
Recommended Working Pressure	1.0–5.0 bar (100 kPa – 500 kPa)
Tested Pressure	Up to 16 bar (1000 kPa)

Feature	Detail
Flow Rate (with regulator)	8 L/min
Connection Hoses	3/8", 35 cm length
Max. Countertop/Sink Thickness	50 mm
Drill Hole Diameter	35 mm
ASIN	B01F9ULOBO

WARRANTY AND CUSTOMER SUPPORT

Information regarding specific warranty terms for the IKEA VIMMERN mixer tap is not provided within this manual. Please refer to your purchase receipt or contact IKEA customer service directly for detailed warranty information applicable to your region.

For technical assistance, inquiries about spare parts, or any further questions, please visit the official IKEA website or contact your local IKEA store. Their contact details can typically be found on the IKEA website or in your purchase documentation.

© 2024 IKEA. All rights reserved.
This manual is for informational purposes only and may be subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question