

Logilink CP132

Logilink CP132 Power Cable Extension 2m User Manual

Model: CP132

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Logilink CP132 Power Cable Extension. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the cable or connected devices, and to ensure personal safety:

- Do not exceed the specified voltage and current ratings of the cable (230V AC).
- Ensure the cable is fully inserted into compatible sockets and devices.
- Do not use the cable if it is damaged, frayed, or has exposed wires.
- Keep the cable away from water, excessive heat, and sharp objects.
- Do not modify or attempt to repair the cable.
- Unplug the cable from the power source before cleaning or when not in use.

3. PRODUCT OVERVIEW

The Logilink CP132 is a 2-meter power extension cable designed to extend the reach of devices using a C8 inlet (male) to a C7 outlet (female) connection. It is suitable for various electronic devices such as radios, game consoles, and some audio equipment.



Figure 3.1: The Logilink CP132 Power Cable Extension as it appears in its retail packaging.



Figure 3.2: Overview of the Logilink CP132 Power Cable Extension, displaying both the male C8 plug and the female C7 socket.



Figure 3.3: Detailed view of the male C8 connector, which plugs into a device's power inlet.



Figure 3.4: Detailed view of the female C7 socket, which receives a device's power cord.

4. SETUP

To set up the Logilink CP132 Power Cable Extension:

1. **Identify Connectors:** Locate the male C8 connector and the female C7 socket on the extension cable.
2. **Connect to Device:** Insert the male C8 connector of the extension cable into the C8 power inlet of your electronic device. Ensure a firm connection.
3. **Connect to Power Source:** Plug the power cord of your device (which should have a C7 connector) into the female C7 socket of the extension cable.
4. **Power On:** Once both connections are secure, you can connect your device's power cord to a wall outlet or power strip.



Figure 4.1: Illustration of the male C8 connector inserted into the female C7 socket, demonstrating a typical connection.

5. OPERATION

The Logilink CP132 Power Cable Extension operates passively, extending the reach of your existing power connection. No specific operational steps are required for the cable itself once connected. Ensure that the total power draw of the connected device does not exceed the cable's rated capacity.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your power cable extension.

- **Cleaning:** Disconnect the cable from all power sources before cleaning. Wipe the cable and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cable loosely to prevent kinks and damage. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cable for any signs of wear, cuts, or damage to the insulation or connectors. If any damage is observed, discontinue use immediately and replace the cable.



Figure 6.1: The power cable extension coiled for proper storage, preventing kinks and damage.

7. TROUBLESHOOTING

If you encounter issues with your Logilink CP132 Power Cable Extension, consider the following:

- **No Power to Device:**
 - Ensure both ends of the extension cable are securely connected.
 - Verify that the device's power cord is properly plugged into the extension cable.
 - Check if the wall outlet or power strip is functional by testing with another device.

- Inspect the cable for visible damage. If damaged, discontinue use.

- **Loose Connection:**

- Ensure connectors are fully inserted. Avoid pulling the cable by the cord; always grasp the plug.

8. SPECIFICATIONS

Feature	Detail
Model Number	CP132
Brand	Logilink
Length	2 meters
Connector Type	Male C8 to Female C7
Voltage Rating	230V AC
Color	White
Product Dimensions	7.87 x 5.91 x 0.47 inches (approximate packaging)
Item Weight	2.75 ounces
Manufacturer	2 Direct

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or visit the official Logilink website. Keep your proof of purchase for warranty claims.
