

[Manuals.plus](#) /

› [Signstek](#) /

› Signstek 1.5L Ultrasonic Aroma Humidifier User Manual

Signstek 1.5L Ultrasonic Aroma Humidifier

Signstek 1.5L Ultrasonic Aroma Humidifier User Manual

Brand: Signstek | **Model:** 1.5L Ultrasonic Aroma Humidifier

INTRODUCTION

Thank you for choosing the Signstek 1.5L Ultrasonic Aroma Humidifier. This device is designed to enhance your indoor environment by providing a fine mist, acting as an air diffuser, purifier, and ionizer. It features a 1.5-liter water capacity, adjustable mist output, and an automatic shut-off function for safety. The integrated LED lights offer a soothing visual experience. This manual provides essential information for the safe and efficient operation, setup, and maintenance of your humidifier.


IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Always place the humidifier on a firm, flat, waterproof surface away from direct sunlight and heat sources.
- Do not immerse the base unit in water or other liquids.
- Ensure the power cord is not damaged and is placed where it cannot be tripped over.
- Unplug the humidifier from the power outlet before filling, cleaning, or moving it.
- Do not add water to the base unit directly; always fill the water tank.
- The humidifier will automatically shut off when the water level is too low, and the LED light may flicker as a warning.
- Use only clean tap water or distilled water. Do not use hot water.
- Only use 100% natural water-soluble essential oils if desired. Other oils may damage the unit.
- Keep out of reach of children and pets.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Signstek Ultrasonic Aroma Humidifier:

- **Mist Output Nozzle:** Directs the mist.
- **Water Tank:** Holds up to 1.5 liters of water.
- **Water Filling Nozzle:** Opening for refilling the water tank.
- **Air Intake:** Draws air into the unit.
- **Product Base:** Contains the ultrasonic vibrator, control knob, and electronics.
- **Mist Volume Control Knob:** Adjusts the intensity of the mist output.
- **Power Switch:** Located at the back of the base.



This diagram labels the mist output nozzle, water tank, water filling nozzle, air intake, product base, and mist volume control knob.



This image shows the front of the humidifier, featuring the decorative cut-out pattern and the control knob on the base.

SETUP

1. **Unpack:** Carefully remove all packaging materials and place the humidifier on a flat, stable surface.
2. **Remove Water Tank:** Lift the water tank from the base unit.
3. **Fill Water Tank:** Unscrew the water filling nozzle cap at the bottom of the tank. Fill the tank with clean, cool tap water or distilled water. Do not exceed the maximum fill line. If adding essential oils, add a few drops directly into the water tank.



This image displays the interior of the humidifier's base, showing the ultrasonic vibrator and water reservoir area.

4. **Secure Cap:** Screw the water filling nozzle cap back on tightly to prevent leaks.
5. **Place Tank on Base:** Carefully place the filled water tank back onto the base unit, ensuring it is seated correctly.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet. Ensure the power switch at the back of the unit is in the OFF position before plugging in.



The back of the humidifier is shown, highlighting the main power switch and the power cord connection point.

OPERATING INSTRUCTIONS

1. **Power On:** Flip the power switch located at the back of the base unit to the ON position.
2. **Adjust Mist Volume:** Turn the mist volume control knob on the front of the base clockwise to increase mist output and counter-clockwise to decrease it. The humidifier will begin to produce mist.



This image focuses on the control knob, which adjusts mist volume, and indicates the 'Power' and 'Waterless' indicators.

3. **LED Light Function:** The humidifier features a colorful LED light that changes colors automatically. You can turn the light on or off using a separate button (if available, otherwise it operates with the mist). The light cannot be set to a single color.



The humidifier is shown in operation, producing a visible mist and illuminating with its integrated LED light, creating an ambient effect.

4. **Direct Mist:** The mist output nozzle can be rotated 360 degrees to direct the mist flow in your desired direction.



This diagram illustrates how the mist output nozzle can be rotated 360 degrees to direct the mist flow.

5. **Automatic Shut-off:** The humidifier will automatically turn off when the water level in the tank is too low. The LED light may flicker to indicate this condition.
6. **Power Off:** To turn off the humidifier, turn the mist volume control knob counter-clockwise until it clicks off, or flip the power switch at the back to the OFF position. Unplug the unit when not in use.

MAINTENANCE AND CLEANING

Regular cleaning helps maintain the efficiency and longevity of your humidifier.

1. Daily Maintenance:

- Unplug the humidifier before any cleaning.
- Empty any remaining water from the tank and base.
- Wipe the tank and base with a clean, damp cloth.

2. Weekly Cleaning:

- **Clean the Water Tank:** Remove the water tank. Unscrew the cap and rinse the inside thoroughly with clean water. You can use a soft brush to clean any residue.
- **Clean the Base Unit:** Gently wipe the inside of the base unit, especially around the ultrasonic vibrator (the small disc in the center), with a soft cloth. Do not use abrasive cleaners or scrub the vibrator. If mineral deposits are present, you can use a solution of white vinegar and water (1:1 ratio) to soak the area for 10-15 minutes, then gently wipe clean. Rinse thoroughly with clean water.
- **Clean the Mist Output Nozzle:** Ensure the nozzle is free from any blockages.

3. **Storage:** When not in use for an extended period, clean the humidifier thoroughly, ensure all parts are dry, and store it in a cool, dry place.

Note: No special water is required for operation, but using distilled water can help reduce mineral buildup.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
No mist is being produced.	No power; Water tank empty; Mist knob set to minimum.	Ensure unit is plugged in and power switch is ON; Refill water tank; Turn mist knob clockwise.
LED light is flickering.	Water level is too low.	Refill the water tank. The unit will resume operation once sufficient water is detected.
Unusual odor from mist.	Dirty water tank or base; Stale water.	Clean the water tank and base thoroughly; Replace water daily.
Water leakage.	Water tank cap not secured; Tank not seated correctly; Overfilled tank.	Ensure water tank cap is tightly screwed; Re-seat the water tank on the base; Do not overfill the tank.
Excessive noise.	Unit not on a flat surface; Water level too low.	Place on a flat, stable surface; Refill water tank.

PRODUCT SPECIFICATIONS

Feature	Specification
Capacity	1.5 Liters (approx. 0.4 Gallons)
Power Source	Corded Electric
Material	Polypropylene (PP)
Special Features	Aroma Diffuser, Quiet Operation, Automatic Shut-off
Light Source Type	LED (Color-changing)
Recommended Coverage	Medium to Large Room
Dimensions (approx.)	27.7 x 17.7 x 15.9 cm

WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the documentation included with your purchase or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance, or encounter issues not covered in this manual, please contact Signstek customer support through your retailer or the official Signstek website. Please have your product model and purchase information ready when contacting support.



