

[manuals.plus](#) /› [Nilfisk](#) /› [Nilfisk Replacement 30' Power Cord for GM80 Instruction Manual](#)**Nilfisk 11827420**

# Nilfisk Replacement 30' Power Cord for GM80 Instruction Manual

Model: 11827420

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use and replacement of the Nilfisk 30-foot power cord, model 11827420. This power cord is specifically designed as a replacement part for the Nilfisk GM80 vacuum cleaner. Please read these instructions thoroughly before attempting any installation or use.

## 2. SAFETY INFORMATION

### WARNING: Electrical Shock Hazard

- Always unplug the vacuum cleaner from the power outlet before attempting to replace the power cord or perform any maintenance.
- Ensure your hands are dry before handling electrical components.
- Do not use the power cord if it is damaged, frayed, or has exposed wires. Replace it immediately.
- This power cord is designed for indoor use only.
- Do not modify the plug or the cord in any way.

## 3. PRODUCT OVERVIEW

The Nilfisk Replacement 30' Power Cord (Model 11827420) is a durable, gray power cable designed to provide reliable electrical connection to your Nilfisk GM80 vacuum cleaner. It features a standard Type B male plug for connection to a wall outlet and a specific female connector for the vacuum unit.



This image displays the Nilfisk 30-foot replacement power cord, coiled for packaging. It features a standard two-prong Type B male plug for wall outlets and a specialized female connector designed for the Nilfisk GM80 vacuum cleaner.

## 4. INSTALLATION AND SETUP

Follow these steps to safely replace the power cord on your Nilfisk GM80 vacuum cleaner:

- 1. Disconnect Power:** Ensure the Nilfisk GM80 vacuum cleaner is completely unplugged from the electrical outlet.
- 2. Locate Cord Connection:** Identify where the existing power cord connects to the vacuum cleaner. This connection point is typically secured by screws or a locking mechanism.
- 3. Remove Old Cord:** Carefully disconnect the old power cord. This may involve unscrewing a cover or releasing a latch. Note the orientation of the connector for proper installation of the new cord.
- 4. Connect New Cord:** Align the female connector of the new Nilfisk 30' Replacement Power Cord (Model 11827420) with the corresponding port on the vacuum cleaner. Push firmly until it is securely seated.
- 5. Secure Connection:** If applicable, re-attach any covers or secure any screws that hold the cord in place. Ensure the connection is stable and not loose.
- 6. Test:** Once the new cord is securely installed, plug the vacuum cleaner into a functional electrical outlet and test its operation.

*If you are unsure about any step, consult a qualified technician or the Nilfisk service center.*

## 5. OPERATION

Once installed, the Nilfisk Replacement 30' Power Cord functions identically to the original cord, providing electrical power from a standard 120V AC outlet to your Nilfisk GM80 vacuum cleaner. Ensure the cord is fully extended and not coiled during operation to prevent overheating.

## 6. MAINTENANCE

- Regularly inspect the entire length of the power cord for any signs of damage, cuts, fraying, or kinks.
- Avoid wrapping the cord too tightly around objects, which can cause internal wire damage.
- Store the cord neatly coiled when not in use to prevent tangling and damage.
- Keep the cord away from sharp edges, hot surfaces, and moving parts of the vacuum cleaner.
- Clean the cord with a damp cloth if it becomes dirty; ensure it is unplugged before cleaning.

## 7. TROUBLESHOOTING

If your Nilfisk GM80 vacuum cleaner does not power on after replacing the cord, consider the following:

- **No Power:**

- Ensure the power cord is fully plugged into a functional electrical outlet.
- Verify that the new power cord's connector is securely seated in the vacuum cleaner's port.
- Check the circuit breaker or fuse for the outlet.

- **Loose Connection:**

- Unplug the vacuum, then firmly re-seat both ends of the power cord.

*If issues persist after troubleshooting, contact Nilfisk customer support or a certified service technician.*

## 8. SPECIFICATIONS

<b>Model Number</b>	11827420
<b>Brand</b>	Nilfisk
<b>Length</b>	30 feet
<b>Color</b>	Gray
<b>Voltage</b>	120 Volts (AC)
<b>Plug Format</b>	Type B (Male)
<b>Connector Gender</b>	Male-to-Female
<b>Product Dimensions</b>	14 x 9 x 2 inches (packaged)

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or to purchase additional replacement parts, please contact Nilfisk customer service directly. Refer to your original Nilfisk GM80 vacuum cleaner manual or the official Nilfisk website for contact details.

**Nilfisk Official Website:** [www.nilfisk.com](http://www.nilfisk.com)