

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Nilfisk](#) /
- › [Nilfisk Alto Attix 30 Wet/Dry Vacuum Instruction Manual](#)

### Nilfisk Attix 30 (Model 302004229)

## Nilfisk Alto Attix 30 Wet/Dry Vacuum Instruction Manual

Model: Attix 30 (302004229)

### INTRODUCTION

---

The Nilfisk Alto Attix 30 Wet/Dry Vacuum is engineered for superior suction power and durability, designed for both wet and dry cleaning tasks. This robust machine features a low noise level, powerful suction, and advanced filtration, including the Push and Clean filter cleaning system. Its ergonomic design and sturdy grip facilitate easy transport and storage, making it suitable for demanding environments such as automotive facilities or construction sites.



Image: The Nilfisk Alto Attix 30 Wet/Dry Vacuum, showcasing its robust design and hose attachment.

## SETUP

---

### Unpacking and Assembly

Carefully remove all components from the packaging. Ensure all listed accessories are present before beginning assembly. The vacuum includes a 10-foot long, 1.5-inch diameter hose, chrome curved wand, 2-piece chrome extension wand, floor nozzle-combination, crevice nozzle, brush nozzle, universal nozzle, washable filter, and aluminum extension tube.

### Filter Installation

The washable filter is designed for both wet and dry use. For dry vacuuming, ensure the filter is clean and properly seated. For wet vacuuming, the filter should also be in place to protect the motor.

## Hose and Accessory Attachment

Attach the hose securely to the inlet port on the vacuum. Connect the desired wand and nozzle (e.g., floor nozzle, crevice nozzle, brush nozzle) to the end of the hose for specific cleaning tasks. Ensure all connections are firm to maintain optimal suction.

Video: This video demonstrates the general installation and attachment of accessories for a wet/dry vacuum cleaner. While not specific to the Nilfisk Attix 30, it illustrates common setup procedures for similar products.

## OPERATING INSTRUCTIONS

---

### Powering On/Off

Plug the vacuum into a standard 120V outlet. Locate the power switch on the unit and toggle it to the 'ON' position to begin operation. To turn off, toggle the switch to the 'OFF' position.

### Dry Vacuuming

For dry debris, attach the appropriate nozzle (e.g., floor nozzle for large areas, crevice nozzle for tight spaces, brush nozzle for upholstery). Move the nozzle over the surface to be cleaned. The powerful suction will collect dust, dirt, and other dry particles.

### Wet Vacuuming

For liquid spills, ensure the washable filter is correctly installed. Use the floor nozzle or universal nozzle to effectively pick up liquids. The vacuum is designed to handle wet messes efficiently.

Video: This video demonstrates the effective use of a wet/dry vacuum cleaner for both dry debris and liquid spills, showcasing various attachments for different cleaning scenarios.

## MAINTENANCE

---

### Filter Cleaning and Replacement

The Attix 30 features a Push and Clean filter cleaning system. Refer to the specific instructions in your included assembly guide for detailed steps on how to activate this feature. Regularly inspect the washable filter for wear and tear. Clean the filter as needed by rinsing with water and allowing it to air dry completely before reinstallation. Replace the filter if it shows signs of damage or reduced performance.

### Canister Emptying

Periodically empty the vacuum canister. Disconnect the power before opening the canister. Dispose of collected debris responsibly. For wet vacuuming, drain the liquid from the canister.

Video: This Nilfisk overview highlights features like easy filter changes and bag capacity, which are relevant for maintaining the vacuum's performance and ensuring efficient operation.

## TROUBLESHOOTING

---

- Reduced Suction:** Check for blockages in the hose, wands, or nozzles. Ensure the filter is clean and properly installed. Verify the canister lid is securely latched.
- Motor Not Starting:** Confirm the power cord is securely plugged into a working outlet. Check the power switch position.

- **Unusual Noise:** Inspect for foreign objects in the hose or motor area. Ensure all components are correctly assembled.

## SPECIFICATIONS

---

Feature	Detail
Brand	Nilfisk
Model Name	Attix 30 (B476538)
Special Feature	Dry, Wet
Filter Type	Cartridge
Wattage	1500 watts
Amperage	9 Amps
Hose Length	3.04 Meters (10 feet)
Product Dimensions	24"L x 15"W x 23"H
Item Weight	33 pounds
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor

## WARRANTY

---

This product is sold without an explicit manufacturer's warranty. Please refer to your retailer's return policy or contact them directly for any concerns regarding product defects or issues upon purchase.

## SUPPORT

---

For further assistance, technical support, or inquiries regarding your Nilfisk Alto Attix 30 Wet/Dry Vacuum, please visit the official Nilfisk website or contact their customer service department. Keep your product model number and purchase information readily available when seeking support.