

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Dyson](#) /

› [Dyson Supersonic Hair Dryer \(Iron/Fuchsia, 1200W\) Instruction Manual](#)

Dyson 306002-01

Dyson Supersonic Hair Dryer Instruction Manual

Model: 306002-01

INTRODUCTION

The Dyson Supersonic hair dryer is engineered to protect hair from extreme heat damage with the fastest drying and controlled styling. This manual provides instructions for the safe and effective setup, operation, maintenance, and troubleshooting of your Dyson Supersonic Hair Dryer.

KEY FEATURES

- Helps prevent extreme heat damage to protect natural shine; Air temperature is measured 20 times every second, keeping the temperature under control.
- Ultra-fast drying; For fast drying you need controlled, high velocity airflow. Rated power 1600 watts.
- Lightweight and balanced; The motor is positioned in the handle, rebalancing the dryer's weight and shape.
- Acoustically tuned; The powerful motor is tuned to produce one inaudible frequency.
- Cool to touch; With Heat Shield technology, the surfaces of the attachments stay cool, even during close-up styling.
- Includes: 4 precise heat settings (fast drying & styling, regular drying, gentle drying, and constant cold).
- Includes: 3 precise speed settings (fast drying, regular drying and gentle drying).
- Negative ions: Help reduce static in the hair.

PACKAGE CONTENTS

- Dyson Supersonic Hair Dryer Unit
- Smoothing Nozzle
- Styling Concentrator
- Diffuser
- Non-slip Mat
- Storage Hanger

SETUP

Attaching Nozzles

The Dyson Supersonic hair dryer features magnetic attachments for easy and secure connection. Simply align the desired attachment with the front of the dryer and it will snap into place. To remove, gently pull the attachment away from the dryer.





Image: The Dyson Supersonic Hair Dryer in Iron/Fuchsia, showcasing its sleek design and magnetic attachments including the smoothing nozzle, styling concentrator, and diffuser.

OPERATING INSTRUCTIONS

Power, Heat, and Speed Settings

The hair dryer features intuitive controls located on the handle for power, temperature, and airflow. Use the power button to turn the device on or off. Adjust the heat settings using the red dot button and the speed settings using the fan icon button. The LED indicators will show the current selection.

Using the Cold Shot

To set your style with a burst of cold air, press and hold the cold shot button (blue dot) located on the handle. Release the button to return to the previous heat setting.

ATTACHMENTS GUIDE

Smoothing Nozzle

The Smoothing Nozzle dries hair with smooth, controlled airflow, helping to create a sleek, natural finish and reduce frizz.

Styling Concentrator

The wide, thin design of the Styling Concentrator creates a high-velocity blade of air that is ideal for precision styling, allowing you to style one section of hair at a time without disturbing the rest.

Diffuser

The Diffuser is engineered to disperse air evenly around your curls, simulating natural drying to help reduce frizz and define curls and waves. Its long prongs allow you to style hair with control and reach deep into the hair.

MAINTENANCE

Cleaning the Filter

To maintain optimal performance and airflow, regularly clean the air intake filter located at the bottom of the handle. Twist the filter cage counter-clockwise to remove it. Gently wipe away any dust or debris from the filter mesh with a soft, dry cloth. Reattach the filter cage by twisting it clockwise until it locks into place.

TROUBLESHOOTING

Power Interruption

If the hair dryer unexpectedly shuts off, check the power plug for a test/reset button. This is a safety feature designed to prevent electrical shock, especially if water comes into contact with the device. Press the reset button on the plug to restore power and resume operation.

Overheating

The Dyson Supersonic features intelligent heat control to prevent extreme heat damage. If the device feels excessively hot during use, it may automatically reduce heat or shut off. Allow the hair dryer to cool down for a few minutes before resuming use.

Reduced Airflow

A clogged air intake filter can significantly reduce airflow and efficiency. Refer to the "Cleaning the Filter" section for instructions on how to clean the filter to restore proper airflow.

SPECIFICATIONS

Feature	Detail
Product Dimensions	38.61 x 26.7 x 10.01 inches
Item Weight	1.1 pounds
Manufacturer	Dyson
Item Model Number	306002-01
Color	Iron/Fuchsia
Material	Metal
Wattage	1200 watts
Voltage	110 volts
Special Feature	Lightweight

WARRANTY AND SUPPORT

The Dyson Supersonic Hair Dryer includes a 2-year manufacturer's warranty. For detailed warranty information, product support, or to register your device, please visit the official Dyson website or contact Dyson customer service directly. Keep your proof of purchase for warranty claims.