



Manuals.plus /

› Moen /

› Moen S6312ORB Icon Showerhead User Manual

## Moen S6312ORB

# Moen S6312ORB Icon Showerhead User Manual

Model: S6312ORB

## 1. INTRODUCTION

---

Thank you for choosing the Moen S6312ORB Icon Showerhead. This manual provides detailed instructions for the installation, operation, and maintenance of your new showerhead. Please read this manual thoroughly before beginning installation to ensure proper function and to prevent damage.

The Moen Icon showerhead combines sleek design with reliable performance, featuring a 5-7/8" diameter one-function full spray and a 2.5 GPM flow rate. Its Oil Rubbed Bronze finish offers a classic, antiqued look.

## 2. SAFETY INFORMATION

---

Please observe the following safety precautions during installation and use:

- Always turn off the main water supply before beginning any plumbing work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not overtighten connections, as this can damage the product or plumbing.
- Ensure all connections are secure to prevent leaks.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- Moen S6312ORB Icon Showerhead (1)
- Installation Instructions (1)

*Note: Additional plumbing tools and supplies (e.g., pipe thread sealant tape) are required and sold separately.*

## 4. INSTALLATION INSTRUCTIONS

---

Follow these steps to install your Moen S6312ORB Icon Showerhead:

1. **Prepare the Shower Arm:** Ensure the shower arm extending from your wall is clean and free of old sealant or debris. If replacing an existing showerhead, remove it by turning counter-clockwise.
2. **Apply Thread Sealant:** Wrap pipe thread sealant tape (Teflon tape) clockwise around the threads of the shower arm. Apply 3-4 layers for a secure, watertight seal.
3. **Attach the Showerhead:** Thread the Moen S6312ORB Icon Showerhead onto the shower arm by turning it clockwise. Hand-tighten until snug.
4. **Final Tightening:** Using an adjustable wrench, carefully tighten the showerhead an additional 1/4 to 1/2 turn. **Do not overtighten**, as this can damage the showerhead or shower arm.
5. **Test for Leaks:** Turn on the main water supply and check for any leaks around the connection point. If leaks occur, tighten slightly more or reapply thread sealant tape.



Image: The Moen S6312ORB Icon Showerhead, showcasing its Oil Rubbed Bronze finish and single-function design. This image represents the product being installed.



Image: A side profile view of the Moen S6312ORB Icon Showerhead, highlighting its sleek design and connection point for the shower arm.

## 5. OPERATION

---

The Moen S6312ORB Icon Showerhead features a single-function full spray. To operate:

- Turn on your shower's water control handle to the desired temperature and flow.
- The showerhead will deliver a consistent full spray pattern.

Your browser does not support the video tag.

Video: An official Moen brand video showcasing various Moen products in use, demonstrating water flow and design. This video provides a general overview of Moen's commitment to water experiences.

## 6. MAINTENANCE

---

To keep your Moen S6312ORB Icon Showerhead in optimal condition:

- **Cleaning:** Clean the showerhead regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the Oil Rubbed Bronze finish.
- **Mineral Deposits:** If mineral deposits accumulate on the spray nozzles, gently rub them with your finger or a soft brush to dislodge. For stubborn deposits, a solution of white vinegar and water can be

used, applied with a soft cloth.

- **Inspection:** Periodically inspect the showerhead and its connection for any signs of wear or leaks.

## 7. TROUBLESHOOTING

---

| Problem                    | Possible Cause  | Solution   |
|----------------------------|---|--|
| Low Water Flow             | Mineral buildup in nozzles; partially closed water valve. | Clean nozzles as described in Maintenance section; ensure water supply valve is fully open.                |
| Leaking at Connection      | Loose connection; insufficient thread sealant tape.       | Tighten connection slightly; turn off water, remove showerhead, reapply thread sealant tape, and reattach. |
| Inconsistent Spray Pattern | Blocked nozzles.  | Clean nozzles to remove debris or mineral deposits.  |

## 8. SPECIFICATIONS

---

- **Model:** S6312ORB
- **Finish:** Oil Rubbed Bronze
- **Flow Rate:** 2.5 GPM (9.5 L/Min) Max
- **Showerhead Diameter:** 5-7/8 inches
- **Function:** One-function, full spray
- **Connection:** 1/2-inch IPS
- **Material:** Metal, Plastic
- **Installation Type:** Wall Mounted
- **Item Weight:** 16 ounces

## 9. WARRANTY AND SUPPORT

---

This Moen product is backed by Moen's Limited Lifetime Warranty. For detailed warranty information, product support, or to purchase replacement parts, please visit the official Moen website or contact Moen customer service.

**Moen Customer Service:** Refer to your product packaging or the official Moen website for current contact information.

**Online Resources:** [www.moen.com](http://www.moen.com)