

[Manuals.plus](#) /

› [Sunnydaze Decor](#) /

› Sunnydaze Curved Wooden Hammock Stand (12 ft) Instruction Manual

Sunnydaze Decor WSN-WHS12

Sunnydaze Curved Wooden Hammock Stand (12 ft)

Model: WSN-WHS12 | Brand: Sunnydaze Decor

1. SAFETY INFORMATION

WARNING: Maximum weight capacity 400 lbs. Securely assemble and use the hammock stand according to these instructions. Keep the area around the hammock clear and ensure the stand is stable on a flat surface. Do not use without a hammock designed for this stand. Always check all connections before each use.

2. PRODUCT OVERVIEW

The Sunnydaze Curved Wooden Hammock Stand is designed to provide a stable and elegant support for your hammock. Constructed from durable larch wood with a warm, medium-tone tree oil finish, it is suitable for outdoor use. The stand features a curved arc design that accommodates most spreader bar hammocks ranging from 8 to 11 feet in length (ring to ring).

- **Material:** Larch wood with tree oil finish.
- **Weight Capacity:** 400 lbs, comfortably supporting two adults.
- **Dimensions:** 142.5 inches (W) x 50 inches (D) x 51 inches (H).
- **Hammock Compatibility:** Designed for spreader bar hammocks 8 to 11 feet long.

- 1 Crafted from larch wood with a tree oil finish
- 2 Unique arched design creates a dynamic shape without sacrificing comfort
- 3 Fits any 8 ft. to 11 ft. hammock




Figure 2.1: Key features of the hammock stand, including material, design, and capacity.




Figure 2.2: Detailed dimensions of the assembled hammock stand.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 6 Curved Larch Wood Pieces (for base and arcs)
- 8 Bolts
- 8 Washers
- 8 Nuts
- 2 Eye-bolts
- 2 Chains (20-inch each)
- 4 Carabiners (3-inch each)
- Basic Assembly Tools (wrenches)



1-YEAR
WARRANTY



U.S. BASED SELLER

Figure 3.1: The hammock stand components before hammock attachment.

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 30 minutes with two people. A socket wrench is recommended for faster and more secure tightening, though basic tools are included.

1. **Prepare the Base:** Lay out the base pieces on a flat, stable surface such as grass, a patio, or a deck. Ensure the beveled side of the legs points inward.
2. **Connect Base Pieces:** Insert the four bolts through the designated holes in the base pieces. Attach washers and nuts, but do not tighten completely at this stage. Keep the assembly loose to allow for alignment.
3. **Attach Arc Beams:** Carefully position the two curved arc beams onto the base. The bolt holes should align. A rubber mallet may be used for gentle tapping to help align the bolts through the holes. Ensure the countersunk

holes face outward.

4. **Secure Arc Beams:** Insert the remaining bolts through the arc beams and attach washers and nuts. Again, do not fully tighten yet.
5. **Tighten All Connections:** Once all bolts are in place, systematically tighten all nuts and bolts. Use two wrenches (or a socket wrench) to ensure a secure fit.
6. **Install Eye-bolts and Chains:** Screw the two eye-bolts into the top ends of the curved arc beams. Attach the 20-inch chains and 3-inch carabiners to the eye-bolts.
7. **Attach Hammock:** Connect your compatible spreader bar hammock (8-11 ft length) to the chains using the carabiners.



Figure 4.1: Detail of bolt connections during assembly.





Figure 4.2: Eye-bolt, chain, and carabiner for hammock attachment.

Video 4.1: Official Sunnydaze Decor video demonstrating the assembly and features of the wood curved hammock stand.

5. OPERATING INSTRUCTIONS

To ensure safe and enjoyable use of your hammock stand:

- **Placement:** Always place the hammock stand on a flat, level surface to prevent tipping.
- **Hammock Compatibility:** Use only spreader bar hammocks between 8 and 11 feet in length (from ring to ring). Using an incompatible hammock may result in instability or the hammock touching the ground.
- **Weight Limit:** Do not exceed the maximum weight capacity of 400 lbs.
- **Entry and Exit:** Enter and exit the hammock carefully to maintain stability. The wide-leg design helps reduce wobbling, but sudden movements should be avoided.
- **Clearance:** Ensure there is adequate clear space around the hammock stand to prevent accidental bumps or falls.

Figure 5.1: Guide for selecting a compatible hammock for your stand.



Figure 5.2: Example of proper hammock usage.

6. MAINTENANCE

To maximize the lifespan and appearance of your larch wood hammock stand:

- **Annual Sealing:** Apply a fresh coat of outdoor wood sealant annually. This helps protect the wood from moisture and UV damage.
- **Winter Storage:** During winter months or periods of prolonged inclement weather, store the stand under cover or indoors.
- **Cleaning:** Clean the wood with a soft cloth and mild soap solution. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically inspect all bolts, nuts, chains, and carabiners for tightness and signs of wear. Tighten any loose connections.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Wood splitting or cracking	Lack of proper sealing or exposure to harsh weather.	Apply outdoor wood sealant annually. Store indoors or under cover during winter.
Hammock touches the ground or hangs too low	Hammock is too long for the stand, or not a spreader bar type.	Ensure your hammock is a spreader bar type and measures between 8 and 11 feet (ring to ring). Adjust chain length if possible.
Stand feels unstable or wobbly	Not placed on a level surface; bolts are loose.	Relocate the stand to a flat, level surface. Check and tighten all bolts and nuts securely.
Difficulty aligning bolt holes during assembly	Pieces not properly positioned; minor manufacturing variations.	Ensure assembly is loose until all bolts are in place. Use a rubber mallet for gentle persuasion. Confirm beveled legs point inward and countersunk holes face outward.

8. SPECIFICATIONS

Feature	Detail
Model Number	WSN-WHS12
Brand	Sunnydaze Decor
Material	Larch Wood
Color	Brown
Product Dimensions (L x W x H)	142.5" x 50" x 51"
Item Weight	50 pounds
Maximum Weight Recommendation	400 pounds
Seating Capacity	2 people
Compatible Hammock Length	8 to 11 feet (ring to ring)
Included Components	Stand, Chains, Carabiners

9. WARRANTY AND SUPPORT

This Sunnydaze Curved Wooden Hammock Stand is backed by a **1-year manufacturer warranty**.



Figure 9.1: Sunnydaze Decor 1-Year Warranty information.

For warranty claims, missing parts, or any product-related inquiries, please contact Sunnydaze Decor customer support directly. Refer to your purchase documentation or the official Sunnydaze Decor website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question