

Pet Control HQ EDFRT2

Wireless Dog Fence System Instruction Manual

Model: EDFRT2 | Brand: Pet Control HQ

1. PRODUCT OVERVIEW

The Pet Control HQ Wireless Dog Fence System provides a comprehensive solution for pet containment and training. This system combines a wired perimeter fence with a remote training collar, offering flexibility for various yard sizes and training needs. It is designed to provide a safe and effective boundary for your pets, allowing them to roam freely within a defined area.

Key features include:

- Wireless containment system suitable for large yards and complex spaces, offering up to 10 acres of safe roaming with additional wire.
- Dual-zone system with 492 feet of 20 AWG solid copper core wire for inground, above-ground, or underground installation.
- Ability to control up to 3 separate shock collars (additional collars sold separately) with beep and vibration modes (levels 1-10).
- Electric shock collar with adjustable levels (1-10) for effective behavior correction.
- 12-hour electronic anti-bark collar feature with an 8-second safety shutdown switch.
- Long-lasting rechargeable batteries for 3 to 7 days of use, with a rapid 2-3 hour charging time.
- Lightweight, waterproof (IPX7 rated), and rechargeable collar-receiver with an adjustable strap (8-27 inches) suitable for dogs weighing 11-154 pounds.



Figure 1: Overview of the Pet Control HQ Wireless Dog Fence System components.

2. COMPONENTS INCLUDED

Your Pet Control HQ Wireless Dog Fence System package includes the following items:

- Main Transmitter Unit
- Rechargeable Remote Control
- Dog Collar Receivers (Quantity as per package, e.g., 2 for "2 Dogs with Remote" style)
- 492 ft. (150m) of 20 AWG Solid Copper Core Boundary Wire
- Power Adapters for Transmitter and Collars
- Contact Points (short and long)
- Test Light Tool
- Boundary Flags
- Wire Splice Connectors

- User Manual (this document)



Figure 2: All included components of the system.

3. SETUP AND INSTALLATION

Careful setup is crucial for the effective operation of your dog fence system. Read all instructions before beginning installation.

3.1 Planning Your Boundary

Determine the area where you want to contain your dog(s). The system supports both wired perimeter and wireless remote training. The wired system allows for custom shapes and sizes up to 10 acres with additional wire. Consider obstacles, driveways, and areas you want your dog to avoid.



Figure 3: Example of a wired perimeter setup around a house.

HEAVY-DUTY SOLID COPPER WIRE



492FT OF
20 AWG WIRE



WITHSTANDS
ANY WEATHER



CUSTOMIZABLE
FENCING PERIMETER



Figure 4: The system is versatile for different containment needs.

3.2 Installing the Boundary Wire

The 492 ft. of 20 AWG solid copper core wire can be installed inground, above-ground, or attached to existing fences. For inground installation, bury the wire a few inches deep to protect it. Ensure the wire forms a continuous loop back to the main transmitter unit. Use splice connectors for any breaks or extensions.

3/4 MILE LONG RANGE REMOTE



TRAINS UP TO
3 DOGS AT ONCE



3 FUNCTIONS:
BEEPS, VIBRATES,
SHOCKS



10 VIBRATION AND
SHOCK LEVELS

WATERPROOF ADJUSTABLE COLLARS



RECHARGEABLE



BATTERY LASTS
FOR 3-7 DAYS



SUITABLE FOR S,
M, L, XL DOGS



Figure 5: The durable 20 AWG solid copper wire is designed to withstand various weather conditions.



Figure 6: The system is ideal for challenging yard layouts and intricate spaces.

3.3 Transmitter Unit Setup

Connect the boundary wire to the main transmitter unit. Plug the transmitter into a standard electrical outlet. Adjust the boundary width dial on the transmitter to set the desired range of the signal. Test the signal strength using the provided test light tool by walking along the planned boundary.

DUAL TRAINING PET CONTAINMENT SYSTEM

DUAL TRAINING SYSTEM

Can be used together as a wireless remote training collar and a wired boundary system. Or used independently of each other.

Wireless
Remote



OR



492 ft. 20-gauge
solid core wire



LONG BATTERY LIFE

Lasts 3-7 Days (with a rapid
2-3 hours recharge)

Figure 7: The system offers dual training capabilities, combining wired and wireless options.

3.4 Collar Preparation

Charge the collar receivers fully before first use. Attach the appropriate contact points (short for short-haired dogs, long for long-haired dogs) to the collar receiver. Ensure the contact points make proper contact with your dog's skin. The collar should be snug enough not to slide around, but loose enough to allow two fingers to fit comfortably under the strap.

MULTIPLE DOG TRAINING SYSTEM FOR SMALL AND LARGE DOGS

- ✓ Add more collars as your pet family expands to keep every dog safe.
- ✓ 8" to 27" neck size
- ✓ 11-154 lbs. dogs



Train up to 3 dogs at the same time using the remote control



Pet Control HQ

Figure 8: The collars are IPX7 rated, making them waterproof and suitable for various conditions.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The remote control allows for direct training and correction. It features:

- **Beep Mode:** Emits an audible tone.
- **Vibration Mode:** Provides a tactile vibration (Levels 1-10).
- **Shock Mode:** Delivers a static correction (Levels 1-10).
- **Dog Selection Buttons:** Allows you to select and control up to 3 individual collars.

The remote has a range of up to 3/4 mile in an open field, providing ample coverage for training sessions.



Figure 9: The remote control offers a long range for effective training.

4.2 Collar Receiver Response

When a dog approaches the wired boundary, the collar receiver will respond with a progressive series of warnings:

1. **Warning Tone:** An audible beep will sound as the dog nears the boundary.
2. **Vibration:** If the dog continues, a vibration will be activated.
3. **Static Correction:** If the dog persists in crossing the boundary, a static correction will be delivered, increasing in intensity across 3 levels.

This progressive correction helps the dog understand and respect the boundary.

CUSTOM COVERAGE FOR ANY YARD

FASTER TRAINING

3-levels of automatic progressive correction stimulates more as your dogs get closer to the fence.

Perimeter training to keep your pup safe and contained.



Custom above or below ground wired design gives your bestfriend up to 10 acres of safe roaming with additional wire purchased from Pet Control HQ.

Figure 10: The system provides perimeter training to keep your dog safe and contained.

5. TRAINING GUIDELINES

Effective training is key to successful use of the Pet Control HQ system. Begin with short, positive training sessions.

- **Introduce Boundary Flags:** Place boundary flags around the perimeter to visually mark the boundary for your dog.
- **Leash Training:** Walk your dog on a leash around the boundary, allowing them to encounter the warning tone. Praise and reward them when they retreat from the boundary.
- **Progressive Correction:** Start with lower correction levels and gradually increase if necessary, observing your dog's reaction. The goal is to get their attention, not to cause distress.
- **Consistency:** Conduct regular, short training sessions (e.g., 10-15 minutes, 2-3 times a day) until your dog consistently respects the boundary.
- **Remote Training:** Use the remote control for specific behavioral corrections, such as stopping digging or excessive barking. Utilize the beep and vibration modes first before resorting to static correction.



Pet Control HQ

RECHARGEABLE AND WATERPROOF

IPX7 - RATED

30 minutes of waterproof
swimming at a maximum
depth of 3.3ft

Figure 11: The system supports training for multiple dogs simultaneously.

STOP STUBBORN BEHAVIOR FAST

Dog Fence Collar has beep, vibration, plus increasing levels of correction. Remote Training Collar has 1-10 levels of vibration or shock intensity.



Pet Control HQ

Figure 12: The collar's correction modes are designed to help correct unwanted behaviors.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your system.

- **Collar Cleaning:** Periodically clean the collar receiver and contact points with a damp cloth. Ensure no dirt or debris accumulates around the contact points, which could affect conductivity.
- **Battery Charging:** Recharge collar batteries every 3-7 days, depending on usage. The rapid charging station fully charges batteries in 2-3 hours. Ensure the charging ports are sealed with the provided rubber plugs when not charging to maintain waterproofing.
- **Wire Inspection:** Regularly inspect the boundary wire for any damage, especially if installed above ground. Repair any breaks using the provided splice connectors to maintain the circuit.
- **Transmitter Placement:** Keep the transmitter unit in a dry, protected area, away from extreme temperatures and moisture.

7. TROUBLESHOOTING

If you encounter issues with your Pet Control HQ system, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Collar not correcting / No signal	Collar not charged. Contact points not touching skin. Boundary wire break. Transmitter not powered on or faulty. Boundary width set too low.	Charge collar fully. Adjust collar fit and/or use longer contact points. Inspect wire for breaks and repair with splice connectors. Ensure transmitter is plugged in and powered. Check loop indicator light. Increase boundary width on transmitter.
Remote not controlling collar	Remote battery low. Collar not paired with remote. Out of remote range.	Charge remote. Refer to pairing instructions in the full manual (if available). Move closer to the dog.
Collar beeping/vibrating/shocking randomly	Interference from other electronic devices. Dog is too close to the boundary wire.	Relocate transmitter or collar away from sources of interference. Ensure dog is not near the boundary when not intended.

For further assistance, please contact Pet Control HQ customer support.

8. SPECIFICATIONS

Feature	Detail
Model Name	Dog-deluxe-combo
Item Model Number	EDFRT2
Brand	Pet Control HQ
Item Weight	4.8 Pounds
Product Dimensions	13.39 x 12.99 x 2.83 inches
Wire Length Included	492 feet (20 AWG solid copper core)
Max Coverage (with additional wire)	Up to 10 acres
Remote Range	Up to 3/4 mile (in open field)
Collar Neck Size Fit	8 - 27 inches
Suitable Dog Weight	11 - 154 pounds
Collar Waterproof Rating	IPX7
Battery Type	Lithium Ion (rechargeable)

Feature	Detail
Battery Life (Collar)	3-7 days
Charging Time	2-3 hours
Country of Origin	China

9. WARRANTY AND SUPPORT

The Pet Control HQ Wireless Dog Fence System comes with a**1-Year Warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your product, please contact Pet Control HQ customer service. Refer to the contact information provided on the product packaging or the official Pet Control HQ website.

Important: Read all instructions before use. Ensure proper fit and training for the safety and well-being of your pet.

© 2024 Pet Control HQ. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question