

AROMA ASP-600

AROMA Stainless Steel Hot Pot (ASP-600) - Instruction Manual

Model: ASP-600 | Brand: AROMA

INTRODUCTION

The AROMA Electric Shabu Shabu Hot Pot is designed to provide a flavorful hot pot experience at home. Featuring integrated dual compartments, it allows for cooking two different broths simultaneously. The stainless steel pot is a single piece with a built-in divider, ensuring flavors remain separate. With 1500 watts of power, it heats quickly and evenly, offering precise temperature control for cooking various ingredients. Both the removable stainless steel pot and tempered glass lid are dishwasher safe for easy cleanup.

Key Features

- **Timelessly Traditional Design:** Combines traditional Shabu Shabu features with a stainless steel aesthetic.
- **Dual Compartments:** Cook two broths simultaneously with a built-in stainless steel divider. Note: The pot is a single piece, and sections are not removable.
- **Convenient Design:** The cooking pot detaches from the heating base for easy cleaning and storage. Features a tempered glass lid and cool-touch handles.
- **All-in-One Set:** Includes adjustable heating base, dual-section stainless steel pot, and steam vent lid.
- **Powerful Heating:** 1500 Watts for fast and even cooking (120 volt/60Hz).
- **Adjustable Power Dial:** For precise temperature control.
- **Easy Cleanup:** Removable pot and tempered glass lid are dishwasher safe.

SAFETY PRECAUTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.

- To protect against electrical shock, do not immerse cord, plug, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your AROMA Stainless Steel Hot Pot for optimal use.

CONVENIENT DESIGN

Features a dishwasher-safe glass lid and stainless steel body that detaches from the heating base for effortless cleanup.



Figure 1: Exploded view of the AROMA Hot Pot, highlighting its main components.

- **Tempered Glass Lid:** Features a cool-touch handle and steam vent.
- **Stainless Steel Pot:** 5-quart capacity with dual compartments and cool-touch side handles.
- **Heating Base:** Houses the heating element and control panel.
- **Adjustable Temperature Dial:** For setting desired heat levels.
- **Power Cord:** Detachable for safe storage.

INITIAL SETUP

Before using your AROMA Hot Pot for the first time, please follow these steps:

1. Unpack all components and remove any packaging materials.
2. Wash the stainless steel pot and tempered glass lid with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the heating base with a damp cloth. Do not immerse the heating base in water.
4. Place the heating base on a dry, level, heat-resistant surface.
5. Carefully place the clean stainless steel pot onto the heating base, ensuring it is seated correctly.

OPERATING INSTRUCTIONS

Follow these instructions to use your AROMA Hot Pot:

1. Preparing for Cooking

1. Ensure the hot pot is properly assembled on its heating base.
2. Fill the dual compartments with your desired broths or liquids. Do not overfill; leave adequate space for ingredients.
3. Prepare your ingredients (meats, vegetables, noodles, etc.) and have them ready for cooking.

2. Powering On and Temperature Control



Figure 2: The adjustable power dial for precise temperature management.

4. Insert the detachable power cord into the hot pot's receptacle, then plug the other end into a standard 120V AC electrical outlet.
5. Turn the adjustable temperature dial to your desired heat setting (Low, Mid, or High). The indicator light will illuminate.
6. Allow the broth to heat up. The 1500-watt heating element ensures rapid heating.

3. Cooking with Dual Compartments

DUAL COMPARTMENTS

Versatile 2-in-1 design allows you to prepare and enjoy two different broth flavors at the same time.



Figure 3: The dual compartment design allows for two distinct broth flavors.

7. Once the broth is simmering or boiling, add your ingredients to the respective compartments.
8. Use the tempered glass lid to cover the pot, trapping heat and steam for efficient cooking.
9. Cook ingredients to your preference. The cool-touch handles allow for safe serving directly at the table.

4. Capacity

5 QUART CAPACITY

Large 12-inch diameter and stainless steel construction makes feeding the whole family easier than ever!



Figure 4: The 5-quart capacity is suitable for family meals.

The hot pot has a generous 5-quart capacity, making it ideal for family meals or small gatherings.

5. After Use

10. Turn the temperature dial to "OFF" and unplug the power cord from the wall outlet.
11. Allow the hot pot to cool completely before handling or cleaning.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your AROMA Hot Pot.

- **Removable Pot:** The stainless steel pot can be lifted out of the heating base for easy cleaning. It is dishwasher safe.
- **Tempered Glass Lid:** The lid is also dishwasher safe.
- **Heating Base:** Wipe the heating base with a damp cloth. Do not immerse it in water or any other liquid. Ensure it is completely dry before storing or next use.
- Do not use abrasive cleaners or scouring pads on any part of the hot pot, as this may damage the surfaces.

TROUBLESHOOTING

If you encounter any issues with your AROMA Hot Pot, refer to the following common problems and solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into both the appliance and a working electrical outlet. Check if the temperature dial is set to an active heating level (not OFF).
- **Food not cooking evenly:** Ensure the pot is properly seated on the heating base. Stir ingredients occasionally for more even cooking.
- **Liquid not boiling:** Verify the temperature dial is set to a higher heat setting. Allow sufficient time for the liquid to reach boiling point.
- **Excessive noise during operation:** Some noise is normal during heating. If the noise is unusually loud or persistent, ensure the pot is correctly placed on the base and there are no obstructions.

For further assistance, please contact AROMA customer support.

PRODUCT SPECIFICATIONS

Specification	Value
Brand	AROMA
Model Number	ASP-600
Color	Silver
Material	Stainless Steel
Product Dimensions	16.25"D x 13"W x 8.5"H
Capacity	5 Quarts
Wattage	1500 watts
Voltage	120 Volts
Control Method	Touch (Dial)
Number of Settings	3 (Low, Mid, High)
Dishwasher Safe	Yes (Removable Pot & Lid)

WARRANTY AND CUSTOMER SUPPORT

AROMA Housewares products are manufactured to the highest quality standards. For specific warranty information regarding your ASP-600 hot pot, please refer to the warranty card included in your product packaging or visit the official AROMA Housewares website.

If you require technical support, have questions about your product, or need to make a warranty claim, please contact AROMA customer service through their official channels.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: An official overview of the Aroma Stainless Steel Hot Pot, Silver (ASP-600), demonstrating its features and use.