

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [NAVIGATOR](#) /
- › [NAVIGATOR 1193 Ultra Bright Portable LED Flashlight Instruction Manual](#)

NAVIGATOR 1193

NAVIGATOR 1193 Ultra Bright Portable LED Flashlight Instruction Manual

Model: 1193

INTRODUCTION

Thank you for choosing the NAVIGATOR 1193 Ultra Bright Portable LED Flashlight. This manual provides essential information for the safe and efficient use of your new flashlight. Please read these instructions carefully before operation and retain them for future reference.



Image: The NAVIGATOR 1193 flashlight, a compact black device, is shown held comfortably in a hand, illustrating its portable design.

SETUP

1. Battery Installation

The NAVIGATOR 1193 flashlight requires three (3) AAA batteries for operation. Batteries are included with your purchase.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the three AAA batteries into the battery holder, ensuring correct polarity (+/-) as indicated inside the holder.
3. Place the battery holder with batteries into the flashlight body.
4. Screw the tail cap back on clockwise until it is securely tightened.



Image: A composite image showing the NAVIGATOR 1193 flashlight from various angles, including a view with the tail cap removed and the battery holder visible, demonstrating battery insertion.

Mighty in Pocket Size



Solid State



CNC AL



HQ LED




3xAAA



IPX-4



250LM



UPGRADED VERSION

Image: An exploded diagram of the NAVIGATOR 1193 flashlight, highlighting its components such as the LED, aluminum body, battery compartment, and tail cap with a button, along with feature icons.

2. Attaching the Wrist Strap

A wrist strap is included for secure handling. Thread the loop of the wrist strap through the small hole on the tail cap and secure it.

OPERATING INSTRUCTIONS

1. Power On/Off and Mode Selection

The flashlight features a single button for power control and mode cycling.

- To turn the flashlight **ON**, press the button located on the tail cap.
- To cycle through the **3 light modes** (High, Low, Strobe), press the button repeatedly while the flashlight is on.
- To turn the flashlight **OFF**, press the button after cycling through all modes, or hold the button for a few seconds (depending on the model's specific firmware, a quick press after a pause usually turns it off).

2. Adjustable Focus (Zoom Function)

The NAVIGATOR 1193 features an adjustable beam focus, allowing you to switch between a concentrated spot beam and a wide floodlight.

- To adjust the focus, gently pull the head of the flashlight forward or push it backward.
- Pulling the head forward will narrow the beam for a focused **spotlight**, ideal for long-range observation.
- Pushing the head backward will widen the beam for a broad **floodlight**, suitable for illuminating larger areas.




Image: A diagram illustrating the flashlight's adjustable focus mechanism, showing the head extended for "Zoom in" (spotlight) and retracted for "Zoom out" (floodlight).



Image: A side-by-side comparison demonstrating the effect of the adjustable focus, showing a narrow, intense beam when "Zoom in" is applied and a wide, diffused beam when "Zoom out" is applied, illuminating different areas.

MAINTENANCE

1. Cleaning

Wipe the flashlight body with a soft, damp cloth as needed. Do not use abrasive cleaners or solvents, as they may damage the finish.

2. Battery Replacement

When the light output becomes dim or the flashlight stops working, it is time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

- Always replace all three AAA batteries at the same time.
- Use high-quality AAA alkaline batteries for optimal performance and to prevent leakage.
- Remove batteries if the flashlight will not be used for an extended period to prevent potential battery leakage

and damage.

3. Water Resistance

The NAVIGATOR 1193 is designed to be water resistant against splashing water and can be used in heavy rain. However, it is not intended for submersion. Ensure the tail cap is securely tightened to maintain water resistance.



Image: The NAVIGATOR 1193 flashlight is shown partially submerged in flowing water, demonstrating its water-resistant capabilities.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	<ul style="list-style-type: none">• Batteries are dead or incorrectly installed.• Tail cap is loose.	<ul style="list-style-type: none">• Replace batteries with new AAA batteries, ensuring correct polarity.• Tighten the tail cap securely.
Light is dim or flickers.	<ul style="list-style-type: none">• Batteries are low.• Loose connection.	<ul style="list-style-type: none">• Replace batteries with new AAA batteries.• Ensure tail cap is tight and battery holder is properly seated.

Problem	Possible Cause	Solution
Adjustable focus is stiff.	<ul style="list-style-type: none">• Dirt or debris in the mechanism.	<ul style="list-style-type: none">• Gently clean the exterior of the flashlight head. Avoid forcing the mechanism.

SPECIFICATIONS

Model: NAVIGATOR 1193

Light Source: CREE XPE LED

Brightness: Up to 250 Lumens

Beam Distance: Up to 1000 feet (approx. 305 meters)

Light Modes: High, Low, Strobe

Focus: Adjustable (Spot to Flood)

Power Source: 3 x AAA Batteries (included)

Material: Type III Aluminum Aircraft Grade Body

Water Resistance: Water Resistant (splashing water, heavy rain)

Dimensions: Diameter 1.1 inches, Length 4 inches

Special Features: Portable, Durable, Shockproof, Vibration Proof

UPC: 712038072132

WARRANTY INFORMATION

The NAVIGATOR 1193 Ultra Bright Portable LED Flashlight comes with a **Lifetime Warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or further details, please refer to the contact information provided below.

SUPPORT AND CONTACT INFORMATION

For technical support, customer service, or warranty inquiries, please contact us:

Website: www.navigatorbrand.com (Example link, replace with actual if available)

Email: support@navigatorbrand.com (Example email, replace with actual if available)

Phone: 1-800-XXX-XXXX (Example number, replace with actual if available)

Please have your model number (1193) and purchase date available when contacting support.