

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Takeya](#) /

› [Takeya Originals Spout Lid Instruction Manual](#)

Takeya 97126

Takeya Originals Spout Lid Instruction Manual

Model: 97126

INTRODUCTION

The Takeya Originals Spout Lid is a replacement lid designed for Takeya water bottles. It features a convenient spout for easy drinking and a carry handle for portability. This lid is leak-proof, BPA-free, and dishwasher safe, ensuring both safety and ease of maintenance. It is compatible with various Takeya bottle sizes, including Actives, Originals, Pickleball, and Tritan models.



Image: The Takeya Originals Spout Lid in black, shown with its spout open and the integrated carry handle extended, ready for use.

SETUP

1. **Unpack:** Remove the spout lid from its packaging.
2. **Initial Cleaning:** Before first use, wash the lid thoroughly with warm, soapy water or place it on the top rack of a dishwasher. Ensure all components, including the silicone ring, are clean.
3. **Attach to Bottle:** Align the lid with the opening of your Takeya water bottle. Twist clockwise until securely tightened. Ensure the silicone ring is properly seated to prevent leaks.



Image: The underside of the Takeya Originals Spout Lid, highlighting the silicone seal that ensures a leak-proof fit when attached to a bottle.

OPERATING INSTRUCTIONS

1. **Opening the Spout:** To drink, simply twist the small cap on the spout counter-clockwise. The spout will pop open, allowing direct access for sipping.
2. **Closing the Spout:** After drinking, push the spout cap down and twist clockwise until it clicks into place, ensuring a secure, leak-proof seal.
3. **Using the Carry Handle:** The integrated carry handle can be used to transport your bottle easily. It folds up and down for convenience.
4. **Adding Ice:** The wide mouth design of Takeya bottles, compatible with this lid, allows for easy addition of ice cubes.

Your browser does not support the video tag.

Video: This official Takeya video demonstrates the features and ease of use of the Takeya Originals bottle, including the spout lid, wide mouth, and carry handle, highlighting its suitability for an active lifestyle.

MAINTENANCE

- **Dishwasher Safe:** The Takeya Originals Spout Lid is top-rack dishwasher safe for convenient cleaning.
- **Hand Washing:** For thorough cleaning, hand wash the lid with warm, soapy water. Ensure to clean around the spout mechanism and the silicone seal to prevent residue buildup.
- **Drying:** Allow the lid to air dry completely before reassembling or storing to prevent moisture

accumulation.

Image: A hand pouring water into a Takeya bottle, demonstrating the wide mouth design which facilitates easy cleaning and filling with ice or liquids.

TROUBLESHOOTING

- **Leakage:** If the lid is leaking, ensure it is securely tightened onto the bottle. Check the silicone seal for proper placement and any signs of damage or wear. A damaged seal may need replacement.
- **Spout Difficulty:** If the spout is difficult to open or close, ensure it is clean and free of debris. Regular cleaning can prevent stickiness.

SPECIFICATIONS

Feature	Detail
Model Number	97126
Brand	Takeya
Material	Plastic
Color	Black (also available in White, Graphite, Ocean)
Product Dimensions	1.88"L x 2.75"W
Item Weight	1.6 ounces
Dishwasher Safe	Yes
Microwaveable	Yes
BPA-Free	Yes



Image: The Takeya Originals Spout Lid held in a hand, with overlaid text showing its dimensions as 2.0 inches (5 cm) in height.

WARRANTY

Each Takeya Originals product comes with a limited lifetime guarantee. For specific details regarding the terms and conditions of this warranty, please refer to the official Takeya website or contact customer support.

SUPPORT

For further assistance, product information, or to explore other Takeya products, please visit the official Takeya website or their Amazon store:

- [Visit the Takeya Store on Amazon](#)