

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HP](#) /
- › [HP Z420 Workstation User Manual](#)

HP Z420

HP Z420 Workstation User Manual

Model: Z420

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP Z420 Workstation. Please read these instructions carefully to ensure proper use and longevity of your device. The HP Z420 Workstation is designed for demanding professional applications, offering robust performance and expandability.



Front view of the HP Z420 Workstation, showcasing the black tower design, optical drive bays, front USB ports, audio jacks, and power button.

SETUP

Follow these steps to set up your HP Z420 Workstation:

1. **Unpacking:** Carefully remove the workstation and all accessories from the packaging. Ensure that the included

keyboard and mouse are present.

2. **Placement:** Position the workstation on a stable, flat surface with adequate ventilation. Avoid placing it in direct sunlight or near heat sources.
3. **Connect Peripherals:**
 - Connect your monitor(s) to the appropriate video output ports on the back of the workstation.
 - Connect the included keyboard and mouse to the available USB ports.
 - Connect any other necessary peripherals (e.g., printer, external drives) to the available ports.
4. **Network Connection:** Connect an Ethernet cable from your network router or switch to the LAN port on the back of the workstation for wired internet access.
5. **Power Connection:** Connect the power cord to the power supply unit on the back of the workstation, then plug the other end into a grounded electrical outlet.

OPERATING INSTRUCTIONS

This section outlines the basic operation of your HP Z420 Workstation.

Powering On and Off

- **To Power On:** Press the power button located on the front panel of the workstation. The system will boot into the Windows operating system.
- **To Power Off:**
 - From the Windows desktop, click the *Start* button, then select *Power*, and choose *Shut down*.
 - Alternatively, you can press and hold the power button for several seconds to force a shutdown, but this is not recommended for regular use as it may lead to data loss.

Key Features

The HP Z420 Workstation is equipped with high-performance components to handle demanding tasks:

- **Processor:** Features an 8-core Intel Xeon E5-2670 CPU operating at up to 3.3GHz with a 20MB cache, providing significant processing power for complex computations and multitasking.
- **Memory:** Equipped with 64GB of DDR3 RAM, ensuring smooth multitasking and rapid data access for memory-intensive applications.
- **Storage:** Includes a 1TB Solid State Drive (SSD) for quick boot times and fast application loading, complemented by a 4TB Hard Disk Drive (HDD) for ample storage of large files and projects.
- **Networking:** Integrated LAN connectivity provides a fast and reliable wired network connection.
- **Graphics:** Features a dedicated NVIDIA Quadro K4000 graphics coprocessor with 2GB of RAM, suitable for professional graphics applications and CAD.

MAINTENANCE

Regular maintenance helps ensure the optimal performance and longevity of your workstation.

- **Cleaning:**
 - Periodically clean the exterior of the workstation with a soft, damp cloth.
 - Use compressed air to clear dust from ventilation grilles and ports to prevent overheating. Ensure the system is powered off before cleaning.
- **Software Updates:** Regularly check for and install operating system updates (Windows) and driver updates for

your hardware components to maintain security and performance.

- **Data Backup:** Regularly back up important data to an external drive or cloud storage to prevent data loss.
- **System Monitoring:** Monitor system temperatures and disk usage to identify potential issues early.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter.

- **No Power:**
 - Ensure the power cord is securely connected to both the workstation and the electrical outlet.
 - Verify the electrical outlet is functional by plugging in another device.
 - Check the power supply unit for any indicator lights.
- **No Display:**
 - Confirm the monitor is powered on and connected correctly to the workstation's video output.
 - Try connecting the monitor to a different video port if available.
 - Ensure the monitor's input source is set correctly.
- **System Slowdown:**
 - Close unnecessary applications running in the background.
 - Check for sufficient free space on the primary drive (SSD).
 - Run a system scan for malware or viruses.
 - Ensure all drivers and the operating system are up to date.
- **Peripheral Not Responding:**
 - Ensure the peripheral is properly connected to a functional USB port.
 - Try connecting the peripheral to a different USB port.
 - Restart the workstation.
 - Check the manufacturer's website for specific drivers for the peripheral.

SPECIFICATIONS

Detailed technical specifications for the HP Z420 Workstation.

Feature	Specification
Brand	HP
Model Name	Z420
Processor	Intel Xeon E5-2670 (8-Core, up to 3.3 GHz)
Processor Cache	20 MB
RAM	64 GB DDR3 SDRAM
Primary Storage	1 TB SSD
Secondary Storage	4 TB HDD
Hard Drive Interface	Serial ATA

Feature	Specification
Graphics Coprocessor	NVIDIA Quadro K4000
Graphics Card RAM Size	2 GB
Operating System	Windows
Optical Drive Type	DVD-ROM
Hardware Platform	PC
Color	Black
Item Weight	41 pounds
Product Dimensions (LxWxH)	18.5 x 6.7 x 17.6 inches
Included Components	Keyboard, Mouse

WARRANTY AND SUPPORT

This HP Z420 Workstation is a renewed product and comes with a 3-year warranty as indicated in the product title. For specific warranty details and support, please refer to the documentation provided with your purchase or contact the seller directly. Renewed products are typically eligible for replacement or refund under the Amazon Renewed Guarantee if not satisfied with the purchase.

For technical assistance or further inquiries, please consult the official HP support resources or the vendor from whom the renewed product was purchased.