

[Manuals.plus](#) /

› [BRITA](#) /

› Brita Metro 6-Cup Water Filter Pitcher User Manual (Model 61728)

BRITA 61728

Brita Metro 6-Cup Water Filter Pitcher User Manual

Model: 61728

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Brita Metro 6-Cup Water Filter Pitcher. Please read these instructions carefully before first use and retain for future reference.

PRODUCT COMPONENTS

Your Brita Metro 6-Cup Water Filter Pitcher includes the following components:

- Brita Metro Pitcher (6-cup capacity)
- Pitcher Lid with Electronic Filter Indicator
- Water Filter Reservoir
- 1 Standard Brita Water Filter



Image: The Brita Metro 6-Cup Water Filter Pitcher in turquoise, showing the pitcher body, lid, and internal filter reservoir.

SETUP INSTRUCTIONS

1. **Wash Hands:** Before handling the filter, wash your hands thoroughly.
2. **Prepare Filter:** Flush the new Brita Standard Water Filter under cold tap water for 15 seconds. This helps remove any loose carbon dust.



Image: A close-up of a Brita Standard Water Filter, ready for flushing.

3. **Insert Filter:** Insert the prepared filter firmly into the designated opening in the water filter reservoir. Ensure it is seated securely to prevent unfiltered water from passing through.



Image: A Brita Standard Water Filter being inserted into the pitcher's reservoir.

4. **Fill Pitcher:** Add cold tap water to the reservoir. The water will slowly filter into the main pitcher body.
5. **Discard First Pitchers:** The first three pitchers of filtered water may contain harmless carbon dust. It is recommended to use this water for plants or discard it. After the third pitcher, the water is ready for consumption.

OPERATION

Refilling the Pitcher

To refill, simply open the flip-top lid and pour cold tap water into the reservoir. The water will filter through automatically. Do not overfill the reservoir beyond the indicated maximum fill line.

Electronic Filter Indicator

The lid features an electronic filter indicator that tracks filter life. It will notify you when it's time to replace the filter. Press the 'Start' button on the indicator after installing a new filter to reset it. The indicator typically uses a series of lights or bars to show remaining filter life.

When the indicator shows that the filter life is depleted, it's time for a replacement.

MAINTENANCE

Filter Replacement

For optimal performance and water quality, replace the Brita Standard Water Filter every 40 gallons or approximately every 2 months, whichever comes first. Follow the 'Setup Instructions' for installing a new filter.

Cleaning the Pitcher

The pitcher, lid, and reservoir (excluding the filter) can be hand-washed with mild detergent and warm water. Do not wash the electronic filter indicator in a dishwasher or submerge it in water. Rinse all components thoroughly before reassembly.

TROUBLESHOOTING

- **Slow Filtration:** If water filters slowly, ensure the filter is properly seated in the reservoir. If the filter is old, it may be clogged and require replacement.
- **Carbon Dust in Water:** It is normal to see small black flecks (carbon dust) in the first few pitchers of water after installing a new filter. This is harmless. Discard the first three pitchers as instructed in the setup guide.
- **Electronic Indicator Not Working:** Ensure the indicator is clean and dry. If it still doesn't work after pressing the reset button, contact Brita customer support.

SPECIFICATIONS

Feature	Detail
Brand	BRITA
Model Name	Metro Turquoise
Model Number	61728
Capacity	6 cups (5 cups listed in some specifications)
Material	Plastic (BPA Free)
Product Dimensions (L x W x H)	15.59" x 10.16" x 5.63"
Item Weight	1.2 pounds
Purification Method	Activated Carbon
Filter Life Cycle	2 months (or 40 gallons)




Image: The Brita Metro Pitcher with an overlay indicating its height of 10 inches (24 cm).

SAFETY INFORMATION

- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- Keep out of reach of children.
- Do not expose the pitcher to direct sunlight for extended periods.
- Only use genuine Brita replacement filters.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the official Brita website or contact their customer service directly. Details can typically be found on the product packaging or the manufacturer's website.

You can also visit the [BRITA Store on Amazon](#) for more product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B01G9ADQYG>

More documents and user manuals: <https://manuals.plus/>