

[Manuals.plus](#) /

› [Quorum International](#) /

› Quorum 97215-86 Windmill 72 Inch Ceiling Fan Instruction Manual

## Quorum International 97215-86

# Quorum 97215-86 Windmill 72 Inch Ceiling Fan Instruction Manual

Model: 97215-86 | Brand: Quorum International

## 1. INTRODUCTION AND SAFETY INFORMATION

---

This manual provides essential instructions for the safe installation, operation, and maintenance of your Quorum 97215-86 Windmill 72 Inch Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or personal injury.

### Important Safety Precautions:

- Always disconnect power at the circuit breaker before installation or servicing.
- All electrical wiring must be performed by a qualified electrician and conform to local codes and national electrical codes.
- Ensure the installation site can support the fan's weight (approximately 48 pounds). The outlet box must be marked 'Acceptable for Fan Support of 35 lbs (15.9 kg) or less'.
- Do not operate the fan with damaged blades or housing.
- Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades.
- This fan is rated for dry indoor locations only. Do not install in damp or wet environments.

## 2. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact Quorum International customer service.

- Fan Motor Assembly
- 15 Weathered Oak Plywood Blades
- Blade Brackets and Hardware
- Canopy and Mounting Bracket
- 6-inch Downrod
- Handheld Remote Control (with wall mount)
- Installation Hardware (screws, washers, wire nuts)
- Instruction Manual

## 3. SETUP AND INSTALLATION

---

Installation of this ceiling fan requires electrical knowledge. If you are unsure about any steps, consult a qualified electrician. A detailed installation manual (PDF) is available for download: [Download Installation Manual \(PDF\)](#)

## Overview of Installation Steps:

1. **Turn off Power:** Locate the circuit breaker for the fan's electrical box and turn off the power.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling electrical box. Ensure the box is fan-rated and capable of supporting the fan's weight.
3. **Downrod Assembly:** Attach the downrod to the fan motor assembly.
4. **Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the detailed manual.
5. **Hang Fan:** Carefully lift and hang the fan motor assembly onto the mounting bracket.
6. **Canopy Installation:** Secure the canopy to cover the wiring connections.
7. **Blade Assembly:** Attach the 15 weathered oak blades to the blade brackets, then secure the blade assemblies to the fan motor.
8. **Power On:** Restore power at the circuit breaker and test the fan.



Image: The Quorum Windmill 72 Inch Ceiling Fan installed in a living room, highlighting its dry rating and 6-speed reversible motor.

# Windmill



---

72 Inches

6" downrod included

Image: A detailed view of the Windmill fan, illustrating its 72-inch blade sweep and the included 6-inch downrod.

# 15 x Weathered Oak Blades




Image: A close-up shot of the fan's 15 weathered oak blades, showcasing their texture and finish.

## 4. OPERATING INSTRUCTIONS

Your Quorum Windmill Ceiling Fan is operated using the included handheld remote control.

### Remote Control Functions:



# Remote Control Included

The 8-9860-0 handheld remote provides convenient wireless control for compatible DC motor ceiling fans, allowing quick fan speed adjustments from anywhere in the room. Its clean white finish and intuitive layout make it a practical replacement or accessory for everyday comfort and reliable operation.

Image: Diagram of the remote control, detailing buttons for fan speed, on/off, reverse, and light control.

- **Fan ON/OFF & Speed Control (Buttons 0-6):** Press '0' to turn the fan off. Press '1' through '6' to select desired fan speed, with '6' being the highest speed.
- **Fan Reverse (Button with 'S' arrow):** Press this button to change the direction of the fan blades. This function is useful for seasonal comfort: downward airflow for cooling in summer, and upward airflow for circulating warm air in winter.
- **Light ON/OFF (Light bulb icon button):** If an optional light kit is installed, press this button to turn the light on or off.

## Video Demonstrations:

Video: A demonstration of the Quorum Indoor Windmill Ceiling Fan's features and operation. This video highlights the fan's functionality and design in a home setting.

Video: A review showcasing the Quorum Windmill Ceiling Fan, emphasizing its suitability for large rooms and overall performance.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Fasteners:** Check all screws and fasteners annually to ensure they are secure. Loose connections can cause noise and wobble.
- **Blade Inspection:** Inspect blades for any cracks or damage. Replace damaged blades immediately.
- **No Lubrication Required:** The DC motor is permanently lubricated and does not require additional oiling.

## 6. TROUBLESHOOTING

Before attempting any repairs, ensure the power is disconnected at the circuit breaker.

| Problem                    | Possible Cause                                                                         | Solution                                                                                                                                         |
|----------------------------|----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Fan does not start         | No power to the fan; Loose wire connections; Remote control battery low or not paired. | Check circuit breaker; Verify all wire connections are secure; Replace remote battery or re-pair remote.                                         |
| Fan wobbles                | Loose blade screws; Unbalanced blades; Loose mounting bracket.                         | Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is securely fastened to the ceiling box. |
| Noisy operation            | Loose screws; Motor housing rubbing; Incorrect installation.                           | Check and tighten all screws; Ensure no parts are rubbing; Re-check installation steps.                                                          |
| Remote control not working | Low battery; Remote not paired; Obstruction between remote and receiver.               | Replace battery; Follow pairing instructions in the full manual; Ensure clear line of sight.                                                     |

## 7. SPECIFICATIONS

| Feature           | Detail                                 |
|-------------------|----------------------------------------|
| Model Number      | 97215-86                               |
| Brand             | Quorum International                   |
| Size              | 72 Inches (Blade Length)               |
| Number of Blades  | 15                                     |
| Blade Material    | Plastic (Weathered Oak Finish)         |
| Motor Type        | DC-165L (6-Speed Reversible)           |
| Control Type      | Remote Control                         |
| Air Flow Capacity | Up to 2826 CFM (Cubic Feet Per Minute) |
| Wattage           | 34.00 W                                |
| Voltage           | 120 Volts                              |
| Item Weight       | 48 Pounds                              |

| Feature              | Detail                                                                                                    |
|----------------------|-----------------------------------------------------------------------------------------------------------|
| Product Dimensions   | 44"D x 44"W x 16.46"H (Note: D and W likely refer to overall fan diameter, not just depth/width of motor) |
| Indoor/Outdoor Usage | Indoor ONLY (Dry Rated)                                                                                   |
| Included Components  | Mounting Hardware, Remote Control                                                                         |
| Finish Type          | Oiled Bronze (Metal)                                                                                      |

## 8. WARRANTY AND SUPPORT

### Warranty Information:

This Quorum Windmill Ceiling Fan comes with a **Limited Lifetime Motor Warranty**. For specific terms and conditions, please refer to the warranty documentation included with your product or contact Quorum International directly.

### Customer Support:

For technical assistance, missing parts, or warranty claims, please contact Quorum International customer service. Refer to the contact information provided in your product packaging or on the official Quorum International website.

© 2026 Quorum International. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

