TMEZON MZ-WF-8013P/20-A1

TMEZON Wireless Security Camera System MZ-WF-8013P/20-A1 User Manual

Model: MZ-WF-8013P/20-A1

Brand: TMEZON

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your TMEZON Wireless Security Camera Network System. Please read this manual thoroughly before use to ensure proper functionality and safety.

PACKAGE CONTENTS

Please verify that all items are present in your package. If any items are missing or damaged, contact customer support.

- 1 x 8-Channel 1080P HD WiFi NVR (with 2TB HDD pre-installed)
- Wireless IP Cameras (Quantity may vary, typically 4 or 8 for an 8-channel system)
- Power Adapters for NVR and Cameras
- USB Mouse
- Ethernet Cable
- HDMI Cable
- Mounting Screws and Plugs
- User Manual (This document)

Image Description: A top-down view of the TMEZON NVR unit with four wireless security cameras connected. The NVR has "TMEZON" branding and indicators for PWR and HDD. Each camera has two antennas and a lens assembly.

SYSTEM SETUP

1. NVR Connection

Connect the NVR to a power source using the provided power adapter.

Connect the NVR to a monitor or TV using an HDMI or VGA cable.

Connect the USB mouse to the NVR's USB port for navigation.

For remote viewing, connect the NVR to your router using the Ethernet cable.

Image Description: A diagram illustrating the rear panel connections of the TMEZON NVR. Labels indicate ports for VGA, HDMI, WAN (Ethernet), USB (for mouse), and DC 12V power input. Corresponding icons show connections to a 1080P monitor, an Ethernet router, a USB mouse, and a DC power adapter.

2. Camera Installation

Mount the wireless IP cameras in desired locations. Ensure they are within range of the NVR's WiFi signal. Connect each camera to its respective power adapter.
The cameras will automatically pair with the NVR upon power-up. If pairing issues occur, refer to the troubleshooting section.

3. Initial Configuration

Follow the on-screen prompts to set up the NVR, including language, date/time, and password.
The system comes with a 2TB HDD for continuous recording. Ensure it is recognized and formatted by the NVR.

OPERATING YOUR SECURITY SYSTEM

Live View

After setup, the NVR will display live feeds from all connected cameras on the monitor.

Recording

The system is configured for continuous recording to the 2TB HDD. You can adjust recording schedules and motion detection settings via the NVR menu.

Playback

Access recorded footage through the NVR's playback menu. You can search by date, time, or event.

Remote Access (Smartphone Quick View)

Download the official TMEZON app on your smartphone or tablet.
Register an account and add your NVR device by scanning the QR code or manually entering the device ID.
Ensure your NVR is connected to the internet via the Ethernet port for remote viewing functionality.

Night Vision

The 2.0MP IP cameras feature night vision technology, automatically switching to infrared mode in low-light conditions to provide clear surveillance.

Image Description: A visual comparison demonstrating the difference between 1080P and 720P video resolution. The 1080P image of a house appears sharper and more detailed than the 720P image, highlighting the superior clarity of the system's cameras.

Maintenance Guidelines

- Keep the NVR and cameras clean and free from dust. Use a soft, dry cloth.
- Ensure proper ventilation for the NVR to prevent overheating.
- Regularly check camera lenses for obstructions or dirt that may impair image quality.
- Periodically review recorded footage to ensure the system is functioning as expected.
- Keep the NVR firmware updated for optimal performance and security. Check the manufacturer's website for updates.

Troubleshooting Common Issues

No Image on Monitor

Check power connections for both NVR and monitor.
Verify HDMI/VGA cable connections.
Ensure the correct input source is selected on your monitor.

Cameras Not Connecting

Ensure cameras are powered on and within range of the NVR.
Check for physical obstructions or strong interference sources.
If necessary, manually pair cameras through the NVR's menu (refer to the NVR's specific pairing instructions).

Remote Access Not Working

Confirm the NVR is connected to your router via Ethernet and has internet access.
Verify your smartphone has a stable internet connection.
Ensure the correct device ID is entered in the app.
Check firewall settings on your router if issues persist.

Poor Image Quality

Clean camera lenses.
Ensure cameras are securely mounted and not vibrating.
Check for strong light sources directly facing the camera, which can cause glare.

Product Specifications

| Feature	Detail
Model Number	MZ-WF-8013P/20-A1
Connectivity	Wireless (WiFi)
Video Resolution	1080p, 960p
Number of Channels	8
Storage Capacity	2 TB HDD (pre-installed)
Power Source	Corded Electric
Compatible Devices	Cameras, Personal Computers, Smartphones

| Feature	Detail
Low Light Technology	Night color (Infrared Night Vision)
Product Dimensions	14.17 x 11.22 x 8.27 inches
Item Weight	12.82 pounds

WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official TMEZON website.

If you encounter any issues not covered in this manual or require further assistance, please contact TMEZON customer support. Contact details are typically available on the product packaging or the official website.

Related Documents - MZ-WF-8013P/20-A1

	TMEZON Wireless Video Doorbell Camera User Guide - HD WiFi, Two-Way Audio, PIR Comprehensive user guide for the TMEZON Wireless Video Doorbell Camera. Learn about its 1080P HD video, two-way audio, motion detection, IP65 waterproofing, and easy setup.
	TMEZON MZ-IP-V739B+MZ-VDP-NE120 Video Intercom System: Wiring and Installation Guide Comprehensive guide for installing and wiring the TMEZON MZ-IP-V739B+MZ-VDP-NE120 video intercom system. Includes detailed wiring diagrams, troubleshooting tips, and instructions for using extension cables and connecting multiple monitors.
	Tmezon 4-Wire IP Video Door Phone 10" Touch Screen Series Quick Guide This document provides a quick guide for the Tmezon 4-Wire IP Video Door Phone, 10" Touch Screen Series. It covers installation, wiring, specifications, and app connection for indoor monitors and outdoor doorbells.
	TMEZON 4-Wire IP Video Door Phone 10" Touch Screen Series Operation Manual Comprehensive operation manual for TMEZON's 4-Wire IP Video Door Phone 10" Touch Screen Series, covering installation, wiring, specifications, and app connectivity for models like MZ-IP-V103W and MZ-IP-V142B.

	[TMEZON Video Intercom System Installation Guide and Wiring Diagram](#) Comprehensive guide for installing and wiring TMEZON video intercom systems, including models MZ-IP-V103W, MZ-VDP-NA100, MZ-IP-V739, and MZ-VDP-738EM. Covers setup, troubleshooting, extension cable usage, and multi-monitor configuration.
	[TMEZON POE NVR Kit User Manual: Setup, Installation, and Operation Guide](#) Comprehensive user manual for the TMEZON POE NVR Kit, covering installation, setup, camera connection, system configuration, playback, backup, and troubleshooting. Learn how to secure your property with TMEZON's advanced surveillance system.