

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Brady](#) /

› [Brady 128338 Maintenance Sign User Manual](#)

Brady 128338

Brady 128338 Maintenance Sign User Manual

Model: 128338

INTRODUCTION

This manual provides essential information for the proper setup, use, and maintenance of the Brady 128338 Maintenance Sign. Designed for clear communication in various environments, this sign serves as a reminder for cleanliness and personal responsibility. Please read this manual thoroughly to ensure optimal performance and longevity of your signs.

PRODUCT OVERVIEW



Figure 1: The Brady 128338 Maintenance Sign. This sign features bold red text on a white background, conveying a clear message about maintaining cleanliness and personal responsibility in shared spaces.

The Brady 128338 Maintenance Sign is a durable, pre-printed sign intended for use in facilities, workplaces, or public areas where a reminder about cleanliness is beneficial. It is part of a pack of 12 signs, allowing for consistent messaging across multiple locations.

SETUP

Proper placement and mounting are crucial for the effectiveness and longevity of your Brady Maintenance Sign.

- Location Selection:** Choose a highly visible location where the sign's message can be easily read by the intended audience. Consider areas prone to clutter or where cleanliness is a priority.
- Surface Preparation:** Ensure the mounting surface is clean, dry, and smooth. Remove any dust, grease, or debris that could interfere with adhesion or mounting hardware.
- Mounting:**
 - Adhesive Mounting:** If using adhesive backing (not included), apply firmly to the clean surface, pressing from the center outwards to remove air bubbles.
 - Screw Mounting:** If the sign has pre-drilled holes (verify product specifications), use appropriate screws and anchors for the wall material. Ensure the sign is level before tightening.
 - Cable Tie Mounting:** For fences or poles, use durable cable ties through the sign's mounting holes (if present) to secure it.
- Visibility Check:** After mounting, step back and confirm the sign is clearly visible, unobstructed, and readable from a reasonable distance.

OPERATING PRINCIPLES

The Brady 128338 Maintenance Sign operates passively by conveying a clear message to individuals. Its effectiveness relies on its visibility and the understanding of its directive.

- Message Clarity:** The sign's bold text, "YOUR HABITS ARE A REFLECTION OF YOU... CLEAN UP AND PICK UP AFTER YOURSELF!", is designed for immediate comprehension.
- Behavioral Reinforcement:** By being prominently displayed, the sign serves as a constant visual reminder, encouraging individuals to maintain tidiness and personal responsibility in their environment.
- Strategic Placement:** For maximum impact, place signs in areas where the message is most relevant, such as break rooms, common areas, workshops, or near waste receptacles.

MAINTENANCE

Regular maintenance will help preserve the appearance and legibility of your Brady Maintenance Sign.

- Cleaning:**
 - Wipe the sign surface periodically with a soft, damp cloth to remove dust and light grime.
 - For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the sign's surface or fade the print.
 - Ensure the sign is completely dry after cleaning to prevent water spots.
- Inspection:** Periodically inspect the sign for any signs of wear, fading, or damage. Ensure it remains securely mounted.
- Replacement:** If the sign becomes significantly faded, damaged, or illegible, replace it promptly to maintain effective communication.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Brady Maintenance Sign.

Issue	Possible Cause	Solution
Sign is not visible or easily overlooked.	Poor placement; obstructed view.	Relocate the sign to a more prominent and unobstructed area. Ensure adequate lighting.

Issue	Possible Cause	Solution
Text is fading or becoming illegible.	Prolonged exposure to direct sunlight or harsh weather; age.	Consider moving the sign to a less exposed location if possible. Replace the sign if fading significantly impacts readability.
Sign is loose or falling off.	Improper mounting; adhesive failure; damaged mounting holes.	Re-secure the sign using appropriate mounting hardware or stronger adhesive. If mounting holes are damaged, consider alternative mounting methods or replace the sign.
Sign surface is dirty or stained.	Accumulation of dust, dirt, or grime.	Clean the sign according to the "Maintenance" section.

SPECIFICATIONS

Attribute	Detail
Brand	Brady
Model Number	128338
Product Type	Maintenance Sign
Quantity	Pack of 12 pcs
Pre-printed	Letter
ASIN	B01GDUY1WI
UPC	754473772130
Date First Available	February 24, 2014

WARRANTY AND SUPPORT

Brady products are manufactured to high standards. For specific warranty information or technical support regarding your Brady 128338 Maintenance Signs, please refer to the official Brady website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the [Brady Store on Amazon](#).