

**mabe MCL1740ESBB0**

# Mabe MCL1740ESBB0 Washer Dryer Combo Instruction Manual

Model: MCL1740ESBB0 | Brand: Mabe

## 1. PRODUCT OVERVIEW

The Mabe MCL1740ESBB0 is a combined washer and dryer unit designed for efficient laundry processing. This stacked appliance offers both washing and drying capabilities in a single compact footprint, optimizing space and time.



*Image 1: Mabe MCL1740ESBB0 Washer Dryer Combo. This image displays the Mabe MCL1740ESBB0 Washer Dryer Combo, a white stacked unit with the dryer on top and the washer below. The control panel is located between the two units.*

## 2. SAFETY INFORMATION

Before operating the appliance, read all instructions carefully to prevent property damage or personal injury. Keep this manual for future reference.

- Ensure proper electrical grounding.
- Do not store or use flammable materials near the appliance.
- Keep children and pets away from the appliance during operation.

- Always unplug the appliance before performing any maintenance or cleaning.
- Do not operate the appliance with damaged power cords or plugs.
- The appliance features a lid safety lock. Do not attempt to bypass it.

## 3. SETUP AND INSTALLATION

### 3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any shipping damage. Retain packaging for potential future transport.

### 3.2 Location Requirements

- Install on a firm, level floor capable of supporting the appliance's weight (110 kg).
- Ensure adequate clearance around the unit for ventilation and service access.
- Avoid installing in areas exposed to freezing temperatures or direct sunlight.

### 3.3 Electrical Connection

The dryer component requires a 220V/60Hz bifasic electrical supply. Consult a qualified electrician for proper installation and ensure the circuit is adequately protected.

### 3.4 Water Connection (Washer)

- Connect the hot and cold water inlet hoses to the corresponding valves and the appliance.
- Ensure all connections are tight to prevent leaks.
- Position the drain hose securely into a standpipe or laundry tub.

## 4. OPERATING INSTRUCTIONS

### 4.1 Washer Operation

1. **Load Preparation:** Sort laundry by fabric type, color, and soil level. Close zippers and fasten hooks.
2. **Loading:** Open the washer lid and load items loosely, ensuring not to overload. The washer has a 17 kg capacity.
3. **Detergent Dispensing:** Add appropriate detergent to the dispenser.
4. **Program Selection:** Select one of the 7 automatic wash programs using the control knob.
5. **Water Level:** Choose from 4 water levels or select the automatic setting.
6. **Temperature:** Select one of the 4 temperature levels.
7. **Start Cycle:** Close the lid and press the Start button. The lid safety lock will engage.

The washer features an infusor wash system for efficient cleaning and garment care.

### 4.2 Dryer Operation

1. **Load Preparation:** Transfer washed items to the dryer. Do not overload.
2. **Lint Filter:** Clean the lint filter before each use for optimal drying performance and safety.
3. **Program Selection:** Select the desired drying cycle based on fabric type and desired dryness level.
4. **Start Cycle:** Close the dryer door and press the Start button.

## 5. MAINTENANCE AND CARE

### 5.1 Lint Filter Cleaning (Dryer)

The dryer is equipped with a lint filter. Clean it after every load to maintain drying efficiency and prevent fire hazards. Remove the filter, clear lint, and reinsert.

### 5.2 Washer Tub Cleaning

Periodically run a self-clean cycle or a hot wash with a specialized washer cleaner to remove detergent residue and odors.

### 5.3 Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents.

### 5.4 Water Inlet Filters

Check and clean the water inlet filters periodically to prevent blockages and ensure proper water flow.

## 6. TROUBLESHOOTING

Refer to this section for common issues and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Appliance does not start	Power cord unplugged, circuit breaker tripped, lid/door not closed properly.	Check power connection, reset breaker, ensure lid/door is securely closed.
Washer not filling with water	Water supply turned off, inlet hoses kinked, water inlet filters clogged.	Open water taps, straighten hoses, clean inlet filters.
Dryer not heating	Lint filter clogged, thermal fuse tripped, incorrect cycle selected.	Clean lint filter, check circuit breaker, select appropriate drying cycle.
Excessive vibration/noise	Appliance not level, shipping bolts not removed, uneven load.	Adjust leveling feet, ensure all shipping bolts are removed, redistribute laundry load.

## 7. SPECIFICATIONS

Feature	Detail
Model	MCL1740ESBB0
Brand	Mabe
Color	White
Dimensions (D x W x H)	78.36 x 68 x 192.28 cm
Weight	110 kg

Feature	Detail
Washer Capacity	17 kg
Washer Programs	7 Automatic Programs
Water Levels	4 levels + Automatic
Temperature Levels	4 levels
Washer Drum Material	Stainless Steel
Dryer Type	Electric
Electrical Requirements (Dryer)	220V/60Hz Bifasic
Special Features	Lid Safety Lock, Infusor Wash System, Lint Filter (Dryer)
UPC	757638512817

## 8. WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Mabe website for detailed terms and conditions. Keep your proof of purchase for warranty claims.

## 9. CUSTOMER SUPPORT

For technical assistance, service requests, or to order replacement parts, please contact Mabe customer support. Contact details can typically be found on the Mabe official website or in the documentation provided with your appliance.

*Note: Always provide your model number (MCL1740ESBB0) and serial number when contacting support.*

© 2023 Mabe. All rights reserved. Information in this manual is subject to change without notice.

## Related Documents - MCL1740ESBB0




### [Mabe Washing Machine LMA79114CBAKO & Dryer SMG26N5MNBABO - Product Overview](#)

Detailed product information for Mabe automatic washing machine model LMA79114CBAKO and gas dryer model SMG26N5MNBABO, featuring specifications, key benefits, and installation guidelines.




### [Mabe Electrical Dryer SME47N8MSBBP02 Spare Parts Catalog](#)

Official spare parts catalog for the Mabe Electrical Dryer, model SME47N8MSBBP02. Features detailed exploded-view diagrams that illustrate the various components of the appliance, identified by unique part numbers for maintenance and repair.




### [Mabe Top Load Washer Kraken 27" Service Manual](#)

Comprehensive service manual for Mabe Kraken 27" top-load washers, covering model nomenclature, safety procedures, disassembly, component replacement, and troubleshooting.



### [Manual de Instrucciones Horno de Empotre Mabe IO8042HGW / IO8042HEY](#)

Guía completa para la instalación, uso y mantenimiento del horno de empotre Mabe. Incluye especificaciones técnicas, advertencias de seguridad y funciones detalladas para los modelos IO8042HGW e IO8042HEY.



### [mabe MSMS2LG SS / MSMF2LG WW](#)

mabe MSMS2LG SS MSMF2LG WW



### [Manual de Servicio Mabe Centro de Lavado: Modelos MCL6840 y MCL6040](#)

Manual de servicio completo para centros de lavado Mabe, cubriendo modelos MCL6840ESBB, MCL6840PSBB, MCL6040ESBB y MCL6040PSBB. Incluye especificaciones técnicas, guías de diagnóstico, desensamble y diagramas eléctricos.