

Tectake 401856

Tectake Giant Cat Tree with Activity Center and Scratching Post

Model: 401856

Brand: Tectake

INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, maintenance, and troubleshooting of your Tectake Giant Cat Tree, Model 401856. This multi-level cat tree is designed to offer your feline companion numerous opportunities for play, scratching, climbing, and relaxation. Please read these instructions carefully before assembly and use to ensure safe and correct installation.

SAFETY INFORMATION

- Always ensure all components are securely fastened during assembly and periodically check for tightness.
- Place the cat tree on a flat, stable surface to prevent tipping.
- An anti-tipping system is included for enhanced stability. Ensure it is properly installed according to the assembly instructions.
- Keep small children away from the assembly area to avoid choking hazards from small parts.
- Do not allow children to climb on the cat tree. It is designed for feline use only.
- Regularly inspect the cat tree for any damage, loose parts, or wear and tear. Replace damaged parts immediately.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present in your package:

- 1 x Tectake Giant Cat Tree DIY Kit (all structural components, platforms, posts, coverings, and accessories)
- 1 x Illustrated Assembly Instructions Manual
- Necessary assembly tools (e.g., Allen key)


SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Tectake Giant Cat Tree. It is recommended to have a clear, spacious area

for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Compare them with the parts list in the included illustrated manual to ensure everything is present.
2. **Base Assembly:** Begin by attaching the lowest scratching posts to the base plate. Ensure they are tightened securely.
3. **First Level Platform:** Attach the first platform to the posts. This platform typically includes the cat house and the opening for the hammock.
4. **Install Cat House and Hammock:** Secure the cat house to its designated spot on the first platform. Attach the hammock through the opening, ensuring it hangs securely.
5. **Ladder Attachment:** Connect the ladder to the base and the first platform as shown in the diagram.
6. **Second Level and Tunnel:** Continue by adding the next set of posts and the second platform. The tunnel will typically attach to this level.
7. **Top Platform:** Install the final posts and the highest viewing platform.
8. **Attach Play Rope:** Secure the play rope to one of the upper platforms or posts.
9. **Anti-Tipping System:** Locate the anti-tipping strap. Secure one end to the cat tree and the other to a wall stud using appropriate hardware (not always included). This step is crucial for stability, especially for active cats.
10. **Final Check:** Once assembled, gently shake the cat tree to ensure all connections are tight and the structure is stable. Retighten any loose screws.

Refer to the detailed diagram below for component placement and dimensions during assembly:



Detailed diagram illustrating the dimensions and structural layout of the cat tree, essential for correct assembly.

OPERATING INSTRUCTIONS / USAGE

The Tectake Giant Cat Tree offers a variety of features designed to enrich your cat's environment:

- **Scratching Posts:** The sisal-covered posts provide an ideal surface for your cat to sharpen its claws, helping to protect your furniture.
- **Multi-Level Platforms:** Cats can climb, jump, and explore different heights, satisfying their natural instincts.

- **Cat House (Cellar):** A cozy enclosed space for your cat to hide, nap, and feel secure.
- **Hammock:** A comfortable, suspended bed perfect for lounging and relaxation.
- **Tunnel:** An engaging feature for play, exploration, and hiding.
- **Play Rope:** Encourages interactive play and exercise.
- **Viewing Platform:** The highest platform allows your cat to observe its surroundings from a commanding position.

Encourage your cat to use the tree by placing treats or toys on different levels. Some cats may need time to adjust to a new structure.



Cats enjoying the multi-level design, scratching posts, and various play areas of the Tectake Cat Tree.



A cat comfortably positioned on the high viewing platform, demonstrating a resting spot.

MAINTENANCE AND CARE

Proper care will extend the life of your cat tree:

- **Cleaning:** Clean the surfaces with a damp cloth. For tougher spots, a mild pet-safe cleaner can be used, but always test on an inconspicuous area first.
- **Avoid Immersion:** Do not immerse any part of the cat tree in water.
- **Sharp Objects:** Avoid using sharp objects near the plush or sisal surfaces to prevent damage.
- **Regular Inspection:** Periodically check all screws and connections for tightness. Tighten as necessary to maintain stability.
- **Sisal Condition:** Inspect the sisal scratching posts for excessive wear. While durable, sisal will fray over time with use.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- Instability/Wobbling:**
Solution: Ensure the cat tree is on a flat, level surface. Check all screws and bolts for tightness, especially those connecting the base and posts. Verify the anti-tipping system is correctly installed and secured to a wall stud.
- Cat Not Using Tree:**
Solution: Place familiar toys or treats on different levels to encourage exploration. Rub catnip on the scratching posts or platforms. Position the tree in a location your cat frequently visits or near a window.
- Damaged Components:**
Solution: If a part is damaged or excessively worn, contact Tectake customer support for replacement parts. Do not attempt to repair structural components with makeshift solutions.

SPECIFICATIONS

Feature	Detail
Overall Dimensions (L x W x H)	105 x 60 x 141 cm
Base Plate Dimensions (L x W x H)	75 x 40 x 1.5 cm
Sisal Pole Diameter	Approx. 6.5 cm (2.56 inches)
Cat House (Cellar) Dimensions (Diameter x Height)	30 x 26 cm
Cat House Opening (W x H)	17 x 18 cm
Hammock Dimensions (L x W)	40 x 30 cm
Tunnel Dimensions (Diameter x Length)	16 x 20 cm
Top Viewing Platform (L x W x H)	30 x 30 x 6 cm
Product Weight	13.9 kg (Approx. 30.6 lbs)
Materials	Pressed wood board, Sisal, Plush, 100% Polyester fabric
Color	Burgundy (Model 401856)
Special Features	Multi-levels, Hammock, Tunnel, Cat House, High-platform, Sisal-covered poles for scratching, Stability with anti-tipping system

WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please refer to the contact details provided with your purchase documentation or visit the official Tectake website. Keep your proof of purchase for warranty claims.

