

[Manuals.plus](#) /

› [TENGA](#) /

› TENGAF LIP 0 (Zero) Men Masturbation Device User Manual

TENGA TFZ-001

TENGA FLIP 0 (Zero) User Manual

Model: TFZ-001 | Brand: TENGA

1. INTRODUCTION

The TENGA FLIP 0 (Zero) is a reusable pleasure device designed for personal use. It features an innovative flip-open design for easy cleaning and an intricate internal structure for enhanced sensation. This manual provides essential information for the proper use, care, and maintenance of your device.

2. SAFETY INFORMATION

- For adult use only.
- Do not use if the device appears damaged or cracked.
- Use only water-based lubricants. Oil-based lubricants may damage the elastomer material.
- Clean the device thoroughly before and after each use as instructed in the Maintenance section.
- Discontinue use immediately if any irritation or discomfort occurs. Consult a medical professional if symptoms persist.
- Store in a clean, dry place away from direct sunlight and extreme temperatures.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components are present:

- TENGA FLIP 0 (Zero) Device
- Instruction Manual (this document)
- Sample Lubricant (may be included)

4. SETUP

1. **Unpack the Device:** Carefully remove the TENGA FLIP 0 from its packaging.
2. **Initial Cleaning:** Before first use, thoroughly wash the device with mild soap and warm water. Rinse completely and allow to air dry.
3. **Apply Lubricant:** Apply a generous amount of water-based lubricant to the entry point and the internal surfaces of the device.



Figure 4.1: The TENGA FLIP 0 in its open position, showcasing the seamless insertion design.


5. OPERATING INSTRUCTIONS

The TENGA FLIP 0 is designed for intuitive use, providing a unique experience through its internal structure and pressure pads.

1. **Insertion:** Gently insert into the device. The integrated pivot allows for seamless entry.
2. **Utilizing Pressure Pads:** The device features squeezable pressure pads on the exterior. After insertion, you can squeeze these pads at any point to provide focused stimulation and create an internal vacuum. This enhances the sensation by increasing suction and pressure against the internal textures.
3. **Explore Internal Textures:** The elastomer interior is engineered with less dead-space, stimulating all-over. Experiment with different movements and pressure levels to discover the various sensations provided by the

intricate internal details, such as the Layered End Orb, Triple Chain Gate, Ridge Wall, and Ripple Dome.

Internal Structure




The FLIP 0 (ZERO) features our most intricate internal details yet for great sensation.

Figure 5.1: Detailed internal structure of the FLIP 0, highlighting key sensation points.



Figure 5.2: Demonstrating the use of external pressure pads for enhanced vacuum and stimulation.

Using Pressure Pads



After insertion, you can squeeze the Pressure Pads at any point to provide focused stimulation and create an internal vacuum.

Figure 5.3: Illustration of the vacuum mechanism created by the pressure pads.

6. MAINTENANCE AND CLEANING

The FLIP O's design prioritizes hygiene and ease of cleaning.

1. **Flip Open:** After use, simply flip the device open. This exposes the entire internal surface for thorough cleaning.
2. **Wash:** Rinse the device under warm running water. Use a mild, pH-neutral soap if desired. Gently rub the internal textures to remove any lubricant residue.
3. **Rinse Thoroughly:** Ensure all soap is rinsed off.
4. **Air Dry:** Place the device in its open position on its stand or in a well-ventilated area to air dry completely. This also accommodates charging if applicable (though this model does not have charging). Avoid using towels or cloths inside the device as they may leave lint.
5. **Storage:** Once completely dry, close the device and store it in a clean, dust-free environment.



Figure 6.1: The FLIP 0 fully open for comprehensive cleaning.



Figure 6.2: Rinsing the device under running water.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced Suction/Vacuum	Insufficient lubricant; air leakage from improper closure or damage.	Ensure adequate lubricant is applied. Check that the device is fully closed and inspect for any visible cracks or damage to the casing or elastomer.
Lubricant Leakage	Excessive lubricant; improper insertion; device not fully closed.	Use an appropriate amount of lubricant. Ensure proper insertion technique. Verify the device is securely closed.
Device Not Closing Properly	Debris in hinge; damaged latch mechanism.	Inspect the hinge area for any obstructions and clean if necessary. If latches are damaged, contact customer support.
Material Degradation (Cracks/Tears)	Use of incompatible lubricants; improper storage; excessive force during use or cleaning.	Always use water-based lubricants. Store properly. Avoid excessive force. If damage occurs, the device may need replacement.

8. SPECIFICATIONS

Feature	Detail
Model Name	FLIP ZERO
Item Model Number	TFZ-001

Feature	Detail
Brand	TENGA
Color	White
Material	Thermoplastic Elastomer (TPE)
Product Dimensions	9 x 4 x 4 inches
Item Weight	1.2 Pounds
Manufacturer	OneUp Innovations
Date First Available	June 24, 2016

9. WARRANTY AND SUPPORT

For specific warranty information, please refer to the product packaging or the official TENGA website. General support and additional resources may be found through the following links:

- [User Manual \(PDF\)](#)
- [User Guide \(PDF\)](#)
- [Visit the TENGA Store on Amazon](#)

For further assistance, please contact TENGA customer support directly via their official channels.

© 2024 TENGA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01GNSP2XC>

More documents and user manuals: <https://manuals.plus/>