

Smeg SMSG01

SMEG Stand Mixer Slicer & Grater Attachment SMSG01 Instruction Manual

Model: SMSG01

Brand: Smeg

1. INTRODUCTION

This instruction manual provides comprehensive guidance for the safe and efficient use of your SMEG Stand Mixer Slicer & Grater Attachment, Model SMSG01. This accessory is designed to expand the capabilities of your SMEG Stand Mixer (SMF01 series) by offering versatile slicing and grating functions for various food preparation tasks.

Please read this manual thoroughly before first use and retain it for future reference. Proper use and maintenance will ensure optimal performance and longevity of the attachment.

2. IMPORTANT SAFETY INFORMATION

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before using the appliance.
- Ensure the appliance is unplugged from the power outlet before assembling, disassembling, or cleaning.
- Keep hands and utensils away from moving parts during operation to prevent personal injury and/or damage to the appliance.
- Never feed food by hand. Always use the provided plastic pusher.
- Do not use the attachment for purposes other than its intended use.
- Avoid contact with sharp blades. Handle cutting drums with extreme care.
- Do not immerse the main body of the stand mixer or the attachment housing in water or other liquids.
- Supervise children closely when the appliance is in use.

3. PACKAGE CONTENTS

Your SMEG Stand Mixer Slicer & Grater Attachment package includes the following components:

- Slicer & Grater Attachment Housing
- 4 Stainless Steel Drums (for various slicing and grating tasks)

- Plastic Food Pusher



Figure 1: Components of the SMEG Slicer and Grater Attachment, showing the main housing and four stainless steel drums for different cutting styles.

4. SETUP AND ASSEMBLY

1. **Prepare the Stand Mixer:** Ensure your SMEG Stand Mixer (SMF01 series) is unplugged and turned off. The front accessory hub cover should be removed.
2. **Attach the Housing:** Insert the Slicer & Grater Attachment housing into the front accessory hub of your stand mixer. Rotate the attachment slightly until it locks into place. Secure it by tightening the accessory knob on the side of the stand mixer.
3. **Insert a Drum:** Select the desired stainless steel drum for your task (slicing or grating). Insert the drum into the attachment housing, ensuring it is seated correctly.
4. **Position a Bowl:** Place a suitable bowl or container beneath the outlet of the attachment to collect the processed food.



Figure 2: SMEG Stand Mixer with the Slicer & Grater Attachment correctly installed and a bowl positioned to collect ingredients.

5. OPERATING INSTRUCTIONS

Once the attachment is securely installed and a collection bowl is in place, you can begin processing food.

- 1. Power On:** Plug in your SMEG Stand Mixer and turn it on to a low to medium speed setting (refer to your stand mixer manual for recommended speeds for accessories).
- 2. Feed Food:** Gently place food items into the feed tube of the attachment. Use the plastic food pusher to guide the food towards the rotating drum. **Never use your fingers or other utensils to push food.**
- 3. Process:** The food will be sliced or grated by the drum and exit through the front opening into your

collection bowl.

4. **Turn Off:** When finished, turn off the stand mixer and unplug it from the power outlet before disassembling or cleaning.

5.1. Slicing

Use the slicing drums for uniform slices of vegetables like zucchini, cucumbers, carrots, or potatoes. Ensure food items fit comfortably into the feed tube.



Figure 3: Slicing zucchini with the attachment, demonstrating uniform output.



Figure 4: Slicing carrots with the attachment, showing consistent results.

5.2. Grating

The grating drums are suitable for cheese, chocolate, nuts, or firmer vegetables. Select the appropriate drum for fine, medium, or coarse grating.



Figure 5: Grating chocolate with the attachment for dessert toppings.



Figure 6: Grating hard cheese with the attachment for culinary use.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures hygiene and extends the life of your attachment. Always unplug the stand mixer before cleaning.

- 1. Disassembly:** Remove the attachment from the stand mixer. Carefully remove the drum and the plastic pusher.
- 2. Washing:** The stainless steel drums and the plastic pusher can be washed by hand using warm, soapy water. Rinse thoroughly and dry immediately. **Note: The product specifications indicate that this attachment is NOT dishwasher safe.**
- 3. Housing:** Wipe the exterior of the attachment housing with a damp cloth. Do not immerse the housing in water.
- 4. Storage:** Ensure all parts are completely dry before reassembling or storing. Store the attachment and drums in a dry place.

7. TROUBLESHOOTING

If you encounter issues with your Slicer & Grater Attachment, please refer to the following common solutions:

- Attachment not operating:** Ensure the stand mixer is properly plugged in and turned on. Verify the attachment is correctly installed and secured in the accessory hub.
- Food not processing efficiently:** Check that the correct drum is inserted and seated properly. Ensure food items are cut to an appropriate size to fit the feed tube and are not too hard for the selected drum. Do not overload the feed tube.
- Excessive vibration or noise:** Confirm the attachment is securely fastened to the stand mixer. Check that the drum is correctly inserted and there are no obstructions.

If problems persist, please contact Smeg customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	SMSG01
Brand	Smeg
Material	Chrome-plated Steel (drums)
Dimensions (Product)	13 x 14 x 6 inches
Item Weight	2.16 pounds (980 Grams)
Drums Included	4 Stainless Steel Drums for grating or slicing
Dishwasher Safe	No



9. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the documentation included with your SMEG Stand Mixer or visit the official Smeg website. Keep your proof of purchase for warranty claims.

If you require assistance, please contact Smeg customer service directly. Contact details can typically be found on the Smeg website or in your product's main manual.

© 2025 Smeg. All rights reserved.

Related Documents - SMSG01

	<p>Smeg Stand Mixer User Manual (Models SMF02, SMF03, SMF13)</p> <p>Comprehensive user manual for Smeg stand mixers, models SMF02, SMF03, and SMF13. Includes safety instructions, operating guide, maintenance tips, and troubleshooting.</p>
	<p>Smeg Stand Mixer SMF02/SMF03/SMF13: Instruction Manual and User Guide</p> <p>This document provides comprehensive instructions, safety guidelines, and usage recommendations for the Smeg Stand Mixer models SMF02, SMF03, and SMF13. Learn how to operate, clean, and maintain your appliance for optimal performance.</p>

 <p>MANUALE D'USO INSTRUCTION MANUEL MANUEL D'UTILISATION BEDIENUNGSANLEITUNG GERÜBRAHANWIEZUNGS MANUAL DE USO MANUAL DE UTILIZAÇÃO BRUKSANVÄNDNING РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ BRUGERVEJLEDNING INSTRUÇÃO DE USO КАРТООЧКА BRUKSANVÄNDNING الكتاب التوجيهي</p> <p>smeg</p>	<p>Smeg Stand Mixer SMF02/SMF03/SMF13 User Manual and Instructions</p> <p>Comprehensive user manual for Smeg stand mixers (models SMF02, SMF03, SMF13) covering safety, operation, cleaning, and maintenance. Learn how to use your Smeg appliance effectively with detailed instructions and tips.</p>
 <p>Verwendet dieses Manuale per la utilizzazione dei modelli SMF02, SMF03 e SMF13. Bedienungsanleitung für die Verwendung der Modelle SMF02, SMF03 und SMF13. Gebruiksaanwijzing voor de gebruik van de modellen SMF02, SMF03 en SMF13. Manual de uso para los modelos SMF02, SMF03 y SMF13. Manual de utilização para os modelos SMF02, SMF03 e SMF13. Bruksanvisning av modellerna SMF02, SMF03 och SMF13. Руководство по эксплуатации для моделей SMF02, SMF03 и SMF13. Brugervejledning til modelle SMF02, SMF03 og SMF13. Instruções de uso para os modelos SMF02, SMF03 e SMF13. Käyttöohje modellille SMF02, SMF03 ja SMF13. Bruksanvisning av modellene SMF02, SMF03 og SMF13. الكتاب التوجيهي للموديلات SMF02, SMF03 و SMF13.</p> <p>smeg</p>	<p>Smeg SMF02, SMF03, SMF13 Stand Mixer User Manual</p> <p>User manual for Smeg stand mixers SMF02, SMF03, and SMF13, covering features, operation, maintenance, and safety instructions.</p>
 <p>MANUALE D'USO INSTRUCTION MANUEL MANUEL D'UTILISATION BEDIENUNGSANLEITUNG GERÜBRAHANWIEZUNGS MANUAL DE USO MANUAL DE UTILIZAÇÃO BRUKSANVÄNDNING РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ BRUGERVEJLEDNING INSTRUÇÃO DE USO КАРТООЧКА BRUKSANVÄNDNING الكتاب التوجيهي</p> <p>smeg</p>	<p>Smeg BLF01 Blender Instruction Manual</p> <p>Instruction manual for the Smeg BLF01 blender, covering safety, operation, cleaning, maintenance, and recipes.</p>