

[manuals.plus](#) /› [PetSpy](#) /› [PetSpy M86 Dog Training Collar User Manual](#)

## PetSpy M86

# PetSpy M86 Dog Training Collar User Manual

Model: M86

## 1. INTRODUCTION

The PetSpy M86 Dog Training Collar is designed to assist in effective dog training through various stimulation modes. This manual provides essential information for the proper setup, operation, and maintenance of your training collar system. It is crucial to use this device responsibly and humanely, focusing on communication and positive reinforcement rather than punishment.

The system includes a remote transmitter and a collar receiver, offering Beep, Vibration, and Static Shock modes to suit different training needs and dog sensitivities.

## 2. IMPORTANT SAFETY INFORMATION

**Please read all safety instructions before using the PetSpy M86 Dog Training Collar. Failure to follow these instructions could result in harm to your dog or damage to the product.**

- **Training Purpose:** This collar is a training aid, not a punishment device. Use it to reinforce commands and correct unwanted behaviors, not to inflict pain.
- **Static Shock:** The static shock function should always be the last stimulation mode used. Begin with sound or vibration.
- **Proper Fit:** Ensure the collar fits correctly. A collar worn too tightly or for extended periods can cause skin irritation or pressure necrosis. Allow two fingers to fit comfortably between the collar and your dog's neck.
- **Wearing Duration:** Do not leave the collar on your dog for more than 4 hours per day. Regularly reposition the collar on the dog's neck every 1 to 2 hours to prevent irritation.
- **Dog Weight:** This collar is suitable for dogs weighing between 10 and 140 pounds.
- **Supervision:** Never leave your dog unattended while wearing the training collar.
- **Leash Attachment:** Do not attach a leash to the training collar. Use a separate, non-metallic collar for leash attachment.
- **Water Safety:** While the receiver is waterproof, ensure the charging port is securely sealed before exposing it to water.
- **Children:** Keep the training system out of reach of children.
- **Limitation of Liability:** The manufacturer is not liable for any direct, indirect, punitive, incidental, special, or consequential damages or injuries arising from the use or misuse of this product. The

buyer assumes all risks and liability.

## Use & Care Tips




Don't keep the collar on your dog for over 4 hours a day




Use the collar only for short training sessions (10-15 min)



Make sure you can fit 2 fingers between the collar and the dog's neck



Don't attach a leash to the collar



Cover contact points with silicone caps



Store in a dry place away from direct sunlight



Check and clean the dog's neck daily



Clean the receiver with a damp cloth daily

**Figure 1: Use and Care Tips.** This image illustrates important guidelines for using the PetSpy M86 collar, such as limiting wear to 4 hours daily, ensuring a two-finger fit, and regular cleaning.

### 3. PACKAGE CONTENTS

Upon opening your PetSpy M86 Dog Training Collar package, please verify that all the following components are included:

- 1 x Remote Transmitter
- 1 x Collar Receiver
- 1 x Adjustable TPU Strap
- 1 x Dual USB Charger
- 1 x Test Bulb
- 2 x Set of Metal Probes (short and long)
- 1 x User Guide (this manual)



**Figure 2:** Complete Package Contents. This image displays all items you should find in your PetSpy M86 training collar box.

## 4. PRODUCT OVERVIEW

Familiarize yourself with the remote transmitter and collar receiver components.

### 4.1 Remote Transmitter

# TRAINING MODES AND BUTTONS



Figure 3: Remote Transmitter and Collar Receiver Features. This diagram highlights the key buttons and functions on both the remote and the collar.

1. **Charging Port:** For connecting the USB charger.
2. **Remote Beep Button:** Activates an audible tone from the receiver.
3. **Vibration Button:** Activates vibration from the receiver.
4. **Menu/Training Mode Button:** Cycles through training modes and settings.
5. **Static Shock Button:** Activates static shock from the receiver.
6. **Collar Beep Button:** Activates an audible tone from the receiver (alternative to remote beep).

## 4.2 Collar Receiver

The collar receiver is the device worn by your dog. It contains the components that deliver the training stimuli (beep, vibration, static shock) and is designed to be waterproof. It features an on/off button and contact points for static stimulation.

## 5. SETUP GUIDE

### 5.1 Charging the Devices

Before initial use, fully charge both the remote transmitter and the collar receiver.

- Connect the dual USB charger to a power adapter and then to the charging ports on both the remote

and receiver.

- Charging indicators will illuminate. Allow approximately 2-3 hours for a full charge.
- Once fully charged, the indicator lights will change or turn off, depending on the model. Disconnect the charger.
- Ensure the rubber cover on the receiver's charging port is securely closed after charging to maintain its waterproof integrity.

## **5.2 Attaching Contact Points and Silicone Caps**


Select the appropriate length of metal probes (short for short-haired dogs, long for long-haired dogs) and screw them firmly onto the receiver. For added comfort and to prevent direct metal contact with the skin, place the silicone caps over the metal probes.

## **5.3 Fitting the Collar Receiver**

Proper fit is essential for the collar to function effectively and safely.

- Position the receiver on the underside of your dog's neck, directly below the chin.
- The contact points should make direct contact with your dog's skin.
- Adjust the strap so it is snug but not overly tight. You should be able to fit two fingers comfortably between the collar strap and your dog's neck.
- Trim any excess strap length if necessary.

# Easy & Effective Training



**Figure 4:** Proper Collar Placement. This image shows a dog wearing the collar correctly, ensuring the contact points are positioned for effective training.

## 5.4 Pairing (Synchronization)

Your PetSpy M86 collar and remote are typically pre-paired from the factory. If they are not responding to each other, follow these steps to re-pair them:

1. Ensure both devices are fully charged and turned off.
2. Turn on the receiver collar by pressing and holding its power button until the indicator light flashes.
3. Within 10 seconds, press and hold the Beep button on the remote transmitter until the receiver's indicator light becomes solid, indicating successful pairing.
4. Test the functions (Beep, Vibration, Static Shock) to confirm pairing.

## 6. OPERATING INSTRUCTIONS

The PetSpy M86 offers three primary training modes: Beep, Vibration, and Static Shock. Each mode has adjustable intensity levels.

### 6.1 Selecting Training Modes and Levels

- Press the **Menu/Training Mode** button on the remote to cycle through the available modes (Beep,

Vibration, Static Shock). The selected mode will be displayed on the remote's screen.

- Use the up/down arrow buttons on the remote to adjust the intensity level for the selected mode. There are 8 adjustable levels for vibration and static shock.
- Always start with the lowest level and gradually increase it until your dog responds without showing signs of distress.

## 6.2 Using the Training Modes

- **Beep Mode:** Press the **Beep** button to emit an audible tone from the receiver. This is often used as a warning or a positive reinforcement signal.
- **Vibration Mode:** Press the **Vibration** button to activate vibration. This is a gentle but noticeable stimulation, ideal for initial corrections or for sensitive dogs.
- **Static Shock Mode:** Press the **Static Shock** button to deliver a static stimulation. This mode should be used only after other modes have been attempted and only at the lowest effective level. Use the included test bulb to verify static shock functionality before applying to your dog.

The remote has a range of up to 1100 yards, allowing for training in various environments.

## 6.3 General Training Tips

- **Consistency:** Use the collar consistently with commands to help your dog associate the stimulation with specific behaviors.
- **Timing:** Deliver stimulation immediately when your dog performs an unwanted action or fails to respond to a command.
- **Positive Reinforcement:** Always pair corrections with positive reinforcement when your dog performs the desired behavior.
- **Short Sessions:** Keep training sessions short and positive to maintain your dog's engagement.
- **E-book:** A complimentary dog training e-book is available with your purchase, offering detailed guidance on various training techniques.

# GET FREE E-BOOK WITH YOUR ORDER!



**Figure 5:** Dog Training Guide E-book. This image shows the digital training guide that provides additional instructions and tips for effective dog training.

## 7. MAINTENANCE

Proper maintenance ensures the longevity and effective operation of your PetSpy M86 training collar.

- **Cleaning the Receiver:** Regularly clean the receiver and contact points with a damp cloth to remove dirt, debris, or skin oils. Ensure the device is dry before charging or storing.
- **Dog's Neck:** Check and clean your dog's neck daily, especially the area under the contact points, to prevent skin irritation.
- **Storage:** Store the collar and remote in a dry place, away from direct sunlight and extreme temperatures, when not in use.
- **Battery Care:** Recharge the devices when the battery indicator is low. Avoid completely draining the battery frequently to prolong its lifespan. The collar features an auto-sleep mode to conserve battery when inactive.

## 8. TROUBLESHOOTING

If you encounter issues with your PetSpy M86 training collar, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Collar not responding to remote.	Low battery on either device, devices not paired, out of range.	Charge both devices. Re-pair the remote and receiver (refer to Section 5.4). Ensure you are within the 1100-yard range.
Static shock not working.	Contact points not touching skin, level too low, test bulb not used correctly.	Ensure proper collar fit and contact with skin. Increase static level gradually. Use the test bulb to confirm functionality.
Receiver indicator light not turning on.	Battery is dead, device is off.	Charge the receiver. Press and hold the power button to turn it on.
Skin irritation on dog's neck.	Collar worn too long, too tight, or dirty contact points.	Remove collar immediately. Clean dog's neck and collar. Ensure proper fit and limit wear time (max 4 hours/day). Consult a veterinarian if irritation persists.
Remote freezing or glitching.	Software issue, temporary malfunction.	Try turning the remote off and on again. If the issue persists, contact PetSpy customer support.

## 9. SPECIFICATIONS

---

- **Model:** M86
- **Range:** Up to 1100 yards
- **Training Modes:** Beep, Vibration, Static Shock (8 adjustable levels)
- **Battery Type:** Lithium Ion (rechargeable, included)
- **Waterproof:** Yes (receiver)
- **Suitable for Dogs:** 10-140 lbs
- **Material:** Nylon (strap)
- **Item Weight:** Approximately 8.8 ounces (250 grams)
- **Product Dimensions:** 6 x 1.5 x 3 inches (receiver)

## 10. WARRANTY AND SUPPORT

---

PetSpy products are designed for reliability and performance. This product typically comes with a 1-year manufacturer's warranty covering defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or additional assistance, please visit the official PetSpy website: [www.petspystore.com](http://www.petspystore.com).

### Related Documents - M86

 <b>PetSpy M919 Dog Training Collar User Manual</b> Models M919-1/M919-2 <small>PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING</small>	<p><a href="#"><u>PetSpy M919 Dog Training Collar User Manual: Features, Operation, and Training Tips</u></a></p> <p>Comprehensive user manual for the PetSpy M919-1 and M919-2 Dog Training Collars. Learn about product features, setup, operation, fitting, training techniques, troubleshooting, and warranty information.</p>
 <b>PetSpy M686/M686B Dog Training Collar User Manual</b> Models M686/M686B <small>PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING</small>	<p><a href="#"><u>PetSpy M686/M686B Dog Training Collar User Manual - Guide and Operation</u></a></p> <p>Comprehensive user manual for the PetSpy M686 and M686B dog training collars. Learn about features, setup, operation, fitting, training techniques, troubleshooting, and warranty. Includes detailed instructions for effective and safe dog training.</p>
 <b>PetSpy M686/M686B Dog Training Collar User Manual</b> Models M686/M686B <small>PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING</small>	<p><a href="#"><u>PetSpy M686/M686B Dog Training Collar User Manual</u></a></p> <p>Comprehensive user manual for the PetSpy Premium Dog Training Collar, models M686 and M686B. Learn about features, operation, fitting, training tips, troubleshooting, and FAQs for effective dog training.</p>
 <b>PetSpy Remote Training Collar: Operating and Training Guide for p-collar 320 and p-collar 320B</b> <small>Models p-collar 320 and p-collar 320B</small>	<p><a href="#"><u>PetSpy Remote Training Collar: Operating and Training Guide for p-collar 320 and p-collar 320B</u></a></p> <p>This guide provides detailed instructions for operating and training your dog with the PetSpy Remote Training Collar, including setup, safety precautions, troubleshooting, and warranty information for models p-collar 320 and p-collar 320B.</p>