

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bright Starts](#) /

› [Bright Starts Toucan Tango Baby Bouncer Infant Seat Instruction Manual](#)

Bright Starts 10589

Bright Starts Toucan Tango Baby Bouncer Infant Seat Instruction Manual

Model: 10589

1. INTRODUCTION

Welcome to the Bright Starts Toucan Tango Baby Bouncer. This infant seat is designed to provide a comfortable and engaging environment for your baby, featuring soothing vibrations, musical melodies, and interactive toys. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Never leave child unattended.
- Always use the restraint system.
- This product is not intended for prolonged periods of sleep.
- Do not use this product once your child can sit up unaided or attempts to climb out.
- This product is not a toy. Do not allow children to play with it.
- Do not move or lift the product with the child in it.
- Always place the bouncer on a flat, level surface.
- Ensure all assembly components are securely fastened before each use.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your Bright Starts Toucan Tango Baby Bouncer:

1. **Frame Assembly:** Connect the metal frame components as indicated in the visual guide. Ensure all parts click securely into place.
2. **Seat Pad Attachment:** Drape the fabric seat pad over the assembled frame. Secure the straps and clips underneath the frame to ensure a snug fit.
3. **Headrest Installation:** Attach the removable headrest to the top of the seat pad using the integrated fasteners.

4. **Battery Installation:** Locate the battery compartment on the underside of the control unit (at the front of the seat). Insert **3 C batteries** (not included) according to the polarity indicators. Close the compartment securely.

5.



Image: The fully assembled Bright Starts Toucan Tango Baby Bouncer with a baby comfortably seated, showcasing the colorful fabric and toy bar.

6. **Toy Bar Attachment:** Insert the ends of the toy bar into the designated slots on either side of the bouncer frame until they click into place. The toy bar is designed for easy removal.

7.



Image: A hand demonstrating the easy removal of the toy bar from the bouncer, highlighting its convenient design.

4. OPERATING INSTRUCTIONS

This bouncer offers several features to comfort and entertain your baby:

- **Securing Your Baby:** Always place your baby in the bouncer with the 3-point harness securely fastened. Adjust the straps for a snug fit.
-



Image: A close-up view of the adjustable 3-point harness, emphasizing the secure fastening mechanism for infant safety.

- **Soothing Vibrations:** The control unit at the front of the seat features a switch for activating soothing vibrations. Toggle the switch to turn vibrations on or off.
- **Musical Melodies:** The control unit also includes a switch for playing 7 different melodies. There are two volume settings (low and high). The music feature has an automatic shut-off after 15 minutes to conserve battery life.
-



Image: A detailed view of the control panel, showing the switches for activating vibrations and selecting music volume.

- **Interactive Toy Bar:** The removable toy bar includes two cheerful toys (elephant and toucan) designed to engage your baby. The Taggies satin tags on the toys provide tactile stimulation.
-



Image: A baby's hand reaching out to touch the colorful toucan toy hanging from the toy bar, illustrating interactive play.

- **Integrated Bolster and Head Support:** The bouncer features an integrated bolster and a removable head support for added comfort and support, especially for younger infants.
-



Image: A close-up of the bouncer's seat, highlighting the soft, removable headrest and the vibrant geometric pattern of the fabric.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from Bright Starts showcasing the Toucan Tango Bouncer's features and design.

5. MAINTENANCE AND CARE

- **Cleaning the Seat Pad:** The seat pad is machine-washable. Remove it from the frame by unfastening all straps and clips. Wash in cold water on a gentle cycle. Do not bleach. Tumble dry on low heat or air dry.
- **Frame Cleaning:** Wipe the metal and plastic components of the frame with a damp cloth and mild soap. Do not immerse the control unit in water.
- **Storage:** For compact storage, the bouncer frame can be partially disassembled. The legs can be detached from the main seat unit.

6. TROUBLESHOOTING

- **No Vibration/Music:** Check if the batteries are correctly installed and not depleted. Replace with fresh 3 C batteries if necessary. Ensure the switches on the control unit are in the 'ON' position.

- **Unstable Frame:** Verify that all frame components are fully clicked into place during assembly. Ensure the bouncer is placed on a flat, stable surface.
- **Toy Bar Detaches Easily:** Ensure the toy bar is inserted firmly into its slots until it clicks. It is designed for easy removal, but should remain secure during normal use.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	22.6"D x 17.13"W x 20.47"H (57.4cm D x 43.5cm W x 51.9cm H)
Item Model Number	10589
Batteries Required	3 C batteries (not included)
Target Gender	Unisex
Minimum Weight Recommendation	6.61 Pounds (3 kg)
Maximum Weight Recommendation	20 Pounds (9 kg)
Material Type	65% Metal, 20% Plastic, 15% Polyester
Care Instructions	Seat pad is machine-washable
Item Weight	3.7 pounds (1.68 kg)



Image: A visual representation of the bouncer's dimensions, showing its height, width, and depth.

8. WARRANTY INFORMATION

This product comes with a limited warranty against manufacturing defects. For specific details regarding warranty coverage, duration, and how to make a claim, please refer to the warranty card included with your purchase or visit the official Bright Starts website.

9. CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Bright Starts Toucan Tango Baby Bouncer, please contact our customer support team. Contact information can be found on the product packaging or the official Bright Starts website. You can also visit the [Bright Starts Store](#) for more products and information.