

GE WB25X10029

GE WB25X10029 Incandescent Lamp 30w Instruction Manual

[Introduction](#) [Safety Information](#) [Product](#)
[Overview](#) [Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and effective installation, operation, and maintenance of your GE WB25X10029 Incandescent Lamp 30w. Please read this manual thoroughly before installation and retain it for future reference.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- **WARNING:** Disconnect power to the fixture before installing, removing, or servicing the lamp. Failure to do so may result in electric shock or serious injury.
- Ensure the lamp wattage (30w) matches the fixture's requirements. Do not exceed the maximum wattage rating of the fixture.
- Do not use this lamp in wet locations or where it may be directly exposed to water.
- Allow the lamp to cool completely before handling. Hot lamps can cause burns.
- Dispose of old lamps according to local regulations.
- This lamp is designed for specific applications. Refer to your appliance's manual for compatibility.

3. PRODUCT OVERVIEW

The GE WB25X10029 is a 30-watt incandescent lamp designed as an authorized replacement part for various GE brand models. It provides general lighting and features dimmable functionality, making it suitable for applications requiring adjustable light levels.



Image of the GE WB25X10029 Incandescent Lamp, a 30-watt incandescent bulb. This bulb is a genuine replacement part for compatible GE appliances.

4. INSTALLATION

Follow these steps to safely install your GE WB25X10029 Incandescent Lamp:

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the light fixture or appliance where the lamp will be installed. Turn off the power completely to prevent electric shock.
2. **Allow Cooling:** If replacing an existing lamp, allow the old lamp to cool down completely before touching it.
3. **Remove Old Lamp:** Carefully unscrew the old lamp counter-clockwise from its socket. If the lamp is broken, use pliers to remove the base, ensuring power is off.
4. **Inspect Socket:** Check the lamp socket for any damage or debris. Clean if necessary.
5. **Install New Lamp:** Gently screw the new GE WB25X10029 lamp clockwise into the socket until it is snug. Do not overtighten.

6. **Restore Power:** Once the new lamp is securely installed, restore power to the fixture or appliance from the circuit breaker or fuse box.
7. **Test:** Turn on the light switch or appliance to confirm the lamp is functioning correctly.

5. OPERATION

The GE WB25X10029 Incandescent Lamp operates like a standard incandescent bulb. Once installed and power is supplied, it will illuminate when the associated switch or control is activated.

- **On/Off:** Use the fixture's or appliance's power switch to turn the lamp on or off.
- **Dimming:** This lamp is dimmable. If your fixture or appliance is equipped with a compatible dimmer switch, you can adjust the light intensity. Ensure the dimmer is rated for incandescent loads.

6. MAINTENANCE

Minimal maintenance is required for the GE WB25X10029 Incandescent Lamp.

- **Cleaning:** Ensure power is off and the lamp is cool before cleaning. Wipe the lamp with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Replacement:** Replace the lamp when it burns out. Follow the installation steps outlined in Section 4.

7. TROUBLESHOOTING

If your GE WB25X10029 Incandescent Lamp is not functioning as expected, consider the following:

Problem	Possible Cause	Solution
Lamp does not light up.	No power to the fixture.	Check circuit breaker or fuse. Ensure the switch is on.
	Lamp not screwed in properly.	Turn off power, then re-tighten the lamp in the socket.
	Lamp is burned out.	Replace the lamp with a new GE WB25X10029.
Lamp flickers.	Loose connection.	Turn off power, then re-tighten the lamp.
	Incompatible dimmer switch.	Ensure dimmer is rated for incandescent lamps and is functioning correctly.

8. SPECIFICATIONS

Key specifications for the GE WB25X10029 Incandescent Lamp 30w:

- **Brand:** GE
- **Model Number:** WB25X10029
- **Light Type:** Incandescent
- **Wattage:** 30 watts
- **Special Feature:** Dimmable
- **Specific Uses:** General Lighting

- **Material Type:** Tungsten
- **Shape:** Tubular (T)
- **Accepted Voltage Frequency:** 100 to 240 Volts and 50 Hertz to 60 Hertz
- **Item Weight:** 4.54 g
- **UPC:** 717449205704

9. WARRANTY & SUPPORT

For warranty information regarding your GE WB25X10029 Incandescent Lamp, please refer to the documentation provided with your original appliance or contact the retailer where the lamp was purchased. As an authorized aftermarket product, warranty terms may vary.

For technical support or further assistance, please contact GE customer service or the authorized seller of this product.

© 2023 GE Appliances. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question