

Samsung DC61-02595A

Samsung DC61-02595A Dryer Lint Filter Instruction Manual

INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your Samsung DC61-02595A Dryer Lint Filter. Adhering to these guidelines will help ensure optimal performance and longevity of your dryer and the filter.

SAFETY INFORMATION

Always prioritize safety when working with appliances. Before performing any installation or maintenance, ensure the dryer is unplugged from the electrical outlet to prevent electric shock or injury.

SETUP AND INSTALLATION

The Samsung DC61-02595A filter is designed for easy replacement. Follow these steps to install your new lint filter:

1. **Power Disconnection:** Unplug your Samsung dryer from the wall outlet.
2. **Locate Filter Housing:** Open the dryer door and locate the existing lint filter housing, typically found inside the door opening or on the top panel.
3. **Remove Old Filter:** Grasp the handle of the old lint filter and pull it straight out. Dispose of the old filter responsibly.
4. **Insert New Filter:** Carefully slide the new Samsung DC61-02595A lint filter into the filter housing. Ensure it is fully seated and flush with the dryer opening. Do not force the filter.
5. **Verify Fit:** Close the dryer door and ensure it latches properly. The filter should not obstruct the door.
6. **Reconnect Power:** Plug the dryer back into the electrical outlet.



Image: Samsung DC61-02595A Dryer Lint Filter. This image shows the complete lint filter assembly, including the frame and mesh screen, ready for installation into a compatible Samsung dryer.

OPERATING INSTRUCTIONS

Once the filter is installed, ensure it is properly seated before each use of the dryer. The lint filter plays a crucial role in preventing lint buildup and maintaining drying efficiency. Operating the dryer without a lint filter or with a damaged filter can lead to reduced performance and potential fire hazards.

MAINTENANCE

Regular maintenance of your lint filter is essential for optimal dryer performance and safety.

- **Clean After Every Load:** Remove and clean the lint filter after every dryer load. Pull the filter out and remove any accumulated lint by hand.
- **Deep Cleaning:** Periodically, or if you notice a film buildup on the screen, wash the lint filter with warm, soapy water. Use a soft brush to gently scrub the mesh. Rinse thoroughly and allow it to air dry completely before reinserting it into the dryer.
- **Inspect for Damage:** Regularly inspect the filter for tears, holes, or damage to the frame. A damaged filter can allow lint to bypass the screen and accumulate inside the dryer, posing a fire risk and reducing efficiency.
- **Replacement:** Replace the lint filter if it becomes damaged or if the mesh screen is no longer effective at trapping lint. The lifespan of the filter can vary depending on usage.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------------|---|---|
| Reduced Drying Efficiency | Clogged lint filter; damaged filter. | Clean the lint filter thoroughly. If damaged, replace the filter. |
| Filter Not Fitting Properly | Incorrect filter model; obstruction in housing. | Ensure you have the correct model (DC61-02595A). Check the filter housing for any debris or obstructions. |
| Lint Accumulation Around Filter | Filter not fully seated; damaged filter. | Push the filter firmly into place. Inspect for damage and replace if necessary. |

If troubleshooting steps do not resolve the issue, contact Samsung customer support or a qualified appliance technician.

SPECIFICATIONS

Model Number: DC61-02595A

Brand: Samsung

Material: Paper (Note: This refers to the filter media, not the frame)

Item Weight: Approximately 6.2 ounces

Product Dimensions: Approximately 8 x 12 x 3 inches

Compatible Devices: Various Samsung brand dryer models (refer to your dryer's manual for specific compatibility)

Reusability: Disposable (Note: While cleanable, it is designed for eventual replacement)

WARRANTY INFORMATION

Warranty coverage for the Samsung DC61-02595A Dryer Lint Filter is typically provided by the manufacturer or the seller at the time of purchase. Please refer to your purchase documentation or contact the retailer/manufacturer directly for specific warranty terms and conditions. Keep your proof of purchase

for any warranty claims.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Samsung customer service or the authorized seller from whom you purchased this product. You may find contact information on the official [Samsung Store](#) or through your product's original documentation.