Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wet Brush SPB830PNPR2

Wet Brush Original Detangler Hair Brush 2-Pack Instruction Manual

Model: SPB830PNPR2

Introduction

The Wet Brush Original Detangler is designed to gently loosen knots and tangles from both wet and dry hair. Its unique IntelliFlex bristles are crafted to minimize pulling, snagging, and breakage, promoting healthier-looking hair. This manual provides essential information on the proper use, care, and specifications of your Wet Brush Original Detangler.



Image: The Wet Brush Original Detangler 2-Pack, featuring one pink and one purple brush.

Setup

The Wet Brush Original Detangler requires no assembly. Remove the brushes from their packaging. Inspect both brushes for any visible damage before first use. No batteries or power source are required for operation.

Operating Instructions

The Wet Brush Original Detangler is suitable for all hair types, including straight, wavy, textured, curly, and thick hair. Its flexible IntelliFlex bristles are designed to glide through knots with ease.




Image: The Wet Brush is effective on various hair textures, including straight, wavy, textured, curly, and thick hair.

How to Use:

1. **Hold the Brush:** Grip the brush comfortably in your hand. The ergonomic design ensures a secure hold.
2. **Start Detangling:** Begin brushing your hair from the ends and work your way up to the roots. This method helps to gently untangle knots without causing damage.
3. **Wet or Dry Hair:** The Wet Brush can be used effectively on both wet and dry hair. The IntelliFlex bristles are designed to be gentle on fragile wet hair and efficient on dry hair.
4. **Gentle Strokes:** Use gentle, smooth strokes. Avoid aggressive pulling or tugging, as this can lead to hair breakage.

The IntelliFlex bristles are designed to reduce breakage by up to 55% compared to traditional brushes, promoting healthier hair.



Image: A close-up view of the IntelliFlex bristles, demonstrating their flexible design.

Official Product Videos:

Wet Brush Original Detangler

Video: An overview of the Wet Brush Original Detangler, showcasing its features and benefits for various hair types.

Wet Brush - Detangle Your Day

Video: A demonstration of the Wet Brush in action, highlighting its ability to detangle hair smoothly and efficiently.

Maintenance

Cleaning Your Brush:

1. **Remove Loose Hair:** Regularly remove any loose hair caught in the bristles. You can use your fingers or a comb to

gently pull out accumulated hair.

2. **Wash the Brush:** For a deeper clean, wash the brush with mild soap and lukewarm water. Gently scrub the bristles and the base to remove any product buildup.
3. **Rinse and Dry:** Rinse thoroughly under running water to remove all soap residue. Shake off excess water and allow the brush to air dry completely with the bristles facing down to prevent water from pooling in the cushion.

Troubleshooting

Common Issues:

- **Bristles Bending or Falling Out:** While IntelliFlex bristles are durable, excessive force or improper storage can cause them to bend or detach. Avoid storing the brush with bristles pressed against hard surfaces. If bristles are significantly damaged, it may be time to replace the brush for optimal performance.
- **Hair Not Detangling Effectively:** Ensure you are starting from the ends of your hair and working upwards. If your hair is severely tangled, consider using a detangling spray or conditioner before brushing.
- **Product Buildup:** If the brush feels sticky or leaves residue on your hair, it likely has product buildup. Follow the cleaning instructions in the Maintenance section.

Specifications

Feature	Detail
Brand	Wet Brush
Model Number	SPB830PNPR2
UPC	736658969405, 736658950397
Product Dimensions	10.25 x 6.25 x 1.55 inches
Item Weight	6.4 ounces
Color	Pink/Purple
Bristle Material	Nylon (IntelliFlex)
Handle Material	Plastic

Warranty and Support

For warranty information or customer support, please refer to the official Wet Brush website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

© 2025 Wet Brush. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01GTR6164

More documents and user manuals: **https://manuals.plus/**