

[Manuals.plus](#) /

› [Y Team](#) /

› Y Team Dual USB PS4 Controller Charging Dock Station Instruction Manual

Y Team XWN-PS4-001

Y Team Dual USB PS4 Controller Charging Dock Station Instruction Manual

Model: XWN-PS4-001

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Y Team Dual USB PS4 Controller Charging Dock Station. Please read this manual thoroughly before use to ensure proper functionality and safety.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x PS4 Controller Charging Dock Station
- 1 x USB Charging Cable
- 1 x Instruction Manual (this document)




Image: Package contents including the charging dock, USB cable, and manual.

SETUP INSTRUCTIONS

Follow these steps to assemble and connect your charging dock station:

1. **Assemble the Charging Dock:** The charging dock consists of a base and a stand. Align the stand with the slots on the base and gently push down until it clicks into place. Ensure it is securely attached.
2. **Connect the USB Cable:** Insert the micro USB end of the charging cable into the USB port located at the back of the charging dock.
3. **Power Connection:** Connect the standard USB end of the cable to a power source. This can be a PS4 console, a computer

USB hub, or a standard USB AC adapter (not included).



Dual Charging Dock
Charge PS-4 Controller
Charger simultaneously.



DC 5V MicroUSB Socket
Powered by USB charging
cable.



Assembly the Controller
Charger.



Put The Controller On The
Stand.



Full Charged-Blue Light.

Image: Step-by-step assembly of the charging dock and controller placement.

Multitple Power Supply

Computer AC Adapter P4 Console USB Hub



Image: Various power input methods for the charging station.


Video: Official Y Team product display demonstrating the unboxing and assembly of the PS4 controller charger.

OPERATING INSTRUCTIONS

The charging dock is designed for ease of use. Follow these steps to charge your PS4 controllers:

- 1. Place Controllers:** Gently align the micro USB port on your PS4 wireless controller with the charging pin on the dock. Place the controller onto the stand, ensuring a secure connection. The dock supports simultaneous charging of two controllers.
- 2. LED Indicator:** The LED indicator lights will show the charging status:
 - **Blue Light (Dock Powered):** The dock's LED lights will turn blue when connected to power and no controllers are charging, or when controllers are fully charged.
 - **Red Light (Charging):** When a controller is placed on the dock and is charging, the corresponding LED light will turn red.
- 3. Charging Time:** A single controller typically takes approximately 2 hours to fully charge. Charging two controllers

simultaneously may take slightly longer.



Intel ligent protection

Bult-in intelligent chip, it will not overcharge to protect your controller.



Over-Current Protection



Over-Voltage Protection



Over-Heated Protection



Short-Circuit Protection

Image: LED indicators showing charging status (Red for charging, Blue for fully charged).

2.5 Hours Fast Charging

Save your time to have more fun



Image: Fast charging capability, indicating approximately 2.5 hours for two controllers.

Video: Official Y Team video demonstrating the fast charging process of the PS4 controller charger.

SAFETY FEATURES

The Y Team charging dock is equipped with an intelligent protection chip to ensure safe and reliable charging:

- **Over-Charging Protection:** Prevents controllers from being overcharged, extending battery life.
- **Over-Heated Protection:** Monitors temperature to prevent overheating during charging.
- **Over-Current Protection:** Safeguards against excessive current flow.
- **Over-Voltage Protection:** Protects against voltage spikes.
- **Short-Circuit Protection:** Prevents damage from short circuits.
- **Over-Discharge Protection:** Ensures controllers are not excessively discharged.



Image: Intelligent protection chip with multiple safety features.

COMPATIBILITY

This charging dock is fully compatible with the following PlayStation 4 wireless controllers:

- PlayStation 4 (PS4)
- PlayStation 4 Pro (PS4 Pro)
- PlayStation 4 Slim (PS4 Slim)

LED Indicator

The light clearly indicate the charging status

Red
Charging

Blue
Full Charged



Image: Compatibility with PS4, PS4 Pro, and PS4 Slim controllers.

MAINTENANCE

To ensure the longevity and optimal performance of your charging dock, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the charging dock. Avoid using abrasive cleaners or solvents, as these can damage the surface.
- **Storage:** When not in use, store the charging dock in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent internal damage.

TROUBLESHOOTING

If you encounter any issues with your charging dock, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Controllers not charging	Loose connection; insufficient power; faulty cable.	Ensure controllers are properly seated. Check USB cable connection to dock and power source. Try a different USB port or power adapter.
LED indicator not lighting up	No power; faulty LED.	Verify power connection. Ensure the USB cable is securely plugged in. If still no light, contact customer support.
Slow charging	Low power output from source; charging two controllers.	Use a power source with adequate output (e.g., a dedicated USB wall adapter). Charging two controllers simultaneously will naturally take longer than one.

SPECIFICATIONS

Feature	Detail
Model Number	XWN-PS4-001
Product Dimensions	6.14 x 3.35 x 4.57 inches
Item Weight	8.2 ounces
Connectivity Technology	USB
Compatible Devices	PlayStation 4 / PS4 Pro / PS4 Slim Controllers
Charging Ports	2 Micro USB Adapter Ports
Charging Time	Approx. 2 hours for one controller
Safety Features	Over-Charging, Over-Heated, Over-Current, Over-Voltage, Short-Circuit, Over-Discharge Protection

WARRANTY AND SUPPORT

Y Team is committed to providing high-quality products and customer satisfaction. For any questions or concerns regarding your PS4 Controller Charging Dock Station, please contact our customer support team.

- **Customer Support:** Please refer to the contact information provided with your product packaging or visit the official Y Team website for assistance.
- **Warranty:** This product comes with a standard manufacturer's warranty. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question