

[Manuals.plus](#) /

› [Satco](#) /

› Satco S9582 LED Bulb User Manual

Satco S9582

Satco S9582 LED Bulb User Manual

Model: S9582

1. INTRODUCTION

Thank you for choosing the Satco S9582 LED Bulb. This manual provides essential information for the safe and efficient use of your new LED bulb. Please read this manual thoroughly before installation and retain it for future reference. The Satco S9582 is a 6.5W T9 LED bulb with a clear finish and a medium (E26) base. It emits 800 lumens of warm white light at 2700K and operates on 120V. Designed with a vintage style, it is dimmable and suitable for damp locations, making it versatile for various indoor and outdoor lighting applications.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing or replacing light bulbs to reduce the risk of fire, electric shock, or injury to persons.

- **WARNING:** Risk of electric shock. Disconnect power before installation.
- Do not use with dimmers not specifically designed for LED bulbs. Use only with compatible dimmers.
- Do not use if the bulb or fixture is damaged.
- Ensure the bulb is securely screwed into the socket.
- This bulb is suitable for damp locations but not for direct exposure to water.
- Do not disassemble or modify the bulb.
- Keep out of reach of children.

3. SETUP AND INSTALLATION

Follow these steps for proper installation of your Satco S9582 LED bulb:

1. **Turn off power:** Before replacing any bulb, ensure the power to the fixture is turned off at the circuit breaker or fuse box.
2. **Allow cooling:** If replacing an old incandescent bulb, allow it to cool completely before touching.
3. **Remove old bulb:** Carefully unscrew the old bulb counter-clockwise from the socket.

4. **Inspect fixture:** Check the fixture's socket for any damage or corrosion.
5. **Install new bulb:** Gently screw the Satco S9582 LED bulb clockwise into the medium (E26) base socket until it is snug. Do not overtighten.
6. **Restore power:** Turn the power back on at the circuit breaker.





Figure 3.1: Front view of the Satco S9582 LED Bulb, showing its clear glass and internal LED filaments.



Figure 3.2: Angled view of the Satco S9582 LED Bulb, highlighting its tubular shape and medium base.

4. OPERATING INSTRUCTIONS

The Satco S9582 LED bulb operates like a standard light bulb once installed. Simply use the light switch connected to the fixture to turn the bulb on or off.

4.1 Dimmable Functionality

This bulb is dimmable, allowing you to adjust the light output to your desired brightness level. For optimal performance and to avoid flickering or buzzing, ensure you use a dimmer switch that is compatible with LED lighting. Consult your dimmer's manual for specific compatibility information.

5. MAINTENANCE

The Satco S9582 LED bulb requires minimal maintenance due to its long lifespan of approximately 15,000 hours.

- **Cleaning:** Before cleaning, ensure the power to the fixture is off and the bulb has cooled. Wipe the bulb with a soft, dry cloth. Do not use liquid or abrasive cleaners.
- **Replacement:** Replace the bulb when its light output significantly diminishes or it ceases to function. Follow the installation steps in Section 3 for replacement.

6. TROUBLESHOOTING

If you experience issues with your Satco S9582 LED bulb, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Bulb does not light up.	No power to the fixture, loose connection, faulty bulb.	Check circuit breaker. Ensure bulb is screwed in tightly. Test bulb in another working fixture.
Bulb flickers or buzzes.	Incompatible dimmer switch, loose connection.	Ensure dimmer is LED compatible. Tighten bulb. If problem persists, try a different dimmer or use without a dimmer.
Light output is too low or too high.	Dimmer setting, incorrect bulb for fixture.	Adjust dimmer setting. Ensure bulb wattage and lumen output are appropriate for your needs.

If these steps do not resolve the issue, please contact Satco customer support or refer to the warranty information.

7. SPECIFICATIONS

Feature	Detail
Model Number	S9582
Brand	Satco
Light Type	LED
Wattage	6.5W
Incandescent Equivalent	60W
Bulb Base	E26 Medium
Light Color	Warm White
Color Temperature	2700K
Brightness	800 Lumens
Voltage	120V
Shape	T9
Material	Glass
Product Dimensions	1.13"W x 12"H
Average Life	15,000 Hours
Special Features	Dimmable, Damp Location Rated, Rated for Fully Enclosed Fixtures
Indoor/Outdoor Usage	Indoor, Outdoor
UPC	045923095825




LED
7W
TUBULAR



60W LED filament
REPLACEMENT resembles
REEMPLAZA incandescent
DE REMPLACEMENT lighting

2700K



3 Year Warranty**

15,000 HOURS
HORAS/HEURES

Medium
Base
Base Media
Culot Moyen

*





Figure 7.1: Packaging of the Satco S9582 LED Bulb, displaying key specifications and features.

8. WARRANTY INFORMATION

The Satco S9582 LED Bulb comes with a **3-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, misuse, abuse, accidents, or unauthorized modifications.

For warranty claims or further details, please retain your proof of purchase and contact Satco customer support.

9. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your Satco S9582 LED Bulb, please visit the official Satco website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

For more information, you may visit the [Satco Store on Amazon](#).

© 2024 Satco. All rights reserved.

Manual Version: 1.0

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01H42IUQM>

More documents and user manuals: <https://manuals.plus/>