

Manuals.plus /

› Pyle /

› Pyle Pro PTED06 Electronic Drum Kit User Manual

Pyle PTED06

Pyle Pro PTED06 Electronic Drum Kit User Manual

Model: PTED06 | Brand: Pyle

1. INTRODUCTION

The Pyle Pro PTED06 is a portable electronic tabletop drum set designed for both beginners and experienced musicians. It offers a comprehensive drumming experience with a variety of sounds and features in a compact form factor.

Key Features:

- 7 drum pads with touch sensitivity, including tom-toms, hi-hat, snare, crash, and ride cymbal.
- Hi-hat and kick bass drum digital pedal controllers for a full drumset sound.
- 55 preset drum kits and 10 custom preloaded drum kits.
- Over 300 cymbal and drum sounds.
- Integrated drum trainer learning mode.
- Digital control panel with LCD screen for audio configuration.
- USB connectivity for MIDI connection to computers.
- AUX input for connecting external audio devices.
- Headphone/output jack for amplifiers or headphones.
- Powered by AC adapter or (6) 'C' batteries for portability.

What's in the Box:

- Pyle Pro PTED06 Electronic Drum Kit
- Drumsticks
- Digital Foot Pedals (Hi-Hat and Kick Bass)
- Wall Power Adapter

What's IN THE BOX



Figure 1.1: Included components of the PTED06 Electronic Drum Kit.

2. SETUP

Follow these steps to set up your Pyle Pro PTED06 Electronic Drum Kit.

2.1 Powering the Unit

- **AC Power:** Connect the included wall power adapter to the DC IN port on the rear of the unit and plug it into a standard electrical outlet.
- **Battery Power:** For portable use, the unit can be powered by (6) 'C' batteries (not included). Open the battery compartment on the underside of the unit and insert the batteries, ensuring correct polarity.

2.2 Connecting Pedals

Connect the two digital foot pedals to the designated PEDAL 1 and PEDAL 2 jacks on the rear of the unit. PEDAL 1 typically controls the Hi-Hat, and PEDAL 2 controls the Kick Bass drum.

2.3 Audio Connections

- **Headphones/Amplifier:** Connect headphones or an external amplifier to the PHONES/OUTPUT jack for private practice or amplified sound.
- **AUX Input:** Use the AUX IN jack to connect external audio devices like MP3 players or smartphones to play along with your favorite music.

2.4 USB MIDI Connection

Connect the unit to a computer using a USB cable (not included) via the USB port. This allows the drum kit to function as a MIDI controller for music production software.



Figure 2.1: Rear panel connections for power, pedals, audio, and USB.

3. OPERATING INSTRUCTIONS

This section details the functions of the Pyle Pro PTED06 and how to operate it.

3.1 Overview of the Digital Control Panel

The central digital control panel features an LCD screen and various buttons for sound selection, kit customization, and learning modes.



Figure 3.1: Labeled diagram of drum pads and control panel.



Clear Control with **3-Digit LED Display**

Easy-to-read LED control display ensures seamless drum kit navigation.

Figure 3.2: Clear control with 3-digit LED display.

3.2 Drum Pads and Sensitivity

The unit features 7 touch-sensitive drum pads. These pads respond to the force of your strike, allowing for dynamic playing. Experiment with different striking techniques to achieve varied sounds.



Figure 3.3: Seven drum pads with touch sensitivity.

3.3 Preset Drum Kits and Sounds

The PTED06 comes with 55 preset drum kits and 10 customizable user kits. You can also access over 300 individual cymbal and drum sounds to create your own unique kits.

- Use the 'KIT' button to cycle through preset drum kits.
- Use the 'VOICE' button to select individual drum or cymbal sounds for each pad when customizing a kit.



55 Drum
Kits

10 Custom User Kits

Preloaded with 55 kits and space for
10 user-defined setups.

Figure 3.4: Explore a wide range of drum kits and sounds.

3.4 Drum Trainer Learning Mode

Utilize the built-in drum trainer to improve your drumming skills. Refer to the detailed instructions in the full user manual (link provided in Section 6) for specific exercises and modes.

3.5 Hand Percussion Mode

The PTED06 features a Hand Percussion Mode, allowing you to play the drum pads with your hands instead of sticks for a different tactile and sonic experience.



Hand Percussion Mode for
A Versatile Experience

Switch to hand percussion mode for
a more dynamic, touch-sensitive performance.

Figure 3.5: Engage Hand Percussion Mode for alternative playing.

4. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Pyle Pro PTED06 Electronic Drum Kit.

4.1 Cleaning

- Wipe the unit with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, waxes, or solvents as

they may damage the finish.

- Avoid spraying cleaning liquids directly onto the unit.

4.2 Storage

- Store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the batteries to prevent leakage.

4.3 General Care

- Avoid dropping the unit or subjecting it to strong impacts.
- Do not place heavy objects on top of the unit.
- Keep the unit away from water and other liquids.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Pyle Pro PTED06.

Problem	Possible Cause	Solution
No sound or low volume	Volume too low; headphones/speakers not connected properly; power issue.	Increase volume using the control panel. Ensure headphones/speakers are fully plugged in. Check power adapter or battery level.
Pedals are unresponsive or double-triggering	Pedal connection loose; pedal sensor issue; pedal sliding on floor.	Ensure pedal cables are securely plugged into the correct jacks. Try unplugging and re-plugging the pedals. Place pedals on a non-slip surface or use Velcro to secure them. If issues persist, contact customer support.
Unit is too loud on startup	Default volume setting is high.	Form a habit of reducing the volume immediately after powering on the unit, especially when using headphones.
Power adapter not compatible (e.g., in EU)	Regional power outlet differences.	Ensure you have the correct power adapter for your region. A voltage converter or a compatible adapter may be required.
Pads not responding or inconsistent sensitivity	Pad sensor issue; firmware issue.	Ensure pads are clean. Try restarting the unit. If the problem persists, refer to the full user manual for calibration or contact customer support.

6. SPECIFICATIONS

Detailed technical specifications for the Pyle Pro PTED06 Electronic Drum Kit.

Feature	Specification
Model Name	Pyle Electronic Drum kit
Item Model Number	PTED06
Item Weight	7.45 Pounds (3.38 kg)
Product Dimensions (L x W x H)	16.5 x 22 x 5.5 inches (41.9 x 55.9 x 14 cm)
Body Material	Bass Wood
Color	Silver
Connector Type	USB, AUX
Power Source	AC Adapter or (6) 'C' Batteries
UPC	068888767590

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your product or visit the official Pyle website. For technical support or service inquiries, please contact Pyle customer service.

A comprehensive user manual in PDF format is available for download:

[Download Pyle Pro PTED06 User Manual \(PDF\)](#)