

## MoKo MK-Kin10-Kin8-CZ-190402F-bk-fA

# MoKo Vertical Flip Stand Case for 6-inch Kindle

Model: MK-Kin10-Kin8-CZ-190402F-bk-fA | Brand: MoKo

## INTRODUCTION

This instruction manual provides guidance for the MoKo Vertical Flip Stand Case, designed to protect and enhance the functionality of your 6-inch Amazon Kindle E-reader. This case is compatible with the following models:

- Amazon 6-inch All New Kindle 11th Generation (2022/2023)
- Amazon 6-inch Kindle 10th Generation (2019 Release)
- Amazon 6-inch Kindle 8th Generation (2016 Release)

**Important:** Please confirm the model number on the back of your E-reader device is **Cav2I3**, **J9G29R**, or **SY69JL** before using this case. This case is **NOT** compatible with Kindle Paperwhite 10th Generation 2018 Release or other Amazon Kindle/Fire Tablet models.





Image: Compatibility chart illustrating supported 6-inch Kindle models (8th, 10th, 11th Gen) and incompatible 6.8-inch Kindle Paperwhite (11th Gen).

## SETUP

Follow these steps to properly install your Kindle E-reader into the MoKo case:

1. Gently align your 6-inch Kindle E-reader with the case's internal frame.
2. Press the Kindle firmly into the frame until it is securely seated. Ensure all corners are properly fitted.
3. Verify that all ports, buttons, and controls are accessible through the case's precise cutouts.



Image: A Kindle E-reader being inserted into the MoKo case, highlighting the snug fit and material quality.

## OPERATING INSTRUCTIONS

### Auto Wake/Sleep Function

The case features an automatic wake/sleep function. Simply open the front cover to wake your Kindle E-reader, and close it to put your device to sleep. This magnetic closure helps conserve battery life.

## Auto Wake / Sleep



Image: Visual representation of the auto wake/sleep feature, showing the Kindle screen activating upon opening the case and sleeping upon closing.

### Vertical Flip Stand

The case is designed with a vertical flip stand feature, allowing for hands-free viewing at multiple angles. The front cover can be folded back and secured into one of the three anti-slip strips to create a stable stand. This design aims to reduce strain during extended reading sessions.



# Multiple Viewing Angles

3 cozy angles, hand-free reading.





Image: The MoKo case configured as a vertical stand, showcasing three different viewing angles for hands-free use.

## Access to Controls and Charging

The case provides precise cutouts for full access to all Kindle controls and features, including the power button and charging port, ensuring hassle-free operation without needing to remove the device from the case.

# Tailored Cutouts Hassle-free Operation



Power Button



Charging Port

Image: Detailed view of the case's precise cutouts for the power button and charging port, ensuring full accessibility.

## Magnetic Closure

In addition to the auto wake/sleep function, the case features a magnetic closure to keep the front cover securely closed when not in use, providing an additional layer of protection for your Kindle E-reader.



Image: The magnetic back cover of the case, illustrating how it secures the front flap when folded back.

## Product Overview Video

Your browser does not support the video tag.

Video: An official product video from MoKo (BSCstore) demonstrating the vertical flip cover case for Kindle 10th Gen 2019 and Kindle 8th Gen 2016, highlighting its features and functionality.

## MAINTENANCE

To ensure the longevity and appearance of your MoKo case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior PU leather with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Interior Care:** The microfiber lining is designed to protect your screen. If it becomes dusty, gently wipe it with a dry, lint-free cloth.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.
- **Storage:** When not in use, store the case in a clean, dry environment.

## TROUBLESHOOTING



If you encounter any issues with your MoKo case, consider the following:

- **Kindle does not fit:** Double-check the compatibility section and your Kindle's model number. Ensure you are not attempting to install an incompatible device.
- **Auto Wake/Sleep not working:** Ensure your Kindle E-reader is properly seated within the case and that the magnetic front cover is fully closed. Magnets must align correctly for the function to activate.
- **Stand is unstable:** Make sure the Kindle is securely placed in one of the anti-slip grooves on the front cover. Adjust the angle to find a stable position on a flat surface.
- **Difficulty accessing ports/buttons:** Confirm the Kindle is correctly aligned within the case's frame. The precise cutouts should allow unobstructed access.

## SPECIFICATIONS

Feature	Detail
Brand	MoKo
Model Number	MK-Kin10-Kin8-CZ-190402F-bk-fA
Compatible Devices	6-inch Amazon Kindle E-readers (11th Gen 2022, 10th Gen 2019, 8th Gen 2016)
Material	PU Leather (exterior), Microfiber (interior)
Color	Black
Item Weight	4 ounces
Product Dimensions	7 x 5 x 0.7 inches
Special Features	Auto Wake/Sleep, Vertical Flip Stand, Magnetic Closure, Precise Cutouts
Items Included	1 x Tablet Case

## WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the retailer's policy where the product was purchased or contact MoKo customer service directly. You can often find support information on the official MoKo brand store page:

[Visit the MoKo Store on Amazon](#)