

[Manuals.plus](#) /

› [Powell](#) /

› Powell Willow Teal Blue Side Chair (Set of 2) User Manual

Powell 16D8214SCX

Powell Willow Teal Blue Side Chair (Set of 2) User Manual

Model: 16D8214SCX | Brand: Powell

INTRODUCTION

Thank you for choosing the Powell Willow Teal Blue Side Chair. This set of two chairs is designed to bring charm and comfort to your dining space. Featuring a calming teal blue finish with a dry-brushed glaze and subtle wormhole distressing, these chairs offer a vintage-inspired character. The gracefully turned legs and chiseled edges highlight thoughtful craftsmanship, while the padded seat, upholstered in soft, natural-toned 100% polyester fabric, provides both style and support. Built with a sturdy rubberwood and plywood frame, these chairs have a 275 lb weight capacity and are intended for residential use only.

IMPORTANT SAFETY INFORMATION

WARNING: This product can expose you to chemicals including Formaldehyde, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

Always follow the assembly instructions carefully to ensure the chair is properly assembled and stable. Tighten all hardware securely to prevent wobbling or instability. This item is designed for personal spaces and is not intended for commercial or heavy-duty environments.

PARTS LIST

Please ensure all parts are present before beginning assembly. Refer to the assembly video for visual guidance.

Your browser does not support the video tag.

Video Description: An animated video demonstrating the parts included for the Powell Willow Dining Collection Side Chair - Set of 2, and the assembly process. This video is provided by the seller, Powell.

- **Backrest Assembly (A):** 2 units
- **Seat Cushion (B):** 2 units
- **Front Legs (C):** 2 units
- **Rear Legs (D):** 2 units
- **Front Stretcher (E):** 2 units
- **Side Stretchers (F):** 2 units

- **1/4" x 80mm Bolts (G):** 8 units
- **1/4" x 60mm Bolts (H):** 8 units
- **1/4" x 38mm Washers (J):** 4 units
- **#4 x 38mm Screws (K):** 8 units
- **Allen Wrench (L):** 2 units

ASSEMBLY INSTRUCTIONS

Assembly is required for these chairs. It is recommended that two people assemble this unit. Do not fully tighten any bolts until all bolts have been started.

Step 1: Attach Seat to Backrest

Align the seat cushion (B) with the backrest assembly (A). Secure using the 1/4" x 80mm bolts (G) and 1/4" x 38mm washers (J) with the Allen wrench (L). Do not fully tighten at this stage.



Image Description: A close-up side view of one assembled chair, showing the distressed teal blue finish and the upholstered seat.

Step 2: Attach Legs and Stretchers

Attach the front legs (C) and rear legs (D) to the seat assembly. Then, connect the front stretcher (E) and side stretchers (F) between the legs. Use the 1/4" x 60mm bolts (H) and the Allen wrench (L) to secure all

connections. Ensure all parts are correctly oriented before tightening.



Image Description: A front view of the assembled chair, highlighting the comfortable upholstered seat and the elegant turned legs.

Step 3: Final Tightening and Leveling

Once all bolts are in place, gradually tighten them completely. Place the chair on a level surface. If the chair wobbles, adjust the leg levelers (if applicable) or slightly loosen and re-tighten the bolts while applying pressure to the seat to ensure even contact with the floor. Use the #4 x 38mm screws (K) with a screwdriver to secure the seat to the frame from underneath.

Your browser does not support the video tag.

Video Description: A short preview video from the seller, Powell, showcasing the assembled Willow Side Chair. This video provides a quick visual of the finished product.

USAGE

These chairs are designed for dining purposes and are suitable for various interior styles including farmhouse, coastal, or traditional. The armless design allows them to tuck neatly under most dining tables, maximizing space. The comfortable upholstered seating provides a cozy perch for extended dining and gatherings.

HOW TO CHOOSE THE PERFECT STOOL HEIGHT

Chair Type	Table Height (in)	Seat Height (in)
Dining Chair	28-35	18-23
Counter Stool	35-39	24-27
Bar Stool	41-43	28-33

DINING CHAIR
Dining chairs have a seat height of **18" to 23"** and are perfect for dining tables **28" to 35"** high.

COUNTER STOOL
Counter stools have a seat height of **24" to 27"** and are perfect for countertops and tables **35" to 39"** high.

BAR STOOL
Bar stools have a seat height of **28" to 33"** and are perfect for bars and tables **41" to 43"** high.

Image Description: A visual guide on how to choose the perfect stool height, showing a dining chair with a seat height of 18-23 inches for tables 28-35 inches high.

CARE AND MAINTENANCE

To maintain the beauty and longevity of your chairs, follow these simple care instructions:

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the finish or fabric.
- **Fabric Care:** The 100% polyester fabric is designed for performance. For spills, blot immediately with a clean, dry cloth. For tougher stains, a mild fabric cleaner suitable for polyester can be used, following

the product's instructions.

- **Wood Care:** The protective lacquer finish makes the wood easy to clean. Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent fading or cracking.
- **Regular Checks:** Periodically check and tighten all bolts and screws to ensure the chair remains stable and secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair wobbles	Loose bolts or uneven legs.	Ensure all bolts are securely tightened. Place the chair on a flat surface and apply pressure to the seat while tightening to ensure even contact with the floor. Adjust leg levelers if present.
Difficulty during assembly	Incorrect alignment of parts or bolts.	Review the assembly video and instructions. Ensure parts are correctly oriented before inserting bolts. Do not fully tighten bolts until all are started.
Scratches on floor	Lack of protective pads on chair legs.	Attach felt pads or other floor protectors to the bottom of each chair leg.

SPECIFICATIONS

Feature	Detail
Brand	Powell
Model Number	16D8214SCX
Color	Teal Blue
Material	Rubberwood, Plywood (Frame), 100% Polyester (Seat Fabric), Foam (Fill)
Product Dimensions (D x W x H)	23" x 19.5" x 40"
Item Weight	29 Pounds (per chair)
Maximum Weight Recommendation	275 Pounds
Assembly Required	Yes
Recommended Use	Residential Dining

SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact Powell customer support. Refer to your purchase documentation for specific contact details or visit the official Powell website.

