

Child Craft F09514.87

Child Craft Toddler Bed Guard Rail Instruction Manual

Model: F09514.87

INTRODUCTION

This manual provides instructions for the safe and proper installation and use of your Child Craft Toddler Bed Guard Rail, Model F09514.87. This guard rail is designed to convert specific Child Craft 4-in-1 convertible cribs into a toddler bed, providing a secure transition for your child. Please read all instructions carefully before assembly and use.

Important Safety Note: This guard rail is designed and tested for safe use **only** with compatible Child Craft cribs. Do not attempt to use this guard rail with cribs from other brands or modify the guard rail or crib, as this can compromise safety.

COMPATIBLE CRIB MODELS

The F09514.87 Toddler Bed Guard Rail is compatible with the following Child Craft convertible crib collections:

- Abbott
- Ashton
- Coventry
- Bradford
- Camden
- Elin
- Kelsey
- Lucas
- Penelope
- Redmond
- Sheldon
- Tanner

Ensure your crib model number matches one of the following for proper fit: F31902, F16201, F36211, F32401, F31001, F37101, F34201, F36701, F36901, F32801, F33401, F32501.

SETUP AND INSTALLATION

This guard rail is designed for easy attachment to your compatible Child Craft convertible crib. The installation process requires the removal of the crib's front panel.

Required Items (Not Included with Guard Rail):

- Original hardware from your Child Craft convertible crib.
- Tools required for disassembling the crib's front panel (refer to your original crib instruction manual).

Installation Steps:

1. **Prepare the Crib:** Refer to your original Child Craft crib instruction manual for specific steps on how to safely remove the front panel of your convertible crib. Ensure all hardware associated with the front panel is removed and stored safely.
2. **Position the Guard Rail:** Align the Child Craft Toddler Bed Guard Rail with the designated attachment points on the crib where the front panel was previously located. The guard rail is designed to fit securely into these points.
3. **Secure the Guard Rail:** Using the original hardware provided with your Child Craft crib (specifically the hardware used for the front panel attachment), securely fasten the toddler guard rail to the crib frame. Ensure all connections are tight and stable. Do not overtighten.
4. **Verify Stability:** After installation, gently push and pull on the guard rail to confirm it is firmly attached and does not wobble.




Image 1: Child Craft Toddler Bed Guard Rail (Cool Gray)



Image 2: Toddler Bed Guard Rail installed on a compatible Child Craft crib.

OPERATING INSTRUCTIONS

Once installed, the Child Craft Toddler Bed Guard Rail provides a secure barrier to prevent your child from rolling out of bed while allowing easy access for them to enter and exit independently. The guard rail is fixed and does not require any operational adjustments.

Regularly check the guard rail for any signs of damage or loose connections. Ensure the mattress fits snugly within the crib frame and against the guard rail, leaving no gaps that could pose a entrapment hazard.

CARE AND MAINTENANCE

To maintain the quality and safety of your Child Craft Toddler Bed Guard Rail:

- **Cleaning:** Wipe the guard rail with a damp cloth. Avoid using abrasive cleaners or strong chemicals, as these can damage the non-toxic finish.
- **Inspections:** Periodically inspect all hardware and connections to ensure they remain tight. Tighten any loose screws or bolts as needed.
- **Damage:** If any part of the guard rail becomes damaged, discontinue use immediately and contact Child Craft customer support for replacement parts or guidance. Do not attempt to repair damaged components yourself.
- **Storage:** If storing the guard rail, ensure it is kept in a dry, temperate environment away from direct sunlight or extreme temperatures to prevent warping or damage to the wood.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Guard rail does not fit the crib.	Crib is not a compatible Child Craft model, or the wrong hardware is being used.	Verify your crib model number against the list of compatible models in this manual. Ensure you are using the original hardware from your Child Craft crib.
Guard rail is wobbly or loose after installation.	Hardware is not tightened sufficiently, or components are not properly aligned.	Re-check all connections and tighten screws firmly. Ensure the guard rail is correctly seated in the crib's attachment points. Do not overtighten.
Missing hardware.	The guard rail does not include new hardware; it reuses hardware from the original crib.	Locate the original hardware that came with your Child Craft crib, specifically the bolts and nuts used for the front panel. If lost, contact Child Craft customer support for replacement hardware.

PRODUCT SPECIFICATIONS

Model Number: F09514.87

Material: Pinewood

Finish: Non-toxic

Color: Cool Gray (as per current product variant)

Dimensions: 51.5 x 1 x 15.5 inches (Length x Width x Height)

Guard Rail Height: 14 inches

Item Weight: 5 pounds

UPC: 849801004981




Image 3: Dimensional view of the Toddler Bed Guard Rail.

WARRANTY INFORMATION

Specific warranty details for the Child Craft Toddler Bed Guard Rail are typically provided with the original product packaging or can be found on the official Child Craft website. Please refer to those resources for comprehensive warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, replacement parts, or any questions regarding your Child Craft Toddler Bed Guard Rail, please contact Child Craft customer support. Contact information can usually be found on the manufacturer's website or on the product packaging.

Online Resources: Visit the official Child Craft website for product registration, FAQs, and additional support materials.

© 2024 Child Craft. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question