

[Manuals.plus](#) /

› [AMERICAN PHOENIX](#) /

› American Phoenix 5x5 Pop Up Portable Canopy Tent Instruction Manual

AMERICAN PHOENIX 5x5 Pop Up Portable Canopy Tent



American Phoenix 5x5 Pop Up Portable Canopy Tent

INSTRUCTION MANUAL

Introduction

Thank you for choosing the American Phoenix 5x5 Pop Up Portable Canopy Tent. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your canopy tent. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information:

- Do not leave the tent up overnight in heavy rain or strong winds.
- Always secure the tent with ropes and stakes to prevent collapse or damage due to wind.
- Ensure all locking mechanisms are fully engaged during setup.
- Keep children and pets away from the tent during assembly and disassembly.

Package Contents

Verify that all components are present before beginning assembly:

- 1x Pop Up Tent Frame
- 1x Canopy Top Cover
- 4x Ropes
- 4x Stakes
- 1x Carry Bag



Figure 1: All components included with the American Phoenix 5x5 Pop Up Portable Canopy Tent.

Setup Instructions

For optimal safety and ease, it is recommended that two people set up this canopy tent.

1. **Unpack the Frame:** Remove the folded frame from the carry bag and place it in the center of your desired setup area.
2. **Partially Expand the Frame:** With one person at each end, gently pull the outer legs of the frame outwards, partially expanding it. Do not fully extend yet.
3. **Attach the Canopy Top:** Drape the canopy top cover over the partially expanded frame. Align the corners of the canopy with the corners of the frame. Secure the canopy to the frame using the hook-and-loop fasteners or clips provided on the canopy.
4. **Fully Expand the Frame:** Continue to pull the outer legs of the frame outwards until the frame is fully extended. Ensure all truss bars are straight and the frame is stable.
5. **Lock the Frame:** Locate the thumb button locking mechanisms on each leg. Push these buttons and slide the leg connectors upwards until they click into place, securing the frame in its fully open

position.

6. **Adjust Height:** Press the thumb button on each leg to adjust the height. There are multiple height positions available (e.g., 8FT, 8.25FT, 8.5FT, 8.75FT). Ensure all four legs are set to the same height for stability.
7. **Secure the Tent:** For outdoor use, always secure the tent using the provided ropes and stakes. Attach ropes to the canopy corners and stake them firmly into the ground at an angle.




Figure 2: Detail of the frame's corner protection and adjustable height setting.

Operating Instructions

The American Phoenix 5x5 Pop Up Portable Canopy Tent is designed for temporary outdoor use, providing shade and shelter.

- **Sun Protection:** The polyester canopy with PU coating offers significant protection from sunlight.
- **Water Resistance:** The canopy is waterproof with sealed seams to prevent water seepage. However, it is not designed for prolonged exposure to heavy rain.
- **Wind Resistance:** The tent is designed to withstand moderate wind conditions when properly

secured with ropes and stakes. Always monitor weather conditions and disassemble the tent if strong winds are expected.

- **Height Adjustment:** Adjust the tent height as needed for various activities or ground conditions using the thumb button mechanism on each leg.



Figure 3: Key features of the canopy tent: Anti-UV, Windproof, and Waterproof.

Maintenance

- **Cleaning the Canopy:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow the canopy to dry completely before folding and storing to prevent mildew.
- **Frame Care:** The steel framework is powder-coated for rust and corrosion resistance. Wipe down the frame with a damp cloth if it becomes dirty. Inspect the frame periodically for any signs of damage or wear.
- **Storage:** Always disassemble the tent and store it in the provided carry bag when not in use. Store in a dry, cool place away from direct sunlight to prolong its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Difficulty expanding/collapsing frame	Frame joints are stiff or misaligned.	Ensure two people are assisting. Gently wiggle joints to loosen. Check for obstructions.
Tent unstable or wobbling	Legs not fully extended or locked; tent not secured.	Verify all thumb buttons are locked. Use ropes and stakes to anchor the tent firmly.
Water pooling on canopy	Insufficient tension on canopy; heavy rain.	Ensure canopy is taut. Disassemble in heavy rain to prevent damage.

Specifications

Feature	Detail
Brand	AMERICAN PHOENIX
Model	5x5 Pop Up Portable Canopy Tent
Material	Alloy Steel (Frame), Polyester PU coated (Canopy)
Color	Red (as per current product variant)
Product Dimensions	59"L x 59"W x 106"H (approx. 5'x5' footprint)
Item Weight	25 Pounds
Ultraviolet Light Protection	0.99 (High UV protection)
Water Resistance Level	Waterproof
Assembly Required	Yes
Height Positions	3 positions: 8FT, 8.25FT, 8.5FT, 8.75FT (maximum peak height)




Figure 4: Detailed dimensions and adjustable height ranges.

Warranty and Support

Specific manufacturer warranty details are not provided in the product information. For warranty inquiries or support, please refer to your purchase documentation or contact the seller directly.

For additional assistance or to explore other products, visit the official American Phoenix store:

[Visit the AMERICAN PHOENIX Store](#)