

TRIXIE 49929

TRIXIE 49929 Wall-Mounted Scratching Post Instruction Manual

Model: 49929

1. PRODUCT OVERVIEW

The TRIXIE 49929 Wall-Mounted Scratching Post is designed to provide a durable and space-saving scratching surface for your cat. It features a sturdy post wrapped in natural sisal, essential for healthy claw maintenance, and is topped and bottomed with soft plush material for comfort. This wall-mounted design allows for flexible placement and can complement existing cat furniture.





A full view of the Trixie 49929 Wall-Mounted Scratching Post, showing its grey plush top and bottom, and the natural sisal rope wrapped around the main column.

2. SAFETY INSTRUCTIONS

- Always ensure the scratching post is securely mounted to a solid wall stud or using appropriate wall anchors for your wall type. Failure to do so may result in injury to your pet or damage to property.
- Keep all packaging materials away from children and pets to prevent choking hazards.
- Regularly inspect the scratching post for any signs of wear, damage, or loose parts. Replace or repair as necessary to ensure continued safety.
- This product is intended for feline use only. Do not allow children to climb or play on the scratching post.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x TRIXIE 49929 Scratching Post (Ø 11 × 80 cm)
- 1 x Wall Mounting Bracket
- 1 x Set of Wall Mounting Hardware (screws, anchors)

4. SETUP AND INSTALLATION

Follow these steps to securely install your wall-mounted scratching post:

1. **Choose Location:** Select a suitable wall location, preferably near your cat's favorite resting or play areas. Ensure the wall material can support the weight of the scratching post and your cat.
2. **Mark Drilling Points:** Hold the wall mounting bracket against the wall at the desired height. Use a pencil to mark the positions for the screw holes. Use a level to ensure the bracket is straight.
3. **Drill Pilot Holes:** Using an appropriate drill bit for your wall type and the provided anchors/screws, drill pilot holes at the marked points. If drilling into drywall, insert the wall anchors. If drilling into a wood stud, pilot holes are still recommended.
4. **Attach Bracket:** Secure the wall mounting bracket to the wall using the provided screws. Ensure it is firmly attached and does not wobble.
5. **Mount Scratching Post:** The scratching post has a threaded insert at the top. Align this with the threaded bolt on the wall bracket. Carefully screw the scratching post onto the bolt until it is snug against the bracket.
6. **Final Check:** Gently pull on the scratching post to confirm it is securely fastened to the wall before allowing your cat to use it.



This image illustrates the wall-mounting bracket and how the scratching post attaches to it. The bracket is secured to the wall, and the post slides onto a threaded bolt, then secured with a cap.

5. OPERATING INSTRUCTIONS (USAGE)

Once installed, the TRIXIE 49929 Wall-Mounted Scratching Post is ready for use. Encourage your cat to use the post by placing treats or catnip near it, or by gently guiding their paws to the sisal surface. Cats naturally need to scratch to remove dead outer claw sheaths, mark territory, and stretch. Providing a dedicated scratching surface like this post can help protect your furniture.

6. MAINTENANCE

- **Cleaning:** The plush trim can be hand washed only. Do not machine wash or tumble dry. For the sisal, spot clean with a damp cloth and mild detergent if necessary, then allow to air dry completely.
- **Inspection:** Regularly check the sisal wrapping for significant fraying or damage. While sisal is durable, heavy use will eventually wear it down.
- **Mounting Security:** Periodically re-check the tightness of the wall mounting screws to ensure the post remains stable and secure.

7. TROUBLESHOOTING

- **Post feels wobbly after installation:** Re-check all mounting screws and ensure they are tightened securely. Verify that the wall anchors (if used) are properly installed and suitable for your wall type.
- **Cat is not using the scratching post:** Try relocating the post to a more prominent area where your cat frequently scratches or rests. Apply catnip to the sisal surface to attract your cat. Reward your cat with treats when they interact with the post.
- **Sisal is heavily worn:** The sisal rope is designed to be scratched. If it becomes excessively worn, the post may need to be replaced to maintain its effectiveness and appearance.

8. SPECIFICATIONS

Model Number	49929
Brand	TRIXIE
Dimensions (L x W x H)	81.3 cm x 12.7 cm x 12.7 cm (approx. Ø 11 cm x 80 cm)
Weight	1 Kilogram
Material	Natural Sisal, Plush
Color	Grey
Mounting Type	Wall-Mounted
Included Components	Scratching Post, Wall Mounting Material
Care Instructions	Hand wash plush only
Target Species	Cat
Recommended for Breed Size	Small breeds

9. WARRANTY AND SUPPORT

TRIXIE products are manufactured with quality and durability in mind. For specific warranty information, please refer to the documentation provided at the time of purchase or visit the official TRIXIE website. If you encounter any issues or require assistance with your TRIXIE 49929 Wall-Mounted Scratching Post, please contact TRIXIE customer support through their official channels.